SIEMENS



Pressure transmitter SITRANS DS III/P410 with HART

Operating Instructions



Answers for industry.

SIEMENS Introduction Safety instructions Description **SITRANS** Installing/mounting Pressure transmitter SITRANS P DS III/P410 with HART Connecting Operation **Operating Instructions** Operating functions through **HART Functional safety** Commissioning 10 Service and maintenance Technical data **Dimension drawings** Spare parts/accessories **Appendix** 7MF4.33..

List of abbreviations

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

A DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.

▲WARNING

indicates that death or severe personal injury may result if proper precautions are not taken.

ACAUTION

indicates that minor personal injury can result if proper precautions are not taken.

NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

▲ WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduction	onn	11
	1.1	Purpose of this documentation	11
	1.2	Product information	11
	1.3	History	11
	1.4	Scope of the instructions	12
	1.5	Checking the consignment	12
	1.6	Transportation and storage	13
	1.7	Notes on warranty	13
2	Safety ins	tructions	15
	2.1 2.1.1 2.1.2 2.1.3	Precondition for use Other certificates Laws and directives Conformity with European directives	15 15
	2.2	Use in hazardous areas	
3	Descriptio	on	
	3.1	System configuration	
	3.2	Application range	20
	3.3	Structure	21
	3.4	Nameplate layout	23
	3.5	Measuring point label layout	26
	3.6 3.6.1 3.6.2 3.6.3 3.6.3.1 3.6.3.2	Functional principle Overview of mode of operation Operation of the electronics Measuring cell operation Measuring cell for gauge pressure Measuring cell for differential pressure and flow rate	27 27 28 29
	3.6.3.3	Measuring cell for level	
	3.6.3.4 3.6.3.5 3.6.3.6	Measuring cell for absolute pressure from the differential pressure series Measuring cell for absolute pressure from the gauge pressure series Measuring cell for gauge pressure, front-flush membrane	33
	3.6.3.7	Measuring cell for absolute pressure, front-flush membrane	34
	3.7	Remote seal	35
	3.8	SIMATIC PDM	35
4	Installing/	mounting	37
	4.1 4.1.1	Basic safety instructions	

	4.1.2	Proper mounting	41
	4.2	Disassembly	42
	4.3	Installation (except level)	43
	4.3.1	Instructions for installation (except level)	
	4.3.2	Installation (except level)	
	4.3.3	Fastening	44
	4.4	"Level" installation	
	4.4.1	Instructions for level installation	
	4.4.2	Installation for level	
	4.4.3	Connection of the negative pressure line	
	4.5	"Remote seal" installation	
	4.5.1	Remote seal installation	
	4.5.2	Installation of the remote seal with the capillary line	52
	4.6	Turing the measuring cell against housing	58
	4.7	Rotating the display	59
5	Connecting	g	61
	5.1	Basic safety instructions	61
	5.2	Connecting the device	64
	5.3	Connecting the Han plug	66
	5.4	Connecting the M12 connector	67
6	Operation.		71
	6.1	Overview of operation	71
	6.2	Basic safety instructions	72
	6.3	Instructions for operation	72
	6.4	Display	73
	6.4.1	Display elements	
	6.4.2	Units display	
	6.4.3	Error display	
	6.4.4	Mode display	76
	6.4.5	Status display	76
	6.4.6	Overflow range	77
	6.5	Local operation	78
	6.5.1	Local control elements	
	6.5.2	Operation using buttons	
	6.5.3	Start of scale value/full scale value	
	6.5.3.1	Difference between setting and adjusting	
	6.5.3.2	Setting/adjusting the start of scale value	
	6.5.3.3	Setting/adjusting the full scale value	
	6.5.4	Setting/adjusting electrical damping	
	6.5.5	Blind start of scale value/full scale value	
	6.5.5.1	Difference between setting/adjusting and blind setting/adjusting	
	6.5.5.2	Blind setting of start of scale value	
	6.5.5.3 6.5.5.4	Blind setting of full scale valueBlind adjusting of the start of scale value	
	0.5.5.4	Dilliu aujusting of the start of scale value	92

	6.5.5.5	Blind adjustment of the full scale value	
	6.5.6	Trimming the zero point	
	6.5.7 6.5.8	Current simulator Output current in case of fault	
	6.5.9	Locking buttons and functions	
	6.5.10	Releasing key lock or function lock	
	6.5.11	Flow rate measurement (only differential pressure)	
	6.5.12	Measured value display	
	6.5.13	Unit	
7	Operating	g functions through HART	107
	7.1	Operating functions through HART communication	107
	7.2	Process tag data	108
	7.3	Selecting the measuring modes	108
	7.3.1	Overview of measuring modes	
	7.3.2	Measuring mode selector	
	7.3.3	Variable mapper	
	7.3.4 7.3.5	Measuring mode "Pressure" Customized characteristic curve	
	7.3.6	Measuring mode "Level"	
	7.3.7	Measuring mode "Flow rate"	
	7.3.8	Measuring mode "User"	
	7.3.9	Measured value status	
	7.3.10	Analog output	
	7.3.11	Scaling the display value	
	7.4	Setting zero point and limit point	124
	7.5	Blind setting of zero point and limit point	125
	7.6	Zero point calibration (position correction)	125
	7.7	Electrical damping	126
	7.8	Fast response mode	126
	7.9	Current sensor	126
	7.10	Fault current	126
	7.11	Setting the current limits	127
	7.12	Key lock and write protection	128
	7.13	Measured value display	129
	7.14	Selection of the physical unit	130
	7.15	Bar graph	131
	7.16	Sensor calibration	131
	7.16.1	Sensor trim	
	7.16.2	Trimming the sensor	132
	7.17	Current simulator trim	132
	7.18	Factory calibration	134
	7.19	Static configuration data	134

	7.20	Flow rate measurement (only differential pressure)	136
	7.21 7.21.1 7.21.2 7.21.3 7.21.4 7.21.5	Diagnostic functions Overview Operating hours counter Calibration timer and service timer Min/max indicator Limit modules	136 137 137 138
	7.22 7.22.1 7.22.2 7.22.3	Simulation	141 142
	7.23	Limit monitor	143
8	Functiona	l safety	147
	8.1	Safety function	147
	8.2	Safety Integrity Level (SIL)	149
	8.3	Settings	151
	8.4	Safety characteristics	152
	8.5 8.5.1 8.5.2 8.5.2.1 8.5.2.2 8.5.2.3 8.5.2.4 8.5.2.5	Maintenance/check Overview Checking safety function/proof test Checking temperature sensors Simulating fault current Two-point measurement ≥ 10% of the maximum measuring range Two-point measurement ≥ 50% of the maximum measuring range Checking pressure transmitter for external damage	152 153 155 155 155
	8.6 8.6.1 8.6.2	Add-on partsChecking a device with add-on pneumatic block	160
9	Commissi	oning	163
	9.1	Basic safety instructions	163
	9.2	Introduction to commissioning	163
	9.3 9.3.1 9.3.2	gauge pressure, absolute pressure from the differential pressure series and absolute pressure from the gauge pressure series	164
	9.4 9.4.1 9.4.2 9.4.3 9.4.4	Differential pressure and flow rate	167 167 168 170
10	Service a	nd maintenance	175
	10.1	Basic safety instructions	175
	10.2	Maintenance and repair work	178

	10.2.1	Defining the maintenance interval	
	10.2.2 10.2.3	Checking the gaskets	
	10.2.4	Changing the measuring cell and application electronics	
	10.3	Cleaning	181
	10.3.1	Servicing the remote seal measuring system	181
	10.4	Return procedure	183
	10.5	Disposal	184
11	Technical	data	185
	11.1	Overview of technical data	185
	11.2	SITRANS P DS III input	186
	11.3	SITRANS P410 input	192
	11.4	Output	194
	11.5	Measuring accuracy of SITRANS P DS III	195
	11.6	Measuring accuracy of SITRANS P410	203
	11.7	Operating conditions	205
	11.8	Construction	209
	11.9	Display, keyboard and auxiliary power	214
	11.10	Certificates and approvals	216
	11.11	HART communication	217
12	Dimension	n drawings	219
	12.1	SITRANS P, DS III/P410 for gauge pressure and absolute pressure from the gauge pressure series	219
	12.2	SITRANS P DS III/P410 for differential pressure, flow rate and absolute pressure from the differential pressure series	221
	12.3	SITRANS P DS III/P410 for level	224
	12.4	SITRANS P DS III/P410 (flush mounted)	225
	12.4.1	Note 3A and EHDG	
	12.4.2 12.4.3	Connections as per EN and ASME	
	12.4.3	F&B and pharma flangePMC Style	
	12.4.5	Special connections	
13	Spare par	ts/accessories	235
	13.1	Order data	235
	13.2	Order data for SIMATIC PDM	237
Α	Appendix.		239
	A.1	Certificate	239
	A.2	Literature and standards	239
	A.3	Literature and catalogs	239

	A.4	Overview of HART operating structure	240
	A.5	Technical support	243
B List of abbreviations		reviations	245
	Glossary		247
	Index		251

Introduction

1.1 Purpose of this documentation

These instructions contain all information required to commission and use the device. Read the instructions carefully prior to installation and commissioning. In order to use the device correctly, first review its principle of operation.

The instructions are aimed at persons mechanically installing the device, connecting it electronically, configuring the parameters and commissioning it, as well as service and maintenance engineers.

SITRANS P DS III and SITRANS P410

These instructions describe the pressure transmitters SITRANS P DS III and SITRANS P410. The main difference of the SITRANS P410 is the higher measuring precision compared to the SITRANS P DS III. Refer to the information in the section Technical data (Page 185).

You order SITRANS P410 using the order option C41 for specific device versions.

1.2 Product information

The programming manual is an integral part of the CD, which is either supplied or can be ordered. The programming manual is also available on the Siemens homepage.

On the CD, you will also find the catalog extract with the ordering data, the Software Device Install for SIMATIC PDM for additional installation, and the required software.

See also

Product information on SITRANS P in the Internet (http://www.siemens.com/sitransp)

Process instrumentation catalog (http://www.siemens.com/processinstrumentation/catalogs)

1.3 History

This history establishes the correlation between the current documentation and the valid firmware of the device.

1.4 Scope of the instructions

The documentation of this edition applies to the following firmware:

Edition	Firmware identifier nameplate	System integration	Installation path for PDM
5/2015	FW: 11.03.03, FW: 11.03.04, FW: 11.03.05, FW: 11.03.06	SIMATIC PDM 8.x	SITRANS P DSIII: SITRANS P DSIII.2
			SITRANS P410: SITRANS P DSIII.2/P410

The most important changes in the documentation when compared with the respective previous edition are given in the following table.

Edition	Remark	
5/2015	The following chapters have been changed:	
	"Functional safety" chapter	
	"Technical data" chapter	

1.4 Scope of the instructions

Table 1- 1 "7MF4.33.." stands for:

Order number	SITRANS P DS III/P410 for	
7MF4033	Gauge pressure	
7MF4133	Gauge pressure, flush mounted diaphragm	
7MF4233	Absolute pressure from the gauge pressure series	
7MF4333	Absolute pressure from the differential pressure series	
7MF4433	Differential pressure and flow rate, PN 32/160 (MAWP 464/2320 psi)	
7MF4533	Differential pressure and flow rate, PN 420 (MAWP 6092 psi)	
7MF4633	Level	

1.5 Checking the consignment

- 1. Check the packaging and the delivered items for visible damage.
- 2. Report any claims for damages immediately to the shipping company.

- 3. Retain damaged parts for clarification.
- 4. Check the scope of delivery by comparing your order to the shipping documents for correctness and completeness.



Using a damaged or incomplete device

Danger of explosion in hazardous areas.

· Do not use damaged or incomplete devices.

See also

Return procedure (Page 183)

1.6 Transportation and storage

To guarantee sufficient protection during transport and storage, observe the following:

- Keep the original packaging for subsequent transportation.
- Devices/replacement parts should be returned in their original packaging.
- If the original packaging is no longer available, ensure that all shipments are properly
 packaged to provide sufficient protection during transport. Siemens cannot assume
 liability for any costs associated with transportation damages.



Insufficient protection during storage

The packaging only provides limited protection against moisture and infiltration.

Provide additional packaging as necessary.

Special conditions for storage and transportation of the device are listed in "Technical data" (Page 185).

1.7 Notes on warranty

The contents of this manual shall not become part of or modify any prior or existing agreement, commitment or legal relationship. The sales contract contains all obligations on the part of Siemens as well as the complete and solely applicable warranty conditions. Any statements regarding device versions described in the manual do not create new warranties or modify the existing warranty.

The content reflects the technical status at the time of publishing. Siemens reserves the right to make technical changes in the course of further development.

1.7 Notes on warranty

Safety instructions 2

2.1 Precondition for use

This device left the factory in good working condition. In order to maintain this status and to ensure safe operation of the device, observe these instructions and all the specifications relevant to safety.

Observe the information and symbols on the device. Do not remove any information or symbols from the device. Always keep the information and symbols in a completely legible state.

2.1.1 Other certificates



Figure 2-1 Chinese Manufacturing Certificate

Symbol	Explanation
Ŵ	Consult operating instructions

2.1.2 Laws and directives

Observe the test certification, provisions and laws applicable in your country during connection, assembly and operation. These include, for example:

- National Electrical Code (NEC NFPA 70) (USA)
- Canadian Electrical Code (CEC) (Canada)

Further provisions for hazardous area applications are for example:

- IEC 60079-14 (international)
- EN 60079-14 (EC)

2.1 Precondition for use

2.1.3 Conformity with European directives

The CE mark on the device is a sign of conformity with the following European directives:

Electromagnetic Compatibil- Directive of the European Parliament and of the Council on the ity EMC approximation of the laws of the Member States relating to electromagnetic compatibility and repealing Directive 89/336/EEC.

Atmosphère explosible Directive of the European Parliament and the Council on the approximation of the laws of the Member States concerning equipment and protective systems intended for use in potential-

ly explosive atmospheres.

Pressure Equipment Directive PED

rective PED 97/23/EC Directive of the European Parliament and of the Council on the approximation of the laws of the Member States concerning pressure equipment.

The standards applied can be found in the EC declaration of conformity for the device.



WARNING

Improper device modifications

Danger to personnel, system and environment can result from modifications to the device, particularly in hazardous areas.

Only carry out modifications that are described in the instructions for the device. Failure
to observe this requirement cancels the manufacturer's warranty and the product
approvals.

Due to the large number of possible applications, each detail of the described device versions for each possible scenario during commissioning, operation, maintenance or operation in systems cannot be considered in the instructions. If you need additional information not covered by these instructions, contact your local Siemens office or company representative.

Note

Operation under special ambient conditions

We highly recommend that you contact your Siemens representative or our application department before you operate the device under special ambient conditions as can be encountered in nuclear power plants or when the device is used for research and development purposes.

2.2 Use in hazardous areas

Qualified personnel for hazardous area applications

Persons who install, connect, commission, operate, and service the device in a hazardous area must have the following specific qualifications:

- They are authorized, trained or instructed in operating and maintaining devices and systems according to the safety regulations for electrical circuits, high pressures, aggressive, and hazardous media.
- They are authorized, trained, or instructed in carrying out work on electrical circuits for hazardous systems.
- They are trained or instructed in maintenance and use of appropriate safety equipment according to the pertinent safety regulations.



Unsuitable device for the hazardous area

Danger of explosion.

 Only use equipment that is approved for use in the intended hazardous area and labelled accordingly.

See also

Technical data (Page 185)



Loss of safety of device with type of protection "Intrinsic safety Ex i"

If the device has already been operated in non-intrinsically safe circuits or the electrical specifications have not been observed, the safety of the device is no longer ensured for use in hazardous areas. There is a danger of explosion.

- Connect the device with type of protection "Intrinsic safety" solely to an intrinsically safe circuit.
- Observe the specifications for the electrical data on the certificate and/or in Chapter "Technical data (Page 185)".

A WARNING

Use of incorrect device parts in potentially explosive environments

Devices and their associated device parts are either approved for different types of protection or they do not have explosion protection. There is a danger of explosion if device parts (such as covers) are used for devices with explosion protection that are not expressly suited for this type of protection. If you do not adhere to these guidelines, the test certificates and the manufacturer warranty will become null and void.

- Use only device parts that have been approved for the respective type of protection in the potentially explosive environment. Covers that are not suited for the "explosionproof" type of protection are identified as such by a notice label attached to the inside of the cover with "Not Ex d Not SIL".
- Do not swap device parts unless the manufacturer specifically ensures compatibility of these parts.

AWARNING

Risk of explosion due to electrostatic charge

To prevent the build-up of an electrostatic charge in a hazardous area, the key cover must be closed during operation and the screws tightened.

The key cover may be opened temporarily at any time for the purposes of operating the pressure transmitter, even during plant operation; the screws should then be tightened again.

NOTICE

Electrostatic-sensitive devices

The device contains electrostatic-sensitive devices (ESD). ESD can be destroyed by voltages far too low to be detected by humans. These voltages can occur if you simply touch a component part or the electrical connections of a module without being electrostatically discharged. The damage to a module caused by overvoltage cannot normally be detected immediately; it only becomes apparent after a longer period of operating time has elapsed.

Protective measures against the discharge of static electricity:

- Make sure that no power is applied.
- Before working with modules, make sure that you discharge static from your body, for example by touching a grounded object.
- Devices and tools used must be free of static charge.
- Hold modules only by their edges.
- Do not touch connector pins or conductor tracks on a module with the ESD notice.

Description

3.1 System configuration

Overview

The pressure transmitter can be used in a number of system configurations:

- as a stand-alone version, supplied with the necessary auxiliary power
- as part of a complex system environment, e.g. SIMATIC S7

System communication

Communication is via the HART protocol, using:

- HART Communicator (load 230 ... 1100 Ω)
- PC with HART modem, on which appropriate software is installed, e.g. SIMATIC PDM (load 230 ... 500 Ω)
- Control system which can communicate via the HART protocol, e.g. SIMATIC PCS7




Figure 3-1 Possible system configurations

3.2 Application range

Overview

Depending on the variant, the pressure transmitter measures corrosive, non-corrosive and hazardous gases, vapors and liquids.

You can use the pressure transmitter for the following types of measurement:

- Gauge pressure
- Absolute pressure
- Differential pressure

With appropriate parameter settings and the necessary add-on parts (e.g. flow limiters and remote seals), the pressure transmitter can also be used for the following measurements:

- Level
- Volume
- Mass
- Volumetric flow
- Mass flow rate

The output signal is always a load-independent direct current between 4 and 20 mA.

You can install the "intrinsically-safe" or "flameproof enclosure" version of the pressure transmitter in hazardous areas. The devices have an EC type examination certificate and comply with the appropriate harmonized European CENELEC directives.

Pressure transmitters with remote seals of various shapes can be provided for special applications. For example, measuring high-viscosity substances is a special application.

Gauge pressure

This version measures aggressive, non-aggressive and hazardous gases, vapors and liquids.

The smallest span is 0.01 bar g (0.145 psi g), and the largest 700 bar g (10153 psi g).

Differential pressure and flow rate

This version measures corrosive, non-corrosive and hazardous gases, vapors and liquids. You can use this version for the following measurement types:

- differential pressure, e.g. effective differential pressure
- Gauge pressure, suitable for small positive or negative pressure value
- in combination with a restrictor device: flow rate $q \sim \sqrt{\Delta p}$

The smallest measuring span is 1 mbar (0.0145 psi), the largest 30 bar (435 psi).

Level

This version with mounting flange measures the level of non-corrosive, corrosive and hazardous liquids in open and closed containers. The smallest measuring span is 25 mbar (0.363 psi), the largest 5 bar (72.5 psi). The nominal diameter of the mounting flange is DN 80 or DN 100 or 3" or 4".

The negative connection of the measuring cell is kept open when measuring the level of open containers. This measurement is referred to as "measurement against atmosphere". The negative connection is normally connected with the container when measuring the level of closed containers. This balances the static pressure.

Wetted parts are made of various materials, depending on corrosion resistance requirements.

Absolute pressure

This version measures the absolute pressure of aggressive, non-aggressive and hazardous gases, vapors and liquids.

There are two series: a "differential pressure" series and a "gauge pressure" series. The "differential pressure" series is distinguished by a high overload capability.

The smallest measuring span of the "differential pressure" series is 8.3 mbar a (0.12 psi a), and the largest is 100 bar a (1450 psi a).

The smallest measuring span of the "gauge pressure" series is 8.3 mbar a (0.12 psi a), and the largest is 30 bar a (435 psi a).

3.3 Structure

Depending on a customer-specific order, the device comprises different parts.

3.3 Structure




Figure 3-2 View of the pressure transmitter: Left: Front right: Rear view

- The electronics enclosure is made of die cast aluminum or precision cast stainless steel.
- The housing has a removable circular cover at the front and the back.
- Depending on the device version, the front cover ② may be designed as an inspection window. You can read the measured values straight off the digital display through this inspection window.
- The cable inlet ® to the electrical terminal compartment is at the side; either the left or right-hand one can be used. The unused opening is closed with a blanking plug ③.
- The protective conductor terminal/equipotential bonding terminal ① is located at the back of the enclosure.
- The electrical terminal compartment ⁽¹⁾ for the auxiliary power and shield is accessible when you remove the back cover ⁽⁹⁾.
- The measuring cell with a process connection (a) is located in the lower section of the enclosure. This measuring cell is secured against twisting by a retaining screw (b). Thanks to the modular design of the pressure transmitter, the measuring cell and application electronics or connection board can be replaced if required.
- On the upper face of the enclosure you can see crosshead screws which secure the key cover ①, under which there are 3 keys for local operation.

3.4 Nameplate layout

Layout of nameplate with general information

The nameplate bearing the order number and other important information, such as design details and technical data, is on the side of the enclosure.




Figure 3-3 Example of SITRANS P DS III nameplate

3.4 Nameplate layout




Figure 3-4 Example of SITRANS P410 nameplate

Layout of nameplate with approval information

The nameplate with approval information is on the opposite side. This nameplate shows the hardware and firmware versions, for example. You must also observe the information in the relevant certificate for a pressure transmitter version for use in hazardous areas.





Figure 3-5 Example for approval plate SITRANS P DS III



- 1 Characteristics of the hazardous area
- 2 Category for operating area
- 3 Type of protection
- 4 Group (gas, dust)
- Figure 3-6 Example for approval plate SITRANS P410
- (5) Maximum surface temperature (temperature class)
- 6 Device protection level
- 7 Firmware ID
- (8) Hardware identifier

Measuring point label layout 3.5




Figure 3-7 Example of measuring point label

3.6 Functional principle


3.6.1 Overview of mode of operation

This chapter describes how the pressure transmitter works.

First the electronics are described, and then the physical principle of the sensors which are used with the various device versions for the individual measurement types.

3.6.2 Operation of the electronics

Description



 U_{H}

Auxiliary power

Figure 3-8 Operation of the electronics with HART communication

Each with an EEPROM in the measuring cell

and in the electronics

6

3.6 Functional principle

Function

- The input pressure is converted into an electrical signal by the sensor ①.
- This signal is amplified by the measuring amplifier ② and digitized in an analog-to-digital converter ③.
- The digital signal is analyzed in a microcontroller ④ and corrected with regard to linearity and thermal characteristics.
- The digital signal is then converted in a digital-to-analog converter ⑤ into the output current of 4 to 20 mA. A diode circuit provides reverse voltage protection.
- You can make an uninterrupted current measurement with a low resistance ammeter at the connection ¹(0).
- The measuring cell-specific data, electronics data and parameter assignment data are saved in two EEPROMs ⑥. The first memory is linked to the measuring cell, the second to the electronics.

Operation

- The buttons (a) can be used to call up individual functions, so-called modes.
- If you have a device with a display ①, you can use it to track the mode settings and other device messages.
- The basic mode settings can be changed with a computer and HART modem ⑦ via PDM.

3.6.3 Measuring cell operation



WARNING

Destruction of the seal diaphragm

Danger of injury or damage to device

If the seal membrane is destroyed, the sensor may also be destroyed. If the seal membrane is destroyed, no reliable measured values can be output.

Hot, toxic and corrosive process media can be released.

- Ensure that the material of the device parts wetted by the process medium is suitable for the medium. Refer to the information in Technical data (Page 185).
- Make sure that the device is suitable for the maximum operating pressure of your system. Refer to the information on the nameplate and/or in Technical data (Page 185).
- Define maintenance intervals for regular inspections in line with device use and empirical values. The maintenance intervals will vary from site to site depending on corrosion resistance.

In the following sections, the process variable to be measured is called general inlet pressure.

Overview


The following modes of operation are described:

- Gauge pressure
- Absolute pressure
- Differential pressure and flow rate
- Level

The following process connections are available, for example:

- G1/2 B, 1/2-14 NPT
- Male thread: M20
- Flange connection in accordance with EN 61518
- Flush-mounted process connections

3.6.3.1 Measuring cell for gauge pressure



- Reference pressure opening
- 2 Measuring cell
- ③ Process connection
- Seal diaphragm


- 5 Filling liquid
- 6 Gauge pressure sensor
- pe Inlet pressure

Figure 3-9 Function chart of measuring cell for gauge pressure

The inlet pressure (p_e) is transferred to the gauge pressure sensor 6 via the seal diaphragm 4 and the fill fluid 5, displacing its measuring diaphragm. The displacement changes the resistance of the four piezoresistors (bridge circuit) of the gauge pressure sensor. The change in the resistance causes a bridge output voltage proportional to the inlet pressure.

Pressure transmitters with spans \leq 6.3 MPa measure the inlet pressure against atmosphere, those with spans \geq 16 MPa the inlet pressure against vacuum.

3.6.3.2 Measuring cell for differential pressure and flow rate




- 1 Inlet pressure P+
- 2 Pressure cap
- 3 O-ring
- 4 Measuring cell body
- 5 Differential pressure sensor

- 6 Overload diaphragm
- Filling liquid
- 8 Seal diaphragm
- Inlet pressure P.

Figure 3-10 Function chart of the measuring cell for differential pressure and flow rate

- Differential pressure is transmitted to the differential pressure sensor ⑤ through the seal diaphragms ⑧ and the filling liquid ⑦.
- When measuring limits are exceeded, the seal diaphragm (a) is displaced until the seal diaphragm rests on the measuring cell body (a). The differential pressure sensor (b) is thus protected against overloading since no further deflection of the overload diaphragm (b) is possible.
- The seal diaphragm ® is displaced by the differential pressure. The displacement changes the resistance of the four piezoresistors (bridge circuit) of the differential pressure sensor.
- The change in the resistance causes a bridge output voltage proportional to the differential pressure.

3.6.3.3 Measuring cell for level




- Pressure cap
- O-ring
- 3 Measuring cell body
- Overload diaphragm
- 5 Differential pressure sensor
- 6 Seal diaphragm on the measuring cell
- (7) Filling liquid of the measuring cell
- 8 Capillary tube with the fill fluid of the mounting flange
- 9 Flange with a tube
- Seal diaphragm on the mounting flange

Figure 3-11 Function chart of the measuring cell for level

- The inlet pressure (hydrostatic pressure) works hydraulically on the measuring cell through the seal diaphragm ⁽¹⁾ on the mounting flange ⁽¹⁾.
- Differential pressure at the measuring cell is transmitted to the differential pressure sensor ⑤ through the seal diaphragms ⑥ and the filling liquid ⑦.
- When measuring limits are exceeded, the overload diaphragm 4 is displaced until one of the seal diaphragms 6 or 10 rests on the measuring cell body 3. The seal diaphragms 6 thus protect the differential pressure sensor 5 from overload.
- The seal diaphragm ⑥ is displaced by the differential pressure. The displacement changes the resistance of the four doped piezoresistors in the bridge circuit.
- The change in the resistance causes a bridge output voltage proportional to the differential pressure.

3.6.3.4 Measuring cell for absolute pressure from the differential pressure series




- 1 Pressure cap
- Seal diaphragm on the measuring cell
- 3 O-ring
- Measuring cell body
- 5 Absolute pressure sensor

- 6 Overload diaphragm
- Measuring cell filling liquid
- 8 Reference pressure
- pe Pressure input variable

Figure 3-12 Function chart of measuring cell for absolute pressure

- Absolute pressure is transmitted to the absolute pressure sensor ⑤ through the seal diaphragm ② and the filling liquid ⑦.
- When measuring limits are exceeded, the overload diaphragm ⑥ is displaced until the seal diaphragm ② rests on the measuring cell body ④. The seal diaphragm thus protects the absolute pressure sensor ⑤ from overload.
- The difference between the inlet pressure (pe) and the reference pressure (a) on the
 negative side of the measuring cell displaces the seal diaphragm (a). The displacement
 changes the resistance of the four piezoresistors (bridge circuit) of the absolute pressure
 sensor.
- The change in the resistance causes a bridge output voltage proportional to the absolute pressure.

3.6.3.5 Measuring cell for absolute pressure from the gauge pressure series




- Measuring cell
- 2 Process connection
- 3 Seal diaphragm

- 4 Filling liquid
- S Absolute pressure sensor
- Pe Inlet pressure

Figure 3-13 Function chart of measuring cell for absolute pressure

The inlet pressure (p_e) is transferred to the absolute pressure sensor 5 via the seal diaphragm 3 and the fill fluid 4, displacing its measuring diaphragm. The displacement changes the resistance of the four piezoresistors (bridge circuit) of the absolute pressure sensor. The change in the resistance causes a bridge output voltage proportional to the inlet pressure.

3.6.3.6 Measuring cell for gauge pressure, front-flush membrane



- Reference pressure opening
- ② Measuring cell
- ③ Process connection
- Seal diaphragm

- 5 Filling liquid
- 6 Gauge pressure sensor
- pe Inlet pressure

Figure 3-14 Function chart of the measuring cell for gauge pressure, flush mounted diaphragm


The inlet pressure (p_e) is transferred to the gauge pressure sensor ⑥ via the seal diaphragm ④ and the filling liquid ⑤, displacing its measuring diaphragm. The displacement changes

3.6 Functional principle

the resistance of the four piezoresistors (bridge circuit) of the gauge pressure sensor. The change in the resistance causes a bridge output voltage proportional to the inlet pressure.

Pressure transmitters with measuring span \leq 63 bar measure the inlet pressure against atmosphere, those with measuring spans \geq 160 bar the inlet pressure against vacuum.

3.6.3.7 Measuring cell for absolute pressure, front-flush membrane



- Measuring cell
- ② Process connection
- ③ Seal diaphragm

- 4 Filling liquid
- S Absolute pressure sensor
- pe Inlet pressure

Figure 3-15 Function chart of the measuring cell for absolute pressure, flush mounted diaphragm

The inlet pressure (pe) is transferred to the absolute pressure sensor ⑤ via the seal diaphragm ③ and the filling liquid ④, and displaces its measuring diaphragm. The displacement changes the resistance of the four piezoresistors (bridge circuit) of the absolute pressure sensor. The change in the resistance causes a bridge output voltage proportional to the inlet pressure.

3.7 Remote seal

Product description

- A remote seal measuring system comprises the following elements:
 - Remote seal
 - Transmission line, e.g. capillary line
 - Pressure transmitter.

Note

Malfunction of the remote seal measuring system

If you separate the components of the remote seal measuring system, this results in malfunctioning of the system.

Do not separate the components under any circumstances.

- The measuring system based on a hydraulic principle is used to transfer pressure.
- The capillary line and the remote seal diaphragm are the most sensitive components in the remote seal measuring system. The material thickness of the remote seal diaphragm is only ~ 0.1 mm.
- The smallest of leakages in the transmission system leads to the loss of transmission fluid.
- The loss of transmission fluid results in inaccuracies in the measurement and failure of the measuring system.
- In order to avoid leaks and measuring errors, please observe the installation and maintenance instructions in addition to the safety notes.

3.8 SIMATIC PDM

SIMATIC PDM is a software package for configuring, parameter assignment, commissioning, diagnostics and maintenance of this device and other process devices.

SIMATIC PDM offers simple monitoring of process values, alarms, and device status information.

SIMATIC PDM allows the process device data to be:

- displayed
- set
- modified
- saved
- diagnosed
- checked for plausibility

3.8 SIMATIC PDM

- managed
- simulated

Installing/mounting 4

4.1 Basic safety instructions



Wetted parts unsuitable for the process media

Danger of injury or damage to device.

Hot, toxic and corrosive media could be released if the process medium is unsuitable for the wetted parts.

• Ensure that the material of the device parts wetted by the process medium is suitable for the medium. Refer to the information in "Technical data" (Page 185).

MARNING

Incorrect material for the diaphragm in Zone 0

Danger of explosion in the hazardous area. If operated with intrinsically safe supply devices of category "ib" or devices of the flameproof enclosure version "Ex d" and simultaneous use in Zone 0, pressure transmitter explosion protection depends on the tightness of the diaphragm.

• Ensure that the material used for the diaphragm is suitable for the process medium. Refer to the information in the section "Technical data (Page 185)".

AWARNING

Unsuitable connecting parts

Danger of injury or poisoning.

In case of improper mounting hot, toxic and corrosive process media could be released at the connections.

 Ensure that connecting parts (such as flange gaskets and bolts) are suitable for connection and process media.

Note

Material compatibility

Siemens can provide you with support concerning selection of sensor components wetted by process media. However, you are responsible for the selection of components. Siemens accepts no liability for faults or failures resulting from incompatible materials.

4.1 Basic safety instructions



WARNING

Exceeded maximum permissible operating pressure

Danger of injury or poisoning.

The maximum permissible operating pressure depends on the device version. The device can be damaged if the operating pressure is exceeded. Hot, toxic and corrosive process media could be released.

 Make sure that the device is suitable for the maximum permissible operating pressure of your system. Refer to the information on the nameplate and/or in "Technical data (Page 185)".



WARNING

Exceeded maximum ambient or process media temperature

Danger of explosion in hazardous areas.

Device damage.

 Make sure that the maximum permissible ambient and process media temperatures of the device are not exceeded. Refer to the information in Chapter "Technical data (Page 185)".



WARNING

Open cable inlet or incorrect cable gland

Danger of explosion in hazardous areas.

 Close the cable inlets for the electrical connections. Only use cable glands or plugs which are approved for the relevant type of protection.



WARNING

Incorrect conduit system

Danger of explosion in hazardous areas as result of open cable inlet or incorrect conduit system.

 In the case of a conduit system, mount a spark barrier at a defined distance from the device input. Observe national regulations and the requirements stated in the relevant approvals.

See also

Technical data (Page 185)

MWARNING

Incorrect mounting at Zone 0

Danger of explosion in hazardous areas.


- Ensure sufficient tightness at the process connection.
- Observe the standard IEC/EN 60079-14.

AWARNING

Danger with "flameproof enclosure" protection

Danger of explosion in hazardous areas. An explosion may be caused by hot gas escaping from the flameproof enclosure if there is too little space between it and the fixed parts.

 Ensure that there is a space of at least 40 mm between the flameproof joint and the fixed parts.



1 Flameproof joint



Loss of explosion protection

Danger of explosion in hazardous areas if the device is open or not properly closed.

• Close the device as described in Chapter "Connecting the device (Page 64)".

4.1 Basic safety instructions



Use of incorrect device parts in potentially explosive environments

Devices and their associated device parts are either approved for different types of protection or they do not have explosion protection. There is a danger of explosion if device parts (such as covers) are used for devices with explosion protection that are not expressly suited for this type of protection. If you do not adhere to these guidelines, the test certificates and the manufacturer warranty will become null and void.

- Use only device parts that have been approved for the respective type of protection in the potentially explosive environment. Covers that are not suited for the "explosionproof" type of protection are identified as such by a notice label attached to the inside of the cover with "Not Ex d Not SIL".
- Do not swap device parts unless the manufacturer specifically ensures compatibility of these parts.



CAUTION

Hot surfaces resulting from hot process media

Danger of burns resulting from surface temperatures above 70 °C (155 °F).

- Take appropriate protective measures, for example contact protection.
- Make sure that protective measures do not cause the maximum permissible ambient temperature to be exceeded. Refer to the information in Chapter "Technical data (Page 185)".



CAUTION

External stresses and loads

Damage to device by severe external stresses and loads (e.g. thermal expansion or pipe tension). Process media can be released.

• Prevent severe external stresses and loads from acting on the device.

4.1.1 Installation location requirements



Insufficient air supply

The device may overheat if there is an insufficient supply of air.

- Install the device so that there is sufficient air supply in the room.
- Observe the maximum permissible ambient temperature. Refer to the information in the section "Technical data (Page 185)".



Aggressive atmospheres

Damage to device through penetration of aggressive vapors.

Ensure that the device is suitable for the application.

NOTICE

Direct sunlight

Increased measuring errors.

· Protect the device from direct sunlight.

Make sure that the maximum ambient temperature is not exceeded. Refer to the information in the section Technical data (Page 185).

4.1.2 Proper mounting

NOTICE

Incorrect mounting

The device can be damaged, destroyed, or its functionality impaired through improper mounting.

- Before installing ensure there is no visible damage to the device.
- Make sure that process connectors are clean, and suitable gaskets and glands are used.
- Mount the device using suitable tools. Refer to the information in Technical data (Page 185) for installation torque requirements.

4.2 Disassembly



Loss of degree of protection

Damage to device if the enclosure is open or not properly closed. The degree of protection specified on the nameplate or in Chapter "Technical data (Page 185)" is no longer guaranteed.

Make sure that the device is securely closed.

See also

Connecting the device (Page 64)

4.2 Disassembly



WARNING

Incorrect disassembly

The following dangers may result through incorrect disassembly:

- Injury through electric shock
- Danger through emerging media when connected to the process
- Danger of explosion in hazardous area

In order to disassemble correctly, observe the following:

- Before starting work, make sure that you have switched off all physical variables such as pressure, temperature, electricity etc. or that they have a harmless value.
- If the device contains dangerous media, it must be emptied prior to disassembly. Make sure that no environmentally hazardous media are released.
- Secure the remaining connections so that no damage can result if the process is started unintentionally.

4.3 Installation (except level)

4.3.1 Instructions for installation (except level)

Requirements

Note

Compare the desired operating data with the data on the nameplate.

Please also refer to the information on the remote seal if this is fitted.

Note

Protect the pressure transmitter from:

- Direct thermal radiation
- Rapid temperature fluctuations
- · Severe soiling
- Mechanical damage
- Direct sunlight

The installation location is to be as follows:

- Easily accessible
- As close as possible to the measuring point
- Vibration-free
- Within the permitted ambient temperature values

Installation configuration

The pressure transmitter may in principle be configured above or below the pressure tapping point. The recommended configuration depends on the aggregate state of the medium.

Installation configuration for gases

Install the pressure transmitter above the pressure tapping point.

Lay the pressure tubing with a constant gradient to the pressure tapping point, so that any condensation produced can drain in the main line and thereby avoid corruption of the measured values.

Installation configuration for vapor and liquid

Install the pressure transmitter below the pressure tapping point.

Lay the pressure tubing with a constant gradient to the pressure tapping point so that any gas pockets can escape in the main line.

4.3 Installation (except level)

4.3.2 Installation (except level)

Note

Damage to measuring cell

When installing the process connection of the pressure transmitter, do not rotate the housing. Rotating the housing may damage the measuring cell.

To avoid damage to the device, tighten the threaded nuts of the measuring cell using a wrench.

Procedure

Attach the pressure transmitter to the process connection with an appropriate tool.

See also

Introduction to commissioning (Page 163)

4.3.3 Fastening

Fastening without the mounting bracket

You can fasten the pressure transmitter directly to the process connection.

Fastening with the mounting bracket

You can fasten the mounting bracket as follows:

- On a wall or a mounting frame using two screws
- On a vertical or horizontal mounting tube (Ø 50 to 60 mm) using a tube bracket

Fasten the pressure transmitter mounting bracket using the two screws provided.




Figure 4-1 Fastening the pressure transmitter on the mounting bracket




Figure 4-2 An example of fastening the pressure transmitter on the mounting bracket in the case of differential pressure and horizontal differential pressure lines

4.4 "Level" installation




Figure 4-3 An example of fastening on the mounting bracket in the case of differential pressure and vertical differential pressure lines

4.4 "Level" installation

4.4.1 Instructions for level installation

Requirements

Note

Compare the desired operating data with the data on the nameplate.

Please also refer to the information on the remote seal if this is fitted.

Note

Protect the pressure transmitter from:

- Direct thermal radiation
- Rapid temperature fluctuations
- Severe soiling
- Mechanical damage
- Direct sunlight

Note

Select the height of the mounting flange such that the pressure transmitter is always mounted below the lowest fill height to be measured.

The installation location is to be as follows:

- Easily accessible
- The measuring point must be as close as possible
- Vibration-free
- Within the permitted ambient temperature values

4.4.2 Installation for level

Note

Seals are required for the installation. The seals must be compatible with the medium to be measured.

Seals are not included in the delivery.

Procedure

To install the pressure transmitter for level, proceed as follows:

1. Attach the seal to the container's mating flange.

Ensure that the seal is centrically positioned and that it does not restrict the movement of the flange's seal diaphragm in any way as otherwise the tightness of the process connection is not guaranteed.


- 2. Screw on the pressure transmitter's flange.
- 3. Observe the installation position.

4.4.3 Connection of the negative pressure line

Assembly on an open container

A line is not required when taking measurements in an open container since the negative chamber is connected with the atmosphere.

Ensure that no dirt enters the open connection ports, for example by using connection screws with a 7MF4997-1CP bleed valve.



Formula:


Start of scale value: $p_{MA} = \rho \cdot g \cdot h_{U}$ Full-scale value: $p_{ME} = \rho \cdot g \cdot h_{O}$

Measurement assembly on an open container

h∪	Lower filling level	Δp_{MA}	Start of scale value
ho	Upper filling level	Δрме	Full-scale value
р	Pressure	ρ	Density of the measured medium in the container
		g	Acceleration due to gravity

Assembly on a closed container

When taking measurements in a closed container without or with little condensate formation, the negative pressure line is not filled. Lay the line in such a way that pockets of condensate do not form. Install a condensation container if required.



Formula:

Start-of-scale value: $\Delta p_{MA} = \rho \cdot g \cdot$

hυ


Full-scale value: $\Delta p_{ME} = \rho \cdot g \cdot h_{O}$

Measurement assembly on a closed container (no or little condensate separation)

h∪	Lower filling level	Δp_{MA}	Start of scale value
ho	Upper filling level	Δ рме	Full-scale value
р	Pressure	ρ	Density of the measured medium in the container
		a	Acceleration due to gravity

4.4 "Level" installation

When taking measurements in a closed container with strong condensate formation, you must fill the negative pressure line (mostly with the condensate of the measured medium) and install a condensate pot. You can cut off the device using the dual pneumatic block 7MF9001-2.



Formula: Start-of-scale value: $\Delta p_{MA} = g \cdot (h_U \cdot \rho - h_V \cdot \rho')$ Full-scale value: $\Delta p_{MA} = g \cdot (h_O \cdot \rho - h_V \cdot \rho')$

Measurement assembly on a closed container (strong condensate formation)

hυ	Lower filling level	Δp_{MA}	Start of scale value
ho	Upper filling level	Δp_{ME}	Full-scale value
h _V	Gland distance	ρ	Density of the measured medium in the container
p	Pressure	ρ'	Density of fluid in the negative pressure line corresponds to the prevailing temperature there
		g	Acceleration due to gravity

The process connection on the negative side is a female thread $^{1}/_{4}$ -18 NPT or an oval flange. Lay the line for the negative pressure using a seamless steel tube 12 mm x 1.5 mm.

4.5 "Remote seal" installation

4.5.1 Remote seal installation

General installation instructions

- Keep the measuring system in the factory packing until it is installed in order to protect it from mechanical damage.
- When removing from the factory packing and installing: ensure that damage to and mechanical deformations in the membrane are prevented.
- Never loosen the sealed filling screws on the remote seal and the measuring instrument.
- Do not cause damage to the remote separating membrane; scratches on the remote separating membrane, e.g. due to sharp-edged objects, are the main starting points for corrosion.
- Select suitable gaskets for sealing.
- Use a gasket having an adequately large inner diameter for flanging. Insert the gasket concentrically; contact with the membrane leads to deviations in measurements.
- When using gaskets made of soft materials or PTFE: follow the guidelines of the gasket manufacturer, especially regarding the tightening torque and setting cycles.
- At the time of installation, use suitable fastening components such as screws and nuts that are compliant with fitting and flange standards.
- Excessive tightening of screwed joints on the process connection may displace the zero point on the pressure transmitter.

Note

Commissioning

If a shut-off valve exists, open the shut-off valve slowly when commissioning in order to avoid pressure surges.

Note

Permissible ambient and operating temperatures

Install the pressure measuring device such that the permissible limits of ambient and measured medium temperatures are not overshot or undershot even with the consideration of the effect of convection and heat radiation.

- Note the effect of temperature on the measuring accuracy.
- When selecting the remote seals, ensure that fittings and flange components have adequate pressure-temperature resistance by selecting suitable materials and pressure ratings. The pressure rating specified on the remote seal applies to reference conditions according to IEC 60770.
- For the maximum permissible pressure at higher temperatures, please refer to the standard specified on the remote seal.

4.5 "Remote seal" installation

Using remote seals with pressure measuring device for hazardous areas:

- When using remote seals with pressure measuring device for hazardous areas, the
 permissible limits of ambient temperatures for the pressure transmitter must not be
 exceeded. Hot surfaces on the cooling section (capillaries or cooling elements) are a
 possible source of ignition. Initiate suitable measures.
- When remote seals with a flame arrestor are used, the pressure measuring instrument determines the permissible ambient temperature. In the case of potentially explosive gaseous atmosphere, the temperature around the flame arrestor must not exceed +60 °C.

4.5.2 Installation of the remote seal with the capillary line


Notes

- Do not rest the measurement assembly on the capillary line.
- Do not bend capillary lines; risk of leakages and/or risk of considerable increase in the setting time of the measuring system.
- Owing to the risk of bending and breakages, pay attention to mechanical overloads at the joints such as capillary line-remote seal and capillary line-measuring device.
- Unwinding the excess capillary lines with a radius of at least 150 mm.
- Fasten the capillary line such that there are no vibrations.
- Permissible height differences:
 - When installing the pressure measuring device above the measuring point, keep the following in mind: In the case of remote seal measuring systems with silicon, glycerin or paraffin oil filling, the height difference of H_{1max}. = 7 m must not be exceeded.
 - If halocarbon oil is used as a fill fluid, this maximum height difference is only H_{1max.} =
 4 m; see installation type A and installation type B.

If negative overpressure is observed during measurements, reduce the permissible height difference accordingly.

Installation type for gauge pressure and level measurements (open containers)


Installation type A



Start of scale value: $p_{MA} = p_{FL} * g * H_U + p_{oil} * g * H_1$ Full-scale value: $p_{ME} = p_{FL} * g * H_0 + p_{oil} * g * H_1$

Pressure transmitter above the measuring point

Installation type B



Start of scale value: $p_{MA} = \rho_{FL} * g * H_U - \rho_{oil} * g * H_1$ Full-scale value: $p_{ME} = \rho_{FL} * g * H_O - \rho_{oil} * g * H_1$

Pressure transmitter below the measuring point

 $H_1 \le 7$ m (23 ft); with halocarbon oil as the filling liquid, only $H_1 \le 4$ m(13.1 ft)

ĸ	ΔV
1.	σv


рма	Start of scale value
рме	Full-scale value
ρFL	Density of the process medium in the container
Poil	Density of the filling oil in the capillary line of the remote seal
g	Acceleration due to gravity
Ηυ	Lower filling level
Ho	Upper filling level
H ₁	Distance between the container flange and the pressure transmitter

For absolute pressure measurements (vacuum), install the measuring device at least at the height of the remote seal or below it (see installation types C).

4.5 "Remote seal" installation


Installation types for absolute pressure measurements (closed containers)

Installation type C₁



Start of scale value: $p_{MA} = p_{start} + p_{oil} * g * H_1$ Full-scale value: $p_{ME} = p_{end} + p_{oil} * g * H_1$

Installation type C₂



Pressure transmitter for absolute pressure always below the measuring point: $H_1 \ge 200$ mm (7.9 inch)

Key

 pMA
 Start of scale value

 pME
 Full-scale value

 pstart
 Start of scale pressure

 pend
 Full scale pressure

 poil
 Density of the filling oil in the capillary line of the remote seal

 g
 Acceleration due to gravity

 H₁
 Distance between the container flange and the pressure transmitter

Note


Effects of temperature

Keep the following instructions in mind in order to minimize keep the effects of temperature in remote seal measuring systems with the differential pressure measuring device:

Install the device such that the positive and negative sides are symmetrical as far as ambient effects, especially ambient temperatures, are concerned.

Installation type for differential pressure and flow rate measurements

Installation type D



Start of scale value: $p_{MA} = p_{start} - p_{oil} * g * H_V$ Full-scale value: $p_{ME} = p_{end} - p_{oil} * g * H_V$

Key

pma Start of scale value
pme Full-scale value

p_{start}Start of scale pressurep_{end}Full scale pressure

 ρ_{oil} Density of the filling oil in the capillary line of the remote seal


g Acceleration due to gravity

H_V Gland distance

4.5 "Remote seal" installation

Installation types for level measurements (closed containers)

Installation type E



Start of scale value:

 $p_{MA} = \rho_{FL} * g * H_U - \rho_{oil} * g * H_V$

Full-scale value:

 p_{ME} = ρ_{FL} * g * H_{U} - ρ_{oil} * g * H_{V}

Key

PMA Start of scale valuePME Full-scale value


 ρ_{FL} Density of the process medium in the container

 ρ_{oil} Density of the filling oil in the capillary line of the remote seal

g Acceleration due to gravity

 $\begin{array}{lll} \text{H}_{\text{U}} & \text{Lower filling level} \\ \text{H}_{\text{O}} & \text{Upper filling level} \\ \text{H}_{\text{V}} & \text{Gland distance} \end{array}$

Installation type G



 $H_1 \le 7$ m (23 ft), for halocarbon oil, however only $H_1 \le 4$ m (13.1 ft)

Start of scale value:


 $p_{MA} = \rho_{FL} * g * H_U - \rho_{oil} * g * H_V$

Full-scale value:

 $p_{ME} = \rho_{FL} * g * H_O - \rho_{oil} * g * H_V$

Pressure transmitter for differential pressure above the upper measuring point, no vacuum

Installation type H



Start of scale value:


 $p_{MA} = \rho_{FL} * g * H_U - \rho_{oil} * g * H_V$

Full-scale value:

 $p_{ME} = \rho_{FL} * g * H_O - \rho_{oil} * g * H_V$

Below the lower measuring point

Installation type J



Between the measuring points, no vacuum

 $H_2 \le 7$ m (23 ft); with halocarbon oil as the filling liquid, only $H_2 \le 4$ m(13.1 ft)

Start of scale value:

 $p_{MA} = \rho_{FL} * g * H_U - \rho_{oil} * g * H_V$

Full-scale value:

 $p_{ME} = \rho_{FL} * g * H_O - \rho_{oil} * g * H_V$

4.6 Turing the measuring cell against housing


Key	
Рма	Start of scale value
рме	Full-scale value
ρfL	Density of the process medium in the container
ροil	Density of the filling oil in the capillary line of the remote seal
g	Acceleration due to gravity
H_{U}	Lower filling level
Ho	Upper filling level
Hv	Gland distance

4.6 Turing the measuring cell against housing

Description

You can turn the measuring cell against the housing. Rotating the pressure transmitter facilitates its operation when it is installed at an angle, for example. The buttons and the current connection can thus also be operated for an external measuring device. The display also remains visible in enclosure covers with an inspection window.

Only limited turning is permissible! The turning range ① is marked at the foot of the electronic housing. An orientation mark ③ is provided at the throat of the measuring cell. This mark must remain in the marked section when turning.



- Turning range
- 2 Retaining screw
- ③ Orientation mark

Figure 4-4 Example: Turning range of pressure transmitters for pressure and absolute pressure from the gauge pressure series

The turning range for pressure transmitters for differential pressure and flow rate, absolute pressure from the differential pressure series and level is identified in a similar manner.

Procedure

NOTICE

Damage to the ribbon cable

If the pressure transmitter enclosure is rotated against the measuring cell, this can damage the ribbon cable (sensor connection to the electronics).

- Comply with the specified range of rotation ① as detailed.
- 1. Loosen the retaining screw ② (Allen screw 2.5 mm).
- 2. Turn the electronic housing against the measuring cell. Follow the marked turning range
 ① while doing so.
- 3. Tighten the retaining screw (torque: 3.4 to 3.6 Nm).

4.7 Rotating the display

You can rotate the display in the electronics enclosure. This makes it easier to read the display if the device is not being operated in a vertical position.

Procedure

- 1. Unscrew the cover of the electrical cable compartment. See section Structure (Page 21). An identification text "FIELD TERMINAL" is provided at the side of the housing.
- 2. Unscrew the display. Depending on the application position of the pressure transmitter, you can reinstall it at four different positions. You can turn it by ±90° or ±180°.
- 3. Screw the covers back on as far as they will go.
- 4. Secure the covers with the cover catch.

4.7 Rotating the display

Connecting

5.1 Basic safety instructions



Unsuitable cables and/or cable glands

Danger of explosion in hazardous areas.

- Only use suitable cables and cable glands complying with the requirements specified in Chapter "Technical data (Page 185)".
- Tighten the cable glands in accordance with the torques specified in Chapter "Technical data (Page 185)".
- When replacing cable glands use only cable glands of the same type.
- After installation check that the cables are seated firmly.



Hazardous contact voltage in versions with 4-conductor extension

Danger of electrocution in case of incorrect connection.

 Observe the instructions in the 4-conductor extension operating manual for the electrical connection.

See also

Technical data (Page 185)



Improper power supply

Danger of explosion in hazardous areas as result of incorrect power supply, e.g. using direct current instead of alternating current.

Connect the device in accordance with the specified power supply and signal circuits.
 The relevant specifications can be found in the certificates, in Chapter "Technical data (Page 185)" or on the nameplate.

5.1 Basic safety instructions



Unsafe extra-low voltage

Danger of explosion in hazardous areas due to voltage flashover.

Connect the device to an extra-low voltage with safe isolation (SELV).



WARNING

Lack of equipotential bonding

Danger of explosion through compensating currents or ignition currents through lack of equipotential bonding.

Ensure that the device is potentially equalized.

Exception: It may be permissible to omit connection of the equipotential bonding for devices with type of protection "Intrinsic safety Ex i".



WARNING

Unprotected cable ends

Danger of explosion through unprotected cable ends in hazardous areas.

Protect unused cable ends in accordance with IEC/EN 60079-14.



WARNING

Improper laying of shielded cables

Danger of explosion through compensating currents between hazardous area and the non-hazardous area.

- Only ground shielded cables that run into the hazardous area at one end.
- If grounding is required at both ends, use an equipotential bonding conductor.



MARNING

Connecting device in energized state

Danger of explosion in hazardous areas.

Connect devices in hazardous areas only in a de-energized state.

Exceptions:

- Circuits of limited energy may also be connected in the energized state in hazardous areas.
- Exceptions for type of protection "Non-sparking nA" (Zone 2) are regulated in the relevant certificate

AWARNING

Incorrect selection of type of protection

Danger of explosion in areas subject to explosion hazard.

This device is approved for several types of protection.

- 1. Decide in favor of one type of protection.
- 2. Connect the device in accordance with the selected type of protection.
- 3. In order to avoid incorrect use at a later point, make the types of protection that are not used permanently unrecognizable on the nameplate.

NOTICE

Ambient temperature too high

Damage to cable sheath.

 At an ambient temperature ≥ 60 °C (140 °F), use heat-resistant cables suitable for an ambient temperature at least 20 °C (36 °F) higher.

NOTICE

Incorrect measured values with incorrect grounding

The device must not be grounded via the "+" connection. It may otherwise malfunction and be permanently damaged.

If necessary, ground the device using the "-" connection.

Note

Electromagnetic compatibility (EMC)

You can use this device in industrial environments, households and small businesses.

For metal housings there is an increased electromagnetic compatibility compared to high-frequency radiation. This protection can be increased by grounding the housing, see Chapter "Connecting the device (Page 64)".

5.2 Connecting the device

Note

Improvement of interference immunity

- Lay signal cables separate from cables with voltages > 60 V.
- · Use cables with twisted wires.
- Keep device and cables in distance to strong electromagnetic fields.
- Use shielded cables to guarantee the full specification according to HART.
- Refer to HART communication information in Chapter "Technical data (Page 185)".

5.2 Connecting the device

Opening the device


- 1. Use a 3 mm Allen key to loosen the cover (if present).
- 2. Unscrew the cover of the electrical cable compartment. An identification text "FIELD TERMINALS" is provided at the side of the housing.

Connecting the device

- 1. Lead the connecting cable through the cable gland ③.
- 2. Connect the device to the plant with the protective conductor connection ⑦.

- 3. Connect the wires to the terminals "+" and "-". ④

 Observe the correct polarity. If necessary, ground the device using the "-" connection by connecting the "-" connection to the ground terminal ⑨.
- 4. If necessary, connect the shield to the screw of the ground terminal ③. The ground terminal is electrically connected to the external protective conductor connection ⑦.



- Isolating power supply with integrated load
- 2 Auxiliary power
- 3 Cable entry for auxiliary power/analog output
- 4 Connecting terminals

- Test connector for direct current measuring device or connection for external display
- 6 Safety catch
- Protective conductor connection/ equipotential bonding terminal
- 8 Process connection
- Ground terminal

Figure 5-1 Electrical connection, power supply

Closing the device

- 1. Screw the covers ⓐ⑦ back on as far as they will go.
- 2. Secure each cover with the cover catch 36.
- 3. Close the key cover ①.

5.3 Connecting the Han plug

- 4. Tighten the screws in the key cover.
- 5. Check the tightness of the blanking plugs ⑤ and cable gland ② in accordance with the degree of protection.




Figure 5-2 View of the pressure transmitter: Left: Back right: Front view

See also

Structure (Page 21)

5.3 Connecting the Han plug



The connector may only be used for Ex ia devices and non-Ex devices; otherwise the safety required for the approval is not guaranteed.


Note

Observe the protection class of the Han plug when defining the protection class.

The contact parts for the coupling socket are also supplied.

Procedure

- 1. Slide the sleeve and the screwed joint on the cable.
- 2. Strip approx. 8 mm of the cable ends.
- 3. Crimp the contact parts on the cable ends.
- 4. Assemble the coupling socket.



IA Output currentUH Auxiliary power

Connector pin assignment with Han 7D or Han 8D plug

See also

Technical data (Page 185)

5.4 Connecting the M12 connector

Procedure



A conductive connection must not exist between the shield and the connector housing.



The connector may only be used for Ex ia devices and non-Ex devices; otherwise the safety required for the approval is not guaranteed.

Note

Observe the protection class of the M12 connector when defining the protection class.

For devices in which a connector is already available on the housing, the connection is established using a cable jack.

- 1. Thread the parts of the cable jack as described by the connector manufacturer.
- 2. Strip approximately 18 mm of the bus cable ①.

5.4 Connecting the M12 connector

- 3. Twist the shield.
- 4. Thread the shield in the insulating sleeve.
- 5. Draw 8 mm of shrink sleeve over the cable, wires and shield up to the reference edge ②.
- 6. Screw the cable ends and the shield in the pin insert.
- 7. Fix the parts of the cable jack as described by the connector manufacturer.





Figure 5-3 Preparing the connecting cable

- (1) Reference edge for stripping
- Reference edge for the dimension specifications for cable assembly
- (3) Insulating sleeve over the shield
- (4) Shrink sleeve


Pin assignment



Layout for M12 connector

- M12 x 1 thread
- 2 Positioning catch
- 1 +
- 2 Not connected
- 3
- 4 Shield





Layout for M12 jack

- Positioning slot
- 1 +
- 2 Not connected
- 3 -
- 4 Shield

Middle jack contact not connected

See also

Technical data (Page 185)

5.4 Connecting the M12 connector

Operation

6.1 Overview of operation

Introduction

The following description contains an overview of the operating functions that you can execute using the pressure transmitter, and the safety notes that are to be observed when doing so. You can operate the transmitter on-site through HART communication. First, the on-site operation and then, the operating functions using HART are described.

Contents of the chapter

- Basic safety instructions (Page 72)
- Instructions for operation (Page 72)
- Display (Page 73)
- Local operation (Page 78)

Overview of operating functions

You can configure basic settings of the pressure transmitter using the buttons on the device. You can configure all settings through HART communication.

The following table describes the basic operating functions. More operating functions for special applications are accessible through HART.

Table 6-1 Operating functions

Function	Using buttons	Using HART
Start of scale value	Yes	Yes
Full scale value	Yes	Yes
Electrical damping	Yes	Yes
Blind adjustment of the start of scale value	Yes	Yes
Blind adjustment of the full scale value	Yes	Yes
Zero point calibration (position correction)	Yes	Yes
Current simulator	Yes	Yes
Fault current	Yes	Yes
Keyboard lock and write protection	Yes	Yes, release except for write protection
Unit type, unit	Yes	Yes

6.2 Basic safety instructions

Function	Using buttons	Using HART
Characteristic curve (lin., rad.) (Not relevant for absolute or gauge pressure)	Yes	Yes
Customized characteristic curve	No	Yes
Diagnostic function	No	Yes

More operating functions for special applications are accessible through HART.

If a device does not have a display, its operations are limited. This is however not applicable for selecting functions using HART.

6.2 Basic safety instructions

Note

Incorrect reproduction of the process pressure

If you have changed the basic functions of the pressure transmitter, the display and the measurement output could be set such that the actual process pressure is not reproduced.

Therefore, check the basic parameters before commissioning.

6.3 Instructions for operation

The following rules are applicable for the operation of the pressure transmitter:

 The device counts numerical values always in an ascending order step by step starting from the least significant digit displayed.

If you keep the button pressed for a longer time, it counts the next higher digit displayed. This procedure is used for fast coarse adjustment over a wide number range. Release the $[\uparrow]$ or $[\downarrow]$ button again for fine adjustment. Press the button again.

Violations of the measured value limits are output on the display by **↑** or **Ⅰ**.

- The keyboard must have been unlocked in order to operate the device using the keyboard.
- If you are operating the pressure transmitter locally, write access through HART is denied during this time.

However, it is always possible to read the data, e.g. measured values.

Note


The setting is saved and the measured values are automatically displayed again if more than two minutes have passed after a button was pressed for the last time.

The operating instructions in the "Local operation without display" section apply if the device has been delivered with a blind cover.

6.4 Display

6.4.1 Display elements

Structure



- Measured value
- ② Unit/bar graph
- 3 Root display
- Mode/button lock

Figure 6-1 Display layout

- (5) Violation of lower limit
- 6 Symbol for measured value
- Violation of higher limit
- 8 Communication display

Description

The display is used for the local display of the measured value ① with:

- Unit ②
- Mode 4
- Sign ⑥
- Statuses (5) and (7)

Depending on the customer setting, the displayed measured value ① represents the following:

- The current emitted by the pressure transmitter
- The percentage measurement value of the adjusted measurement type, e.g. level, related to the adjusted measurement range.
- The measurement value in a selectable physical unit

The *Violation of lower limit* ⑤ and *Violation of upper limit* ⑦ displays are also referred to as status since they have meanings dependent on the settings.

If the communication display ® blinks, this indicates an active communication.

6.4.2 Units display

Description

The unit display comprises five 14-segment fields for representing the unit as a percentage value, physical unit or current value. A bar graph showing the percentage measured value range from 0 to 100% can be displayed as an alternative to the unit. The bar graph function is disabled by default.

Display





Figure 6-2 Examples for measured value display for current and bar graph

The following messages may appear as a ticker in the bottom line of the display. They have no influence on the current output.

Table 6- 2 Message as ticker

Ticker	Meaning		
"DIAGNOSTIC WARNING"	Is always displayed if:		
	An event configured by the user is to be signaled with a warning. For example:		
	 Limit reached 		
	 Event counter for limit values exceeded 		
	 Calibration time expired 		
	 Current saturation reached 		
	The status of one of the device variables is "UNCERTAIN".		
"SIMULATION"	Is always displayed when the simulation of a pressure value or temperature value is active.		

See also

Measured value status (Page 118)

6.4.3 Error display

Description

If hardware faults, software errors or diagnostic alarms occur in the pressure transmitter, the message "Error" appears in the measured value display.

A ticker appears in the bottom line of the display indicating the type of error. This diagnostic information is also available via HART communication.

Display




Figure 6-3 Example of error message

The following messages may appear as a ticker in the bottom line of the display.

Ticker	Meaning
"HARDWARE FIRMWARE ALARM"	Contains hardware faults such as:
	incorrect checksum
	incorrect EEPROM data
	Defective EEROM
	RAM fault
	ROM fault
	inconsistent data
	EEPROMs not initialized
"DIAGNOSTIC ALARM"	Is always displayed if
	an event configured by the user is to be signaled with an alarm.
	For example:
	 Limit reached
	 Event counter for limit values exceeded
	 Calibration time expired
	 Current saturation reached
	the status of one of the device variables is "BAD".
"SENSOR BREAK"	Appears when there is a sensor break.

6.4 Display

See also

Measured value status (Page 118)

6.4.4 Mode display

Description

The selected active mode is displayed in the mode display.

Display



Figure 6-4 Example of mode display

In the example, a damping of 0.2 seconds was set in mode 4.

6.4.5 Status display

Description

The arrows of the status display have a different meaning depending on the mode setting. The table below shows the meanings of the arrows in the respective functions.

Meaning

Table 6-3 Meaning of the arrow displays

Function	Mode	Display 1	Display I
Adjusting start of scale value	2	if the upper current limit is exceeded	if the value falls below the lower current limit
Adjusting full scale value	3	if the upper current limit is exceeded	if the value falls below the lower current limit
Adjusting damping	4	if the upper damping value is exceeded only for the pressure device version	if the value falls below the lower damping value only for the pressure device version

Function	Mode	Display 1	Display I
Blind adjustment of the start of scale value	5	if the upper sensor limit is exceeded	if the value falls below the lower sensor limit
Blind adjustment of the full scale value	6	if the upper sensor limit is exceeded	if the value falls below the lower sensor limit
Position correction	7	if the max span is exceeded by more than 5% of the upper current limit	if the value falls below the lower current limit
Root application point	12	if the root application point of 15% is exceeded	if the value falls below the root application point of 5%
Keyboard operation	2, 3, 5, 6	when the span to be adjusted is larger than the maximum span	when the span to be adjusted is smaller than the minimum span
Normal operation		Current exceeds the upper saturation limit Pressure exceeds the upper sensor limit.	Current falls below the lower saturation limit Pressure falls below the lower sensor limit.

6.4.6 Overflow range

Description

The output signal is divided into defined ranges:

- Measuring range
- Saturation limits
- Fault current

The pressure transmitter emits the output current according to the device variable selected as primary variable (PV). The working range of the current lies between 4 mA and 20 mA.

Meaning

When the measurement limits are exceeded or not reached, the measured values are correctly displayed in the overflow range.

A ticker is displayed in the bottom line of the display showing alternately the message UNDER or OVER and the selected unit. The possible overflow range can be adjusted via HART communication. If either of the overflow limits are violated, the output current remain constant. Violations of the measured value limits are output on the display by \uparrow or \downarrow .

Note

The setting of the overflow range and the fault current range can be freely selected via HART communication.

Reference

NAMUR recommendation NE43 dated 03.02.2003

"Standardization of the signal level for the breakdown information of digital transmitters"

See also

Fault current (Page 126)

Setting the current limits (Page 127)


6.5 Local operation

6.5.1 Local control elements

Introduction

The pressure transmitter can be operated on-site using the keys. Selectable modes can be used to choose and execute the functions described in the table. The number of available functions is limited if the device does not have a display.

Control elements



- 1 Display
- 2 Connecting plug for the display
- 3 Mode key
- Figure 6-5 Position of keys and display
- 4 Increment key
- ⑤ Decrement key
- 6 Key symbols shown in the key cover

Operating functions

Note

Zero point calibration

For absolute pressure transmitters, the start of scale value is at vacuum.

• For absolute pressure transmitters, set vacuum for zero point calibration.

Table 6- 4 Operating functions using keys

Function	Mode	Key functio	n		Display, explanations	Factory setting
	[M]	[↑]	[↓]	[↑] and [↓]		(default value)
Measured value	The mode s are se-lected here.				The current measured value is displayed as you have adjusted it in the "Measured value display, mode 13" function.	
Start of scale value (only in "Pressure" meas- uring mode)	2	Current higher	Current lower	Set to 4 mA	Output current in mA	
Full scale value (only in "Pressure" measuring mode)	3	Current higher	Current lower	Set to 20 mA	Output current in mA	
Electrical damping	4	Damping higher	Damping lower	Set to 0	Time constant T63 in seconds Adjustment range: 0.0 s to 100.0 s	2 s
Start of scale value in the so- called blind ad- justment	5	Pressure higher	Pressure lower	Set the start of scale value to 0	Start of scale value in the selected pressure unit	"0"; for ordering options Y01 and Y02 as ordered
Full scale value in the so-called blind adjustment	6	Pressure higher	Pressure lower	Set the full scale value to upper measuring limit	Full scale value in the selected pressure unit	Measuring cell full- scale value; for ordering op- tions Y01 and Y02 as ordered
Zero point calibration (position correction)	7	Correction value higher	Correction value lower	execute	Pressurize the pressure transmitter for gauge pressure, differential pressure, flow rate or level. Evacuate the pressure transmitter for absolute pressure (< 0.1% of the measuring span). (Start of scale value remains unaffected) Measured value in pressure unit	
Current transmit- ter	8	Current higher	Current lower	switch on	constant output current in mA "3.6"; "4", "12", "20" or "22.8" Switch off using the [M] key.	

Mode	Key function			Display, explanations		Factory setting
[M]	[1]	[↓]	[↑] and [↓]			(default value)
9	fault current	and up-	lower fault current			22.8 mA
10			_	0	None	"0" for devices
	five functions	3		LA	all locked	with inspection window in the
				LO	all locked except for start of scale value	cover "LS" for devices
				LS	all locked except for start of scale value and full scale value	with no inspection window in the cover
				L	Write protection Operation via HART not possible.	
11	Switch between the		linear	lin	linear	"lin" (also for or-
four funct	four functions	IS		srlin	square root extracting (linear up to the application point)	dering option Y01) "srli2" for ordering option Y02
				sroff	Square root extracting (deactivated up to the application point)	
				srli2	square root extracting (linear up to the application point 10%)	
12	Greater	Smaller	10% flow rate	Adjustment range of 5 to 15% flow rate.		not available for ordering option Y02 or character- istic curve = srli2
13	Select from to options.	hree	 Display type (input value) Output current in mA Measured value in % 		"mA" (for ordering options Y21 and Y22, unit as specified)	
14	for measured display.	d value	In each case, the first value from the table of the physical unit		"bar" (for ordering options Y21 and Y22, unit as speci- fied)	
	[M] 9 10 11 11 12	9 Switch betwee fault current per fault current per fault current five functions 10 Switch betwee five functions 11 Switch betwee four functions 12 Greater 13 Select from toptions. 14 Select from toptions.	[M] [↑] 9 Switch between lower fault current and upper fault current. 10 Switch between the five functions 11 Switch between the four functions 12 Greater Smaller 13 Select from three options. 14 Select from the table for measured value	[M] [↑] [↓] [↑] and [↓] 9 Switch between lower fault current. lower fault current. 10 Switch between the five functions - 11 Switch between the four functions linear 12 Greater Smaller 10% flow rate 13 Select from three options. - 14 Select from the table for measured value display. In each case, the first value from the table of the physical unit	[M] [↑] [↓] [↑] and [↓] 9 Switch between lower fault current. lower fault current select Fault user 10 Switch between the five functions - 0 LA LO LS LS L 11 Switch between the four functions linear lin srlin srlin srli2 srli2 12 Greater Smaller 10% flow rate Adjustrate 13 Select from three options. - • • 14 Select from the table for measured value display. In each case, the first value from the table of the physical unit Physical unit	M [1] [1] In In In In In In In I

See also

Overview of operation (Page 71)

Operating functions through HART communication (Page 107)

6.5.2 Operation using buttons

Introduction

This overview informs you about the most important safety notes to be observed when operating the pressure transmitter. Furthermore, the overview guides you in adjusting the operating functions on site.

Requirement

The keyboard must have been unlocked in order to operate the device using the buttons.

Procedure

In the default setting, the device is in the measured value display.

To adjust the operating functions, proceed as follows:

- 1. Loosen both the screws of the keyboard cover and lift it upwards.
- 2. Press the [M] button until the desired mode is displayed.
- 3. Keep pressing the $[\uparrow]$ or $[\downarrow]$ button until the desired value is displayed.
- 4. Press the [M] button.

Now you have saved the values and the device goes to the next mode.

5. Close the keyboard cover using the two screws.

Note

If you allow more than 2 minutes to pass after pressing a button, the setting is saved and the measured value display is returned to automatically.

See also

Releasing key lock or function lock (Page 98)

6.5.3 Start of scale value/full scale value

6.5.3.1 Difference between setting and adjusting

Introduction

In "Pressure" measuring mode, you can set or adjust the start of scale value and full scale value using the buttons. Modes 2 and 3 are used for this. Rising and falling characteristic curves can be realized with appropriate use of the buttons. If the pressure transmitter is not in "Pressure" measuring mode, this mode is skipped in local operation.

Difference

The difference between setting and adjusting lies in the calculation.

Setting with reference pressure

Requirement

Two reference pressures p_{r1} and p_{r2} are available. The reference pressures are initialized by the process or generated by a pressure sensor.

When setting, a desired start of scale value or a full scale value is allocated to the standard current values (4 mA or 20 mA). After setting, the span given on the nameplate may no longer correspond to the setting made.

Depending on the series and measuring range, a maximum downscaling of 1:100 can be achieved (measuring span ratio = r, turn down).

The correlation between the measured pressure and the output current generated is linear. The square root extracting characteristic curve for differential pressure transmitters is an exception. Calculate the output current using the following formula.

$$I = \frac{p - MA}{MF - MA} * 16 mA + 4 mA$$

 I
 Output current
 MA_{actual}
 Old start of scale value

 p
 Pressure
 ME_{actual}
 Old full scale value

 MA
 Start of scale value
 MA_{target}
 New start of scale value

 ME
 Full scale value
 ME_{target}
 New full scale value


Figure 6-6 Current calculation formula for setting

Example of setting with reference pressure

A Initial situation

B Setting start of scale value

C Setting full scale value



Example of setting with reference pressure

Explanations for the example of setting with reference pressure

- A The measuring range is from 0 to 1.6 MPa. You change the start-of-scale value from 0 to 0.2 MPa and the full-scale value from 1.6 MPa to 1.4 MPa. The span is then 1.2 MPa.
- B You apply a process pressure of 0.2 MPa.
 - Use the [M] button to set the pressure transmitter to mode 2. Press the $[\uparrow]$ and $[\downarrow]$ keys simultaneously for 2 seconds to set the start of scale value.
 - If the input pressure is 0.2 MPa, the pressure transmitter generates an output current of 4 mA.
- C You apply a process pressure of 1.4 MPa.
 - Use the [M] button to set the pressure transmitter to mode 3. Press the $[\uparrow]$ and $[\downarrow]$ keys simultaneously for 2 seconds to set the full scale value.
 - If the input pressure is 1.4 MPa, the pressure transmitter generates an output current of 20 mA.
- D The output current can be calculated for any input pressure using the "current calculation formula for setting".

Note

If the value exceeds or falls below the preset measuring limits by more than 20% when setting, the setting function is not carried out. The old value is retained in this case.

With a marked elevation of the zero point, the full scale value must therefore previously be reduced such that it still lies within the permitted range after elevation of the zero point. This setting function is only possible in "Pressure" measuring mode.

Adjusting with reference pressure

Requirement:

The reference pressure, the adjusted start of scale value and adjusted full scale value are known.

When adjusting, a start of scale value or a full scale value can be allocated to a desired current value with the aid of a reference pressure. This function is particularly suitable when the required pressures for the start of scale value and the full scale value are not available. After adjustment, the measuring range specified on the nameplate may no longer correspond to the setting made.

Using the formulae below, the current to be set for the desired start of scale value and the full scale value can be calculated.


To calculate the output currents when adjusting the start of scale value or the full scale value, the reference pressure must be selected such that a value between 4 and 20 mA results for the current.

$$I = \frac{p - MA}{ME - MA} * 16 mA + 4 mA$$

$$I_{ME} = \begin{array}{c} \frac{p_{ref} - MA_{target}}{ME_{target}} * 16 \text{ mA} + 4 \text{ mA} \\ \\ I & Output current & MA_{actual} & Old start of scale value \\ I_{MA} & Current to be adjusted with MA_{target} & ME_{actual} & Old full scale value \\ I_{ME} & Current to be adjusted with ME_{target} & MA_{target} & New start of scale value \\ p & Pressure & ME_{target} & New full scale value \\ p_{ref} & Existing reference pressure & Description of the property of$$

Figure 6-7 Current calculation formula for adjusting with reference pressure

Example of adjusting with reference pressure



Example of adjusting with reference pressure

Explanations for the example of adjusting with reference pressure

- A The measuring range is from 0 to 1.6 MPa. You change the start-of-scale value from 0 to 0.2 MPa and the full-scale value from 1.6 MPa to 1.4 MPa. The span is then 1.2 MPa. You apply a reference pressure of 1.1 MPa.
- B Use the [M] button to set the pressure transmitter to mode 2.

 The "Current calculation formula for adjusting with reference pressure" can be used to calculate the current to be set for the desired start-of-scale value I_{MA} (13 mA at 0.2 MPa) with the reference pressure applied. It can be adjusted with the [↑] or [↓] buttons I_{MA}.
- C Use the [M] button to set the pressure transmitter to mode 3.

 The "Current calculation formula for adjusting" can be used to calculate the current to be set for the desired full-scale value I_{ME} (16 mA at 1.4 MPa) with the reference pressure applied. It can be adjusted with the [↑] or [↓] buttons I_M.

Note

If the preset measuring limits are exceeded or fallen below by more than 20% during adjustment, the resulting current cannot be set above these limits.

With a marked elevation of the zero point, the full scale value must therefore previously be reduced such that it still lies within the permitted range after elevation of the zero point.

See also

Unit (Page 102)

6.5.3.2 Setting/adjusting the start of scale value

NOTICE

Inadvertent adjustment of parameters on devices without display or without visible display

Key lock is canceled if you press the [M] key for longer than 5 seconds, see chapter "Releasing key lock or function lock (Page 98)". In the case of a device without display or without a visible display, you could inadvertently change parameters.

· Always press the [M] key for less than 5 seconds.

Introduction

Set or adjust the start of scale value of the pressure transmitter in mode 2.

You can also adjust the start of scale value or the full scale value separately as well as adjust both these values one after the other.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

You have selected a reference pressure that corresponds to the start of scale value and is within the permissible tolerance range.

The pressure transmitter is in "Pressure" measuring mode.

Setting start of scale value

To set the output current of the start of scale value to 4 mA, proceed as follows:

- 1. Create the reference pressure.
- 2. Set mode 2.

- 3. Set the start of scale value to 4 mA.
- 4. Save with the [M] button.

Adjusting start of scale value

If you do not set the output current but constantly adjust it, you need to calculate the currents to be adjusted mathematically.

To the adjust the output current of the start of scale value, proceed as follows:

- 1. Create the reference pressure.
- 2. Set mode 2.
- 3. Adjust the output current of the start of scale value to the calculated value.
- 4. Save with the [M] button.

Setting the start-of-scale value without a display

You have a device without a display and wish to set the start of scale value.

To set the output current of the start of scale value to 4 mA, proceed as follows:

- 1. Create the reference pressure.
- 2. Press the [↑] and [↓] buttons simultaneously.

The device has set the start of scale value to 4 mA.

3. When you release the buttons, the device saves the adjusted value automatically.

Adjusting the start-of-scale value without a display

You have a device without a display and wish to adjust rather than set the start of scale value.

You will need an ammeter for this purpose.

To the adjust the output current of the start of scale value, proceed as follows:

- 1. Connect the ammeter to the test connector.
- 2. Create the reference pressure.
- 3. Adjust the output current of the start of scale value using the [↑] or [↓] button.
- 4. When you release the button, the device saves the adjusted value automatically.

6.5.3.3 Setting/adjusting the full scale value

Introduction

Set or adjust the full scale value of the pressure transmitter in mode 3.

You can also adjust the start of scale value or the full scale value separately as well as adjust both these values one after the other.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

You have selected a reference pressure that corresponds to the full scale value and is within the permissible tolerance range.

The pressure transmitter is in "Pressure" measuring mode.

Setting full scale value

To set the output current of the full scale value to 20 mA, proceed as follows:

- 1. Create the reference pressure.
- 2. Set mode 3.
- 3. Set the full scale value to 20 mA.
- 4. Save with the [M] button.

Adjusting full scale value

If you do not set the output current but constantly adjust it, you need to calculate the currents to be adjusted mathematically.

To the adjust the output current of the full scale value, proceed as follows:

- 1. Create the reference pressure.
- 2. Set mode 3.
- 3. Adjust the output current of the full scale value to the calculated value.
- 4. Save with the [M] button.

Setting the full-scale value without a display

You have a device without a display and wish to set the full scale value.

To set the output current of the full scale value to 20 mA, proceed as follows:

- 1. Create the reference pressure.
- 2. Press and hold the [M] button.
- 3. Also press the [↑] and [↓] buttons simultaneously.

The device has set the full scale value to 20 mA.

4. When you release the buttons, the device saves the adjusted value automatically.

Adjusting the full-scale value without a display

You have a device without a display and wish to adjust rather than set the full scale value.

You will need an ammeter for this purpose.

To the adjust the output current of the full scale value, proceed as follows:

- 1. Connect the ammeter to the test connector.
- 2. Create the reference pressure.
- 3. Press and hold the [M] button.
- Adjust the output current of the full scale value to the calculated value using the [↑] or [↓] button.
- 5. When you release the button, the device saves the adjusted value automatically.

6.5.4 Setting/adjusting electrical damping

Difference between setting and adjusting

You can set or adjust the time constant of electrical damping using the buttons. Setting means that the time constant is automatically set to 0 seconds. Adjusting means that the time constant is adjusted between 0 and 100 seconds using the increments of 0.1 seconds. This electrical damping also has an effect on the built-in basic damping of the device.

Condition for "setting"

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

Setting electrical damping

To set electrical damping to 0 seconds, proceed as follows:

- 1. Set mode 4.
- 2. Press the [↑] and [↓] buttons simultaneously.
- 3. Save with the [M] button.

Result

Electrical damping has been set to 0 seconds.

Condition for "adjusting"

The default adjusting of steps is an interval of 0.1 seconds. If you press the $[\uparrow]$ or $[\downarrow]$ button for a long time, the steps are increased.

Adjusting electrical damping

To adjust electrical damping, proceed as follows:

- 1. Set mode 4.
- 2. Adjust the desired damping.
- 3. Save with the [M] button.

Result

Electrical damping has been set to the desired time constant.

6.5.5 Blind start of scale value/full scale value

6.5.5.1 Difference between setting/adjusting and blind setting/adjusting

Differences

In contrast to setting/adjusting with a reference pressure, you do not need a reference pressure for blind setting/adjusting. You can adjust a value in the physical variable "pressure" without a reference pressure, and an output current with a reference pressure.


Blind adjusting

First select the desired physical unit. Then, adjust two pressure values using the $[\uparrow]$ and $[\downarrow]$ buttons and save them in the device. These theoretical pressure values are allocated to the standard current values 4 mA and 20 mA.

Depending on the series and measuring range, a maximum downscaling of 1:100 can be achieved (measuring span ratio = r, turn down).

The correlation between the measured pressure and the output current generated is linear. The square root extracting characteristic curve for differential pressure transmitters is an exception.

Example of blind adjusting



 $\begin{array}{lll} I & \text{Output current} & p & \text{Pressure} \\ \text{MA}_{\text{actual}} \text{ Old start of scale value} & \text{MA}_{\text{target}} & \text{New start of scale value} \\ \text{ME}_{\text{actual}} \text{ Old full scale value} & \text{ME}_{\text{target}} & \text{New full scale value} \\ \end{array}$

Explanations for the blind adjusting example

- A The measuring range is from 0 to 16 bar. You are changing the start of scale value from 0 to 2 bar and the full scale value from 16 to 14 bar. The measuring span is then 12 bar. In this example you create no pressure.
- B Use the [M] button to set the pressure transmitter to mode 5. To adjust the start of scale value to 2 bar, press one of the [↑] or [↓] buttons until 2 bar appears in the display. If there is 2 bar input pressure, the pressure transmitter produces an output current of 4 mA.
- C Use the [M] button to set the pressure transmitter to mode 6. To adjust the full scale value to 14 bar, press one of the [↑] or [↓] buttons until 14 bar appears in the display. If the input pressure is 14 bar, the pressure transmitter generates an output current of 20 mA.

Note

If the preset measuring limits are exceeded or fallen below by more than 20% during adjustment, the resulting current cannot be set above these limits.

With a marked elevation of the zero point, the full scale value must therefore previously be reduced such that it still lies within the permitted range after elevation of the zero point.

Setting without reference pressure

Blind setting resets the start of scale value to the low sensor limit and the full scale value to the high sensor limit.

Note

If the value exceeds or falls below the preset measuring limits by more than 20% when setting, the setting function is not carried out. The old value is retained in this case.

With a marked elevation of the zero point, the full scale value must therefore previously be reduced such that it still lies within the permitted range after elevation of the zero point.

6.5.5.2 Blind setting of start of scale value

Introduction

Blind setting resets the start of scale value to the low sensor limit.

Note

Changes in modes 5 and 6 only affect the pressure scaling. This does not affect the scaling for level or customized characteristic curve. Therefore, only measured pressure values and pressure units are displayed in these modes.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

You have not created any reference pressure and have selected a pressure unit.

Procedure

To set the start of scale value blindly, proceed as follows:

- 1. Set mode 5.
- 2. Press the [↑] and [↓] keys simultaneously for 2 seconds.

6.5.5.3 Blind setting of full scale value

Introduction

Blind setting resets the full scale value to the high sensor limit.

Note

Changes in modes 5 and 6 only affect the pressure scaling. This does not affect the scaling for level or customized characteristic curve. Therefore, only measured pressure values and pressure units are displayed in these modes.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

You have not created any reference pressure and have selected a pressure unit.

Procedure

To set the full scale value blindly, proceed as follows:

- 1. Set mode 6.
- 2. Press the [↑] and [↓] keys simultaneously for 2 seconds.

6.5.5.4 Blind adjusting of the start of scale value

Introduction

In the case of blind adjustment, you adjust the pressure value of the start of scale value continuously and without a reference pressure.

Note

Changes in modes 5 and 6 only affect the pressure scaling. This does not affect the scaling for level or customized characteristic curve. Therefore, only measured pressure values and pressure units are displayed in these modes.

You can toggle between rising and falling characteristic curves.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

You have not created any reference pressure and have selected a pressure unit.

Procedure

To adjust the pressure value of the start of scale value blindly, proceed as follows:

- 1. Set mode 5.
- 2. Adjust the pressure value of the start of scale value.
- 3. Save with the [M] button.

6.5.5.5 Blind adjustment of the full scale value

Introduction

In the case of blind adjustment, you adjust the pressure value of the full scale value continuously and without a reference pressure.

Note

Changes in modes 5 and 6 only affect the pressure scaling. This does not affect the scaling for level or customized characteristic curve. Therefore, only measured pressure values and pressure units are displayed in these modes.

You can toggle between rising and falling characteristic curves by swapping the start of scale value and the full scale value.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

You have not created any reference pressure and have selected a pressure unit.

Procedure

To adjust the pressure value of the full scale value blindly, proceed as follows:

- 1. Set mode 6.
- 2. Adjust the pressure value of the full scale value.
- 3. Save with the [M] button.

6.5.6 Trimming the zero point

Introduction

The zero point is calibrated in mode 7. Zero point calibration corrects zero point errors resulting from the installation position of the pressure transmitter. The device type determines the way in which you proceed.

SIMATIC PDM or the HART communicator will display the total of all zero point corrections.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

Zero point calibration for gauge pressure transmitter

To calibrate the zero point, proceed as follows:

- 1. Pressurize the pressure transmitter.
- 2. Set mode 7.
- 3. Press the $[\uparrow]$ and $[\downarrow]$ keys simultaneously for 2 seconds.
- 4. Save using the [M] key.

Zero point calibration for absolute pressure transmitter

Note

You need a reference pressure known to you which lies within the measuring limits.

To calibrate the zero point, proceed as follows:

- 1. Create the reference pressure.
- 2. Set mode 7.
- 3. Set the reference pressure on the display.
- 4. Save using the [M] key.

6.5.7 Current simulator

Introduction

In mode 8, switch the pressure transmitter into the constant current operation. You can connect an external current simulator in the constant current operation. The current then no longer corresponds to the process variable. The following output current can be adjusted irrespective of the input pressure:

- 3.6 mA
- 4.0 mA
- 12.0 mA
- 20.0 mA
- 22.8 mA

You can use HART communication to adjust intermediate values.

Procedure

To switch on the constant current operation, proceed as follows:

- 1. Set mode 8.
 - "Cur" in the display stands for current.
- 2. Press the [↑] and [↓] buttons simultaneously.
- 3. Select constant current.

Switching off the constant current operation

To switch off the constant current operation, proceed as follows:

Press the [M] button in mode 8.

6.5.8 Output current in case of fault

Introduction

When a fault occurs, the upper fault current is displayed in the basic setting. In mode 9, you can choose between the output of the upper and lower fault current. The standard values 3.6 mA and 22.8 mA are set.

The standard values of the upper and lower fault current can be changed via HART communication.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

Procedure

To change the fault current, proceed as follows:

- 1. Set mode 9.
- 2. Select the fault current.
- 3. Save using the [M] key.

Note

If a current saturation interrupt is active, the setting of the output current may deviate from your setting in the case of a fault.

Resetting fault current

To reset the fault current to the basic setting, proceed as follows:

Press the $[\uparrow]$ and $[\downarrow]$ [M] keys simultaneously.

Fault causes

Fault currents may be triggered by:

- FW alarm
- HW alarm
- Diagnostic interrupt
- Sensor breakage
- Measured value status BAD

Reference

NAMUR recommendation NE43 dated 02/03/2003

"Standardization of the signal level for the breakdown information of digital pressure transmitters"

6.5.9 Locking buttons and functions

Introduction

In mode 10, you can disable the functions that can be executed using buttons. Application example for a lock is e.g. safeguarding the saved parameters.

Lock options

You have the following lock options on the pressure transmitter:

Table 6-5 Meaning of lock modes in mode 10

Lock mode	Meaning
0	The device can be operated by means of the keys and HART communication.
LA	Keys on the pressure transmitter are locked.
	Exception:
	Releasing key lock
	The device can be operated by means of HART communication.
LO	Keys on the pressure transmitter are partially locked.
	Exception:
	Setting start of scale value
	Releasing key lock
	The device can be operated by means of HART communication.

Lock mode	Meaning				
LS	Keys on the pressure transmitter are partially locked.				
	Exception:				
	Setting start of scale value				
	Setting full scale value				
	Releasing key lock				
	The device can be operated by means of HART communication.				
L	Write protection				
	Operation via keys and HART communication is blocked.				
	Exception:				
	Releasing key lock				

Note

If you want to select the LO or LS lock, we recommend you first select the measured value display of "Current" in "mA" or "%" in mode 13. Otherwise, a change in the output variable using the $[\uparrow]$ and $[\downarrow]$ buttons is not detected.

If the blind cover is provided, the LS lock mode is effective, i.e. only the zero point and the span can be changed. If you continuously operate the device with the blind cover, ensure that the LS lock mode is constantly set.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

Note

In the measured value display function, check whether the desired setting is displayed.

Procedure

To disable the buttons, proceed as follows:

- 1. Set mode 10.
- 2. Select the desired lock mode.
- 3. Confirm the lock mode with the [M] button.

6.5.10 Releasing key lock or function lock

Requirement

You own a device with installed display.

Releasing key lock



Releasing key lock

Make sure that only authorized personnel may cancel the key locking of devices for safety-related applications.

To release a set key lock (LA, LO, LS) using buttons, proceed as follows:

Press the [M] button for 5 seconds.

Removing write protection

To release write protection for HART (L) using buttons, proceed as follows:

Press the [M] button for 5 seconds.

6.5.11 Flow rate measurement (only differential pressure)

Introduction

The characteristic curve representing the relationship between the output current and input pressure can be adjusted in mode 11. Adjust the root application point in mode 12.

You can select the following characteristic curve types of the output current in mode 11:

- linear "lin": proportional to differential pressure
- square root extracting "sroff": proportional to flow rate, deactivated up to the application point
- square root extracting "srlin": proportional to flow rate, linear up to the application point
- square root extracting "srli2": proportional to flow rate, two-step linear up to the application point

Variable application point

The output current for the "srlin" and "sroff" functions can be displayed linearly or set to zero below the application point of the square root extracting characteristic curve.

Fixed application point

The "srli2" function has a permanently defined application point of 10%. The range up to this point contains two linear characteristic curve sections. The first section ranges from the zero point to 0.6% of the output value and 0.6% of the pressure value. The second section has a higher gradient and it goes up to the root application point at 10% of the output value and 1% of the pressure value. See the following figure for this purpose.

Procedure

Proceed as follows to set or adjust the type of characteristic curve:

- 1. Set mode 11.
- 2. Select the type of characteristic curve.

To set the characteristic curve to "linear", press the [↑] and [↓] buttons simultaneously.

3. Save with the [M] button.

Proceed as follows to set or adjust the root application point: This procedure is not applicable for "srli2":

- 1. Set mode 12.
- 2. Select an application point between 5 and 15%.

To set the application point to 10%, press the [\uparrow] and [\downarrow] buttons simultaneously.


3. Save with the [M] button.

Note

Mode 12 cannot be selected if the "linear" or "srli2" measuring mode has been adjusted in mode 11.


If the square root extracting characteristic curve has been adjusted in mode 11 and if the measured value display has been set to "Pressure" in mode 13, the root sign and the differential pressure corresponding to the flow rate are displayed.

The root extraction function "srli2" is set in "flow rate" measuring mode. You therefore set the "characteristic curve" parameter in SIMATIC PDM to "linear".




The dotted rectangle has been magnified in the form of the following characteristic curves in order to show the behavior of characteristic curves.


Characteristic curves and application point of square root extracting characteristic curves




Characteristic curve "lin":



Characteristic curve "sroff"



Square root extracting characteristic curve "srlin"



Characteristic curve "srli2"

6.5.12 Measured value display

Note

To use the operating functions with the buttons, first set the device variable (DV) parameters with a host system such as SIMATIC PDM. You will finds details of the relation between primary variable (PV) assignment and the DV in the following section:

Measuring mode "Pressure" (Page 110)

Introduction

In mode 13, adjust the following types of measured value display:

- mA
- %
- Display of the PV selected via HART. (Default setting: P pressure)

Table 6- 6 Display of measuring mode/device variables

Display	DV	Meaning
Р	0	Pressure
t-SE	1	Sensor temperature
t-EL	2	Electronics temperature
P-UNC	3	Pressure (untrimmed)
LEVEL	4	Level
Vol	5	Volume
MASS	6	Mass
V-Flo	7	Volumetric flow rate (not relevant for gauge or absolute pressure)
M-Flo	8	Mass flow rate (not relevant for gauge or absolute pressure)
CUSt	9	Users

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

Procedure

To select the display type, proceed as follows:

- 1. Set mode 13.
- 2. Select the measured value display.
- 3. Save with the [M] button.

See also

Measured value display (Page 129)

6.5.13 Unit

Introduction

In mode 14, select the physical unit in which the measured value display of the device should be shown.

Requirement

You are familiar with the correct operation of the pressure transmitter and the associated safety information.

You have already selected the desired measured value display via HART.

Procedure

To adjust the physical unit, proceed as follows:

- 1. Set mode 14.
- 2. Select a unit.

Press the $[\uparrow]$ and $[\downarrow]$ buttons simultaneously to set the unit to the first value in the following table depending on the measuring mode set.

3. Save with the [M] button.

Instructions for selecting the unit

- Unit selection depends on the type of measurement set. For example, only pressure units
 are available in "Pressure" measuring mode and only level units are available in the
 "Level" measuring mode.
- The displayed measured value is always converted into the new unit. "9.9.9.9.9" appears on the display when its display capacity is exceeded.
- The selected unit is visible on the display in the measuring mode only if you have selected the display of a physical unit via HART. "mA" or "%" will be displayed if you have not selected mode 13, "Measuring mode".

Units

Table 6-7 Units available for pressure

Pressure units	Display	Pressure units	Display
bar	bar	Psi	PSi
mbar	mbar	Pa	Pa
mm water column (20°C / 68°F)	mmH2O	KPa²	KPa
Inch water column (20°C / 68°F)	inH2O	MPa	MPa
Feet water column (20°C / 68°F)	FTH2O	g/cm2	Gcm2
mm mercury column	mmHG	Kg/cm2	KGcm2
Inch mercury column	in_HG	Torr	TORR
mm water column (4°C / 39 °F)	m4H2O	ATM	ATM
Inch water column (4°C / 39°F)	i4H2O		

Table 6-8 Units available for level

Level unit	Display	Level unit	Display
Feet	FT	cm	cm
Inch	inch	mm	mm
М	m		·

Table 6-9 Units available for mass

Mass unit	Display	Mass unit	Display
Gram	G	Long ton	ITon
Kilogram	KG	Pound	lb
Ton	Т	Ounce	OZ
Short ton	STon		

Table 6- 10 Units available for mass flow rate

Mass flow rate unit	Display	Mass flow rate unit	Display
g/s	G/S	Pound / s	P/S
g / min	G/m	Pound / min	lb/m
g / h	G/h	Pound / h	lb/h
Kg/s	KG/S	Pound / d	lb/d
Kg / min	KG/m	Short ton / min	ShT/m
Kg / h	KG/h	Short ton / h	ShT/h
Kg / d	KG/d	Short ton / d	ShT/d
T / min	T/m	Long ton / h	IT/h
T / h	T/h	Long ton / d	IT/d
T / d	T/d		·

Table 6- 11 Units available for temperature

Temperature unit	Display	Temperature unit	Display
° Celsius	°/C	Kelvin	Κ
° Fahrenheit	°/F	Rankine	R

Table 6- 12 Units available for volume

Volume unit	Display	Volume unit	Display
M3	m3	Buschels	buShl
Liter	L	yard3	Yd3
Hectoliter	HL	Feet3	FT3
US gallon	Gal	inch3	in3
British gallons	in Gal	Standard I	STdL
British barrel	bbl	Standard m3	STdm3
British barrel liquid	bblli	Standard feet3	STFT3

Table 6- 13 Units available for volumetric flow

Unit of volumetric flow	Display	Unit of volumetric flow	Display
m3 / second	m3/S	Gallons / hour	Gal/h
m3 / minute	m3/m	Gallons / day	Gal/d
m3 / hour	m3/H	Million gallon / day	MGI/D
m3 / day	m3/d	British gallons / second	iGI/S
Liters/second	L/S	British gallons / minute	iGI/m
Liters/minute	L/m	British gallons / hour	iGl/h
Liters/hour	L/h	British Gallons / day	iGL/d
Million liter / day	mL/d	Standard m3 / hour	Sm3/h
Feet3 / second	FT3/S	Standard I / hour	STL/h
Feet3 / minute	FT3/m	Standard feet3 / minute	SFT3m
Feet3 / hour	FT3/h	British barrel liquid / second	bbl/S
Feet3 / day	FT3/d	British barrel liquid / minute	bbl/m
Gallons / second	Gal/S	British barrel liquid / hour	bbl/h
Gallons / minute	Gal/m	British barrel liquid / day	bbl/d

See also

Selection of the physical unit (Page 130)

Operating functions through HART

7.1 Operating functions through HART communication

Requirement

You can operate the pressure transmitter through HART communication. The following is required for this purpose:

- A HART communicator or PC software such as SIMATIC PDM.
- A HART modem to connect a PC with the pressure transmitter or a lead to connect a HART communicator with the pressure transmitter.

Introduction

The full functionality of the pressure transmitter is available via HART communication. The HART communicator and PC software are not supplied with the pressure transmitter. The procedure for connecting and operating a HART communicator or PC software is described in separate instructions or in the online help for both these tools.

Fundamental description

The input signal is provided in the form of digital information in the following variables through HART communication:

- Pressure
- Level
- Volume
- Mass
- Volumetric flow
- Mass flow rate
- User programmable "characteristic curve"

As soon as you have set up the HART communication and the pressure transmitter, you can adapt the pressure transmitter to your respective measuring task. When doing so you are assisted by the selectable measuring modes "Pressure", "Level", "Flow rate" and a user programmable "Characteristic curve". One or more device variables are permanently allocated to each measuring mode in order to execute corresponding measuring tasks.

See also

Overview of operation (Page 71)

7.2 Process tag data

You can store your process tag data in user definable fields. The following table contains information about the structure of these fields and the format in which you can enter information in these fields:

Table 7-1 Process tag data

Field	Explanations
Tag designation	Eight characters
Date	Day:Month:Year
Description	16 characters
Message	32 characters
Works number	Integer number
Tag designation long	32 characters
Freely definable material parameter	21 x 16 characters

7.3 Selecting the measuring modes

7.3.1 Overview of measuring modes

Overview

The pressure transmitter can be adjusted for the corresponding measuring task using a few parameters. You can select the following measuring modes:

- Pressure
- Level
- Flow rate
- Users: user programmable characteristic curve

You can use the measuring mode selector to activate measuring modes "Level", "Flow rate" and "User".

Selecting the device variables

One or more device variables are permanently allocated to each measuring mode. The following device variables are always active and are therefore always displayed:

- Pressure
- Sensor temperature
- Electronics temperature
- Pressure (untrimmed)

The following device variables are activated only when the allocated measuring mode is activated and parameterized simultaneously:

- "Level", "Volume" and "Mass" are allocated to the "Level" measuring mode.
- "Volumetric flow" and "Mass flow rate" are classified as "Flow rate" measuring mode.
- "User" is allocated to the "User" measuring mode.

The inactive device variables have the CONSTANT status.

7.3.2 Measuring mode selector

You can use this switch to toggle between measuring modes "Pressure", "Level", "Flow rate" and a characteristic curve programmable by a "User".

If a measuring mode has been selected using the measuring mode selector, it has to be configured. This does not mean that this block has an automatic effect on the current output (4 to 20 mA). For that, you need to switch the corresponding device variable to the primary variable (PV) using a so-called variable mapper.

7.3.3 Variable mapper

Introduction

In this pressure transmitter, the dynamic variable that determines the behavior of current output is always called the primary variable (PV). You need to use the variable mapper for a number of purposes, including selecting which device variable is to be switched to PV. The variable selected as PV using a PC program such as SIMATIC PDM or using the HART Communicator is scaled once again in the analog output stage to a start of scale value and a full scale value. These two values then correspond to the current values 4 and 20 mA.

As soon as the PV is switched over using the variable mapper, the start of scale value and full scale value in the analog output stage are preset to the limit values of the new device variables. You can define these limit values within the individual block functions.

The dynamic variables "Primary", "Secondary", "Tertiary" and "Quarternary" (PV, SV, TV, QV) can be interconnected with any active device variables. Various measuring mode examples are conceivable with a 4 bar pressure transmitter.


See also

Measured value status (Page 118)

7.3.4 Measuring mode "Pressure"

The "Pressure" measuring mode contains the "Sensor trim" function, and is always active since it is the standard measuring mode. When the measuring mode selector is set to "Off", no other measuring variables are derived from the "Pressure" measured variable. Except the first four variables, all other device variables are marked as inactive and have the CONSTANT status. These four variables are mapped with dynamic variables PV, SV, TV and QV by default.

Switching an inactive device variable to the primary variable (PV) generates an error message since the variable currently does not have a valid measured value. This message is displayed in SIMATIC PDM or the HART communicator.



DV Device variable

MA Start of scale value

ME Full scale value

PV Primary variable

QV Quarternary variable

SV Secondary variable

TV Tertiary variable

Figure 7-1 Measuring mode "Pressure"

7.3.5 Customized characteristic curve

Introduction

The customized "characteristic curve" is continuously active as an identical function in the three following measuring modes "Level", "Flow rate" and "User". This means that the customized "characteristic curve" always provides a result for the following function, thus also influencing the measured value status of the affected device variables.

In the device, the characteristic curve vertices are only provided once in the EEPROM. Therefore, if the measuring mode is changed, you will usually need to adjust the characteristic curve accordingly.

The characteristic curve function expects at least two and at the most 30 characteristic curve vertices as input parameters. Characteristic curve vertices are entered in pairs of values x %;y %. The values for the x-coordinate are only accepted by the device when they run monotonically. The y-coordinates, on the other hand, may also be non-monotonic. A warning will however be issued by the configuring device, which you as the user have to recognize and acknowledge. The output of the characteristic curve is not explicitly stored in a device variable, but rather is directly interconnected with the input of the next function block in each case. The pairs of values 0%;0% and 100%;100% are set as default values. In principle, rising and falling characteristic curves can be configured. With regard to the device variable status, rising characteristic curves are however preferred. Otherwise the meanings of HIGH LIMIT and LOW LIMIT are swapped.

See also

Measured value status (Page 118)

7.3.6 Measuring mode "Level"

Description

Once you have configured the measuring mode "Level", the device variables "Level", "Volume" and "Mass" are activated. They are all derived from the measured pressure. The "Level" block here represents a series of permanently interconnected functions which you need to configure with appropriate parameters. Only then will you obtain a meaningful measured value for the three device variables.

7.3 Selecting the measuring modes




Figure 7-2 Measuring mode "Level"

DV Device variable

MA Start of scale value

ME Full scale value

Functions of the "Level" block

The first function, "Input scaling, pressure", sets the pressure range used by the following functions in all three blocks in the same way. Ideally, this range corresponds to the sensor limits of the pressure transmitter. In the following calculation examples, 0 and 4 bar are assumed for these sensor limits for all blocks. You can also adjust down-scaling, e.g. 1:2. This down-scaling of 1:2 means that 50% of the nominal measuring range, i.e. in this case 2 bar, controls 100% of the following characteristic.

Use the "Output scaling, level" to set the measuring limits for the measuring mode "Level" with a unit from the level range. Parameter assignment in this example is 10 and 20 m. At 0 bar process pressure, 10 m is displayed in DV4 and 20 m is displayed at 2 bar. The values for the start of scale value and the full scale value, which are effective for the analog output, are configured in the "analog output" block.

In the calculation example, the two pairs of values 0%;0% and 100%;100% are configured for the customized "characteristic curve". This is the default setting. The measured value in this example is passed on from the pressure scaling 1:1.




Figure 7-3 Functions of the "Level" block

DV [x] Device variable x

L Level

m Mass

MA Start of scale value

ME Full scale value

P Pressure

V Volume

Configure the "Output scaling, volume" with a unit from the volume range and the measuring limits for the device variable "Volume". The characteristic curve output directly affects the volume scaling input.

In the calculation example, for the measuring limits from 0 and 100 l, a volume of 50 l is yielded for process pressure of 1 bar.

The "Level" parameter setting also still automatically activates the device variable for the mass. If you have not yet configured a value for the density, the initial value of 1 kg/l is preset. In the calculation example for the "Mass" device variable, a mass of 250 kg is derived at a density of 5 kg/l.

Note


When the density changes, the measuring range limits have to be adjusted accordingly.

You can configure all parameter settings for the "Level" block in SIMATIC PDM or the HART communicator. Activate the "Level" measuring mode for this purpose. For all adjustments, the measuring limits may be exceeded by +/-20%. Values which lie above or below this are rejected by the device.

7.3.7 Measuring mode "Flow rate"

Description

When you activate the "Flow rate" measuring mode, only two other device variables are active: volumetric flow and mass flow rate. If another block was active earlier, the corresponding device variables remain inactive and have the "CONSTANT" status. The "Flow rate" block here represents a series of permanently interconnected functions which you need to configure with appropriate parameters.



DV Device variable

MA Start of scale value

ME Full scale value

Figure 7-4 Measuring mode "Flow rate"

Functions of the "Flow rate" block


The "Input scaling, pressure" function defines the pressure range of 0 to 2 bar that is interpreted as 0 and 100% by the following square root extracting function. A process pressure of 0.5 bar has been assumed in the following figure.

In the "Flow rate" measuring mode, a square root extracting characteristic curve "srlin2" is plotted with a fixed root application point of 10%.

In the calculation example, the input value for the "root extraction function" is approx. 25 % for a prevailing process pressure of 0.5 bar. The output value is approximately 50%.

Note

When using the "Flow rate" block, other square root extracting characteristic curves must be deactivated if required. (The "characteristic curve" parameter must be "linear", as root extraction is already implemented in "flow rate" measuring mode).



VF

Figure 7-5 Functions of the "Flow rate" block

Start of scale value

Full scale value

MA

ME

In the calculation example, the two pairs of values 0%;0% and 100%;100% are configured for the customized "characteristic curve". This setting corresponds to a bisection of the input value for all output values.

Pressure

Volumetric flow

Configure the output scaling "volumetric flow" with a unit from the volume flow range and the measuring limits for the device variable "Volumetric flow". In the calculation example, 0 l/s and 1000 l/s are defined as lower and upper measuring limits. The volumetric flow rate is 500 l/s at a prevailing process pressure of 0.5 bar.

The "Mass flow rate" device variable is automatically activated when the "Flow rate" block is configured. If you have not yet configured a value for the density, the initial value of 1 kg/l is preset.

In the calculation example, a mass of 2000 kg/s is derived for the "mass flow rate" device variable at a value of 1 kg/l. The density value entered is only used to calculate the mass flow rate. The entered value of density has no effect on the diaphragm calculation that is to be carried out by the user.

In SIMATIC PDM or the HART communicator, the "Flow rate" block is configured in an online dialog box in an extremely compact manner. In this online dialog box, you can compile all values in a menu and transfer them to the device collectively.

7.3.8 Measuring mode "User"

Description

The "User" measuring mode is the simplest of the measuring modes that you can select with the measuring mode selector. Only one further device variable, "User", is activated in this measuring mode in addition to the four standard device variables. The variables "Level", "Volume", "Mass", "Volumetric flow" and "Mass flow rate" are marked as inactive and are given the status CONSTANT.

In the "User" measuring mode, you have an option to define a customized unit for output scaling. This customized unit is, e.g. a specific quantity of liquid. This quantity of liquid depends on the input process pressure.

Example: Fill the beverages in cans having a capacity of 0.33 I. You can now define a customized unit "Can" that is exactly equal to 0.33 I. The quantity of "cans" depends on the input process pressure.

Note

Permissible input values

All alphabetic a...z, A...Z and numeric 0...9 inputs are allowed for the customized unit. The following characters are also allowed:




Figure 7-6 Measuring mode "User"

Functions of the "User" block

The first function, "Input scaling, pressure", defines the pressure range which is used by the customized characteristic curve. Ideally, this range corresponds to the sensor limits. In the calculation example, 0 and 2 bar are assumed. This means that with process pressure of 0.5 bar, there is a value of 25% on the characteristic curve.




Figure 7-7 Functions of the "User" block

In the calculation example, the two pairs of values 0%;0% and 100%;100% are configured for the customized "characteristic curve". Any curve shapes can be calculated with the help

7.3 Selecting the measuring modes

of 30 characteristic curve vertices. These curve shapes can be stored in the device using SIMATIC PDM or the HART communicator.

In the calculation example, the value at the input of the characteristic curve is transferred 1:1 to the output.

In the calculation example, a number of filled cans is set for the output scaling. You can enter up to five characters for any given unit. Do not confuse this with the user-programmable display unit of the "Analog output" block.

In the calculation example, you have a start of scale value of 0 cans and a full scale value of 1000 cans. At a process pressure of 0.5 bar, you get a value of 250 cans for the "User" device variable.

See also

Analog output (Page 122)

Measured value status (Page 118)

7.3.9 Measured value status

Introduction

Every device variable is assigned a status byte to indicate the quality of the measured values. This status byte can have the following values:

- BAD
- GOOD
- MANUAL
- UNCERTAIN

The following values are also possible:

- CONSTANT
- HIGH LIMIT
- LOW LIMIT

A higher-level diagnosis program can display and analyze these states.

GOOD status

During smooth, uninterrupted operation, the measured value status of all active device variables is GOOD.

BAD/CONSTANT status

All inactive device variables have CONSTANT/BAD status.

If a variable having the BAD status is an output value for calculation, the measured value is BAD.

The basic measured values, namely pressure and temperatures, have the BAD status in the following cases:

- The analog-to-digital converter does not function.
- Linearization values in the EEPROM are defective.
- If the two end points of the customized characteristic curve are exceeded for the status of the device variables of the following function.

UNCERTAIN status

If a pressure value exceeds or falls below the sensor limits of the device by more than 20%, the corresponding measured value and the variables inferred from it are UNCERTAIN.

If the analog-to-digital converter for pressure control is over/underrange, the status is UNCERTAIN.

HIGH LIMIT and LOW LIMIT

If the analog-to-digital converter is overrange, the HIGH LIMIT label is allocated. If the analog-to-digital converter is underrange, the LOW LIMIT label is allocated.

Change in status

If the status of a device variable changes and it was right at the front of the sequence of operations for a block, e.g. pressure, then all variables that are derived from it will take on the same status. In the following example, the device variable "Pressure" has the BAD status. Since the measuring mode selector is set to "USER", the device variable "User" is also given the BAD status.

The reasons for changes in the status of a device variable are summarized in the table. If there were several reasons for a change in status, MANUAL always has the highest priority. BAD has the second highest and UNCERTAIN the third highest priority.

7.3 Selecting the measuring modes




Figure 7-8 Device status dependency

Table 7-2 Events which result in a change of status

DV	Measuring mode	BAD	MANUAL	UNCERTAIN	CONSTANT	HIGH LIMIT	LOW LIMIT
0	Pressure	DV3 = BAD, fault in lineari- zation	When DV0 is simulated	DV3 = UNCERTAIN	-	DV3 = HIGH LIMIT	DV3 = LOW LIMIT
1	Sensor temperature	DV2 = BAD, analog-to- digital converter in over/underrang e, fault in line- arization	When DV1 is simulated	DV1 more than 20% outside the sensor limits DV2 = UNCERTAIN DV2 = MANUAL	-	Analog-to- digital convert- er in overrange	Analog-to- digital convert- er in under- range
2	Electronics temperature	Analog-to- digital converter in over/underrang e, fault in line- arization	When DV2 is simulated	DV2 more than 20% outside the sensor limits	-	Analog-to- digital convert- er in overrange	Analog-to- digital convert- er in under- range

DV	Measuring mode	BAD	MANUAL	UNCERTAIN	CONSTANT	HIGH LIMIT	LOW LIMIT
3	Pressure (untrimmed)	Analog-to- digital converter in over/underrang e, DV1 sensor breakage, DV2 = BAD, fault in lineari- zation	•	Analog-to-digital converter in over- range/underrange, DV3 more than 20% outside the sensor limits DV2 = MANUAL	-	Analog-to- digital convert- er in overrange	Analog-to- digital convert- er in under- range
4	Level	If DV0 = BAD	When DV0 is simulated	DV0= UNCERTAIN	DV not active	DV0 = HIGH LIMIT	DV0 = LOW LIMIT
5	Volume	DV0 = BAD, Characteristic curve is faulty	When DV0 is simulated	DV0 = UNCERTAIN, input value is out- side the specified characteristic curve range	Characteristic curve is faulty DV not active	DV4 = HIGH LIMIT, Characteristic curve for max- imum value with gradient 0	DV4 = LOW LIMIT, Characteristic curve for mini- mum value with gradient 0
6	Mass	DV5 = BAD	When DV0 is simulated	DV5= UNCERTAIN	DV not active, DV5 = CONSTANT	DV5 = HIGH LIMIT	DV5 = LOW LIMIT
7	Volumetric flow (not absolute and gauge pressure)	DV0 = BAD, characteristic curve is faulty	When DV0 is simulated	DV0 = UNCERTAIN, input value is out- side the specified characteristic curve range	Characteristic curve is faulty, DV not active	DV4 = HIGH LIMIT, Characteristic curve for max- imum value with gradient 0	DV4 = LOW LIMIT, Characteristic curve for mini- mum value with gradient 0
8	Mass flow rate (not absolute and gauge pressure)	DV5 = BAD	When DV0 is simulated	DV5= UNCERTAIN	DV not active DV5 = CONSTANT	DV5 = #HIGH LIMIT	DV5 = LOW LIMIT
9	Users	DV0 = BAD, Characteristic curve is faulty	When DV0 is simulated	DV0 = UNCERTAIN, input value is out- side the specified characteristic curve range	Characteristic curve is faulty DV not active	DV0 = HIGH LIMIT, Characteristic curve for max- imum value with gradient 0	DV0 = LOW LIMIT, Characteristic curve for mini- mum value with gradient 0

If you use falling characteristic curves in the blocks, the meanings of HIGH LIMIT and LOW LIMIT are swapped around.

If you mix falling and rising characteristic curves, the meanings will be swapped each time a falling characteristic curve is run.


7.3.10 Analog output

Introduction

The "Analog output" block converts the value provided by the dynamic primary variable (PV) into a current value of 4 to 20 mA. When you actuate the measuring mode selector, you automatically define the start of scale value and the full scale value to the current values 4 and 20 mA, respectively. Limit values of corresponding device variables are used for scaling the analog output by default. You have entered these limits when setting the parameters of your measuring mode.

Example for measuring mode "Level"


This means that for a "Level" device variable as PV, 10 m corresponds to the value for 4 mA and 20 m corresponds to the value for 20 mA. You can change this presetting again in the "Analog output" block. This is done by restricting the range of the "Level" device variable for scaling the output current to e.g. 12 to 18 m. This downscaling has no effect on the previous block scaling. In this case, a current of 4 mA is output for a measured height of 12 m, and a current of 20 mA for 18 m.



Quarternary variable Figure 7-9 "Analog output" scaling

QV

Description of measuring mode "Level"



MA Start of scale value
ME Full scale value

p PressurePV Primary variable

Figure 7-10 "Analog output" block

Note

If, when setting the analog output, the values for the start of scale value zero and the full scale value are more than 20% below or above the limit values of the set PV (set using the variable mapper), the values will be rejected by the device. The values configured previously are retained. Similarly, the span must not fall below the minimum.

Minimum span = ME - MA

The square root extracting function can only be selected in the "Pressure" measuring mode.

The root extraction function "srli2" is set in "flow rate" measuring mode. You therefore set the "characteristic curve" parameter in SIMATIC PDM to "linear".

7.3.11 Scaling the display value

Introduction

You can scale the value shown in the display as you wish and allocate it any unit of 5 characters. The scaling of the value is independent of the selection of the measuring mode selector, the primary variable (PV) and the display unit defined. Use the "Display settings" item in SIMATIC PDM or the HART communicator for this purpose.

The percent value of the PV is the basis for this scaling. This percent value is also used to scale the current output. In SIMATIC PDM, this item is referred to as "Setting the PV output scaling". After selecting the "Display settings" menu item, you must enter a start-of-scale value, a full-scale value and a unit string.

This display option has the highest priority amongst all options. A switch over to %, mA or any other unit is not possible in this status. You need to deactivate the LCD scaling again for this purpose.

Example

In the Level measuring mode, the start of scale value is assumed as 0 m and the full scale value as 10 m in the example illustrated in the following picture. (Input scaling: 0 to 2 bar) The value of 2 m is displayed at a process pressure of 0.4 bar.




Figure 7-11 Free LCD scaling

7.4 Setting zero point and limit point

You can set the zero point and the limit point using the SIMATIC PDM or HART Communicator. You can use this function to realize rising or falling characteristic curves.

The pressure unit can be set separately for the display and for HART communication.

See also

Difference between setting and adjusting (Page 81)

7.5 Blind setting of zero point and limit point

- The start of scale value and the full scale value can be set without creating a reference pressure.
- Both values can be selected as any point within the sensor limits.
- The maximum downscaling is 1:100, depending on the series and the measuring range.
- You can use this function to realize rising and falling characteristic curves.

7.6 Zero point calibration (position correction)

Description

A zero point calibration is used to correct a zero point error resulting from the mounting position.

Procedure

- Pressurize the device or evacuate it (at absolute pressure, < 0.1 % of the measuring span).
- Perform the zero point calibration using SIMATIC PDM or the HART Communicator.
- If you do not have a vacuum, perform a trimming of the lower sensor calibration point at a known reference pressure.



For absolute pressure transmitters, the start of scale value is at vacuum. A zero point calibration with a pressurized pressure transmitter will lead to faulty settings!

Note

The effective measuring range is reduced by the amount of the upstream pressure.

Example:

With an upstream pressure of 100 mbar, the effective measuring range of a 1-bar pressure transmitter is reduced to a point between 0 and 0.9 bar.

See also

Trimming the sensor (Page 132)

7.7 Electrical damping

Description

You can set the time constant of electrical damping to a point within a range from 0 to 100 s. It always applies to the "Pressure" device variable (DV0) and thus to the measured values derived from it.

7.8 Fast response mode

Description

This mode is only intended for special applications such as fast recognition of jumps in pressure, e.g. pressure drop in the event of pipe breakage. The internal recording of measured values is sped up at the cost of accuracy. From your point of view, an increased low-frequency noise is caused for the measured value. For this reason, good accuracy can only be achieved by setting the measuring span to the maximum.

7.9 Current sensor

Description

The pressure transmitter can be switched to constant current operation for test purposes. In that case, the current no longer corresponds to the process variable. A "C" will appear in the mode display of the display.

7.10 Fault current

Description

You can use this function to adjust the size of the lower (< 4 mA) and upper (> 20 mA) fault current. Both signal a hardware/firmware fault, sensor breakage, or that the alarm limit has been reached (diagnostic interrupt). ERROR will in this case appear in the display. You can obtain a detailed guide to the display using SIMATIC PDM or the HART Communicator.

Reference

NAMUR recommendation NE43 dated 02/03/2003

"Standardization of the signal level for the breakdown information of digital pressure transmitters"

See also

Error display (Page 75)


Limit modules (Page 139)

7.11 Setting the current limits

Description

The level of the upper and lower fault current and the high and low saturation limits can be freely selected within the preset limits of the current output signal.

The specified accuracy of the current output signal is only valid within the current limits 4 to 20 mA.



- 1 Linear control range
- 2 Low saturation limit (default value)
- 3 High saturation limit (default value)
- 4 Lower fault current value (default value)
- 5 Upper fault current value (default value)
- 6 Recommended setting range for lower fault current range and lower control range limit
- Recommended setting range for upper fault current range and upper control range limit

Figure 7-12 Current limits

7.12 Key lock and write protection

Introduction

You can use this function to lock the keys or activate write protection to safeguard the saved parameters.

Lock options

You have the following lock options:

Table 7-3 Meaning of the HART lock modes

Lock mode	Meaning	
0	The device can be operated by means of the keys and HART communication.	
LA	Keys on the pressure transmitter are locked.	
	Exception:	
	Releasing key lock	
	The device can be operated by means of HART communication.	
LO	Keys on the pressure transmitter are partially locked.	
	Exception:	
	Setting start of scale value	
	Releasing key lock	
	The device can be operated by means of HART communication.	
LS	Keys on the pressure transmitter are partially locked.	
	Exception:	
	Setting start of scale value	
	Setting full scale value	
	Releasing key lock	
	The device can be operated by means of HART communication.	
LL	Write protection	
	You can now only release the lock using HART communication.	

See also

Locking buttons and functions (Page 96)

Releasing key lock or function lock (Page 98)

7.13 Measured value display

Introduction

You can use this function to set one of three options for the device display:

- Display in mA
- Display in % (of the set measuring range)
- Display in a physical unit

Table 7-4 Display of measuring mode/device variables

DV	Meaning	
0	Pressure	
1	Sensor temperature	
2	Electronics temperature	
3	Pressure (untrimmed)	
4	Level	
5	Volume	
6	Mass	
7	Volumetric flow rate (not relevant to gauge or absolute pressure)	
8	Mass flow rate (not relevant to gauge or absolute pressure)	
9	Users	

Points to note for "Pressure" DV

If the device variable (DV) is set to "Pressure", you can configure the displayed pressure unit with an extension, GAUGE (G) or ABS (A). The add-on has no effect on the real measured value.

To do so, select the option Gauge or Absolute under the "Pressure display type" menu item.

7.14 Selection of the physical unit

There are two options for the display:

- If the pressure unit is < 5 characters, an A or a G is added at the end, respectively.
- If the pressure unit is ≥ 5 characters, the letters GAUGE or ABS flash alternately with the pressure unit.







Figure 7-13 Add-on with example GAUGE

Note

The change of the display with GAUGE or ABS does not change the physical pressure used by the pressure transmitter, rather only the nature of the display.

See also

Measured value display (Page 101)

7.14 Selection of the physical unit

Introduction

You can use this function to select a unit from a table with predefined units.

Description

The only units available will be those of the device variable that was mapped as the Primary Variable (PV).

The unit can be set separately for the display and for HART communication. You can also choose to link the setting of the two units.

See also

Unit (Page 102)

7.15 Bar graph

Description

You can use this to switch on the "Bar graph" function in the device display as an alternative to the unit display. The "Bar graph" function is disabled in the factory state.

See also

Display elements (Page 73)

7.16 Sensor calibration

7.16.1 Sensor trim

Description

The sensor trim can be used to set the characteristic curve of the pressure transmitter at two sensor trim points. The results are then correct measured values at the sensor trim points. The sensor trim points can be selected as any points within the nominal range.

Devices that are not turned down prior to delivery are trimmed at 0 bar and the high limit of the nominal range; devices that are turned down prior to delivery are trimmed at the low and high limits of the set pressure measuring range.

Application examples

- For a particular device that is not turned down (e.g. 63 bar), the typical measured value is 50 bar. To attain the highest possible accuracy for this value, set the upper sensor trim at 50 bar.
- A 63-bar pressure transmitter is turned down to 4 to 7 bar. You can attain the highest possible accuracy by selecting 4 bar for the low sensor trim point and 7 bar for the high point.
- A 250-mbar absolute pressure transmitter shows 25 mbar at 20 mbar (abs). A reference
 pressure of 100 mbar is available. You can carry out zero-point correction by performing
 a lower sensor trim at 100 mbar.

Note

The accuracy of the test device should be at least three times as high as that of the pressure transmitter.

7.16.2 Trimming the sensor

Trim the sensor at the lower trim point


The pressure at which the lower sensor trim is to be performed is applied at the pressure transmitter. Via SIMATIC PDM or the HART Communicator, you instruct the pressure transmitter to accept this pressure.

This represents an offset shift of the characteristic curve.

Trim the sensor at the upper trim point

The pressure at which the upper sensor trim is to be performed is applied at the pressure transmitter. Via SIMATIC PDM or the HART Communicator, you instruct the pressure transmitter to accept this pressure.

A gradient correction is thereby applied to the characteristic curve. The lower sensor trim point is not affected by this. The upper trim point needs to be greater than the lower trim point.



- A Original characteristic
- B Characteristic curve after lower sensor trim
- C Characteristic curve after upper sensor trim

Figure 7-14 Sensor calibration

7.17 Current simulator trim

The current that is output by the pressure transmitter can be trimmed independently of the pressure measuring circuit. This function is designed for compensating inaccuracies in the processing chain following the pressure transmitter.

Example of an application

The current is to be measured as a voltage drop from 1 to 5 V at a resistance of 250 Ohm +/-5%. To trim the tolerance of the resistance, set the current simulator so that the voltage drop at 4 mA is exactly 1 V and at 20 mA is exactly 5 V.

Trim at 4 mA:


Use the current transmitter trim menu option to instruct the pressure transmitter to output 4 mA. Read the measured value at an ammeter and input it. The pressure transmitter uses this value for offset correction of the current.

• Trim at 20 mA:

Use the current transmitter trim menu option to instruct the pressure transmitter to output 20 mA. Read the measured value at an ammeter and input it. The pressure transmitter uses this value for gradient correction of the current. The value for 4 mA is not affected by this.

Note

If a multimeter is used, it must always be sufficiently accurate.



- A Original characteristic
- B Characteristic curve after current simulator trim 4 mA
- C Characteristic curve after current simulator trim 20 mA

Figure 7-15 Current simulator trim

7.18 Factory calibration

Introduction

You can use factory calibration to reset the pressure transmitter to the delivery state.

Description

You can use the menu-guided interface of SIMATIC PDM or HART Communicator to select the range of parameters to be restored:

- 1. Return of current calibration
- 2. Return of sensor zero-point calibration (position correction)
- 3. Return of pressure corrections (zero-point calibration and sensor trim)
- 4. Return of all parameters relevant for the processing of measured values, such as start of scale value, full scale value, electrical damping, display unit, current trim, zero-point calibration (position correction), sensor trim, measuring speed, alarm current limits, alarm setting, overflow ranges of current.
- Reset of the variable mapper. This is the effect of the following setting:
 PV= Pressure, SV= Sensor temp., TV= Electronics temp., QV= Non-linearized pressure
- PV Primary variable
- SV Secondary variable
- TV Tertiary variable
- QV Quarternary variable

See also

Factory calibration - FAQ (http://support.automation.siemens.com/WW/view/en/10806940/133000)

7.19 Static configuration data

Description

A further menu command in the corresponding operating program allows you to read and also write a series of sensor-specific material data. With the factory state, this data is pre-allocated according to the particular device model. These values are not contained in the "Factory calibration" function; in other words, changes in the device are permanently saved.

List of variable material parameters:

- Flange type
- Flange material

- · Remote seal type
- Filling medium
- O-ring material
- Remote seal
- Remote seal diaphragm material
- Number of remote seals
- · Sensor filling medium
- Sensor seal diaphragm material
- Pressure transmitter version
- Housing material
- Tube length
- Process connection
- Electrical connection
- Process connection screw material
- Vent valve position

For a series of these material data items, you can enter any designation of your choice under the option "Special". This applies to the following parameters:

- Process connection
- Flange type
- · Process connection screws
- · O-ring material
- Material of vent valve
- Vent valve position
- · Remote seal type
- Remote seal
- Diaphragm material
- Remote seal filling medium

You can use up to 16 characters for each entry.

7.20 Flow rate measurement (only differential pressure)

Description

For the "Differential pressure and flow rate" device version, you can select the characteristic curve of output current as follows without actuating the measuring mode selector:

- linear "lin": proportional to differential pressure
- square root extracting "sroff": proportional to flow rate, deactivated up to the application point
- square root extracting "srlin": proportional to flow rate, linear up to the application point
- square root extracting "srlin2": proportional to flow rate, two-step linear up to the application point

Variable application point

The output current for the "srlin" and "sroff" functions can be displayed linearly or set to zero below the application point of the square root extracting characteristic curve.

Fixed application point

The "srlin2" function has a permanently defined application point of 10%. The range up to this point contains two linear characteristic curve sections. The first section ranges from the zero point to 0.6% of the output value and 0.6% of the pressure value. The second section has a higher gradient and it goes up to the root application point at 10% of the output value and 1% of the pressure value.

See also

Flow rate measurement (only differential pressure) (Page 98)

7.21 Diagnostic functions

7.21.1 Overview

Description

HART communication allows you to activate and evaluate a wide range of diagnostic functions from a central control room or on site.

- Calibration/service timer
- Min/max pointer
- Limit monitoring blocks

- Simulation of measured pressure and temperature values
- Limit monitoring of all device variables

The diagnostics strategy employed for the pressure transmitter allows for the configuration of a diagnostic warning and a diagnostic alarm for diagnostic functions for monitoring limit values, e.g. for monitoring current saturation:

- Diagnostic warning: The device transmits via HART communication the diagnostic event that has occurred. The current output value is unaffected. The message "Diagnostic Warning" alternates with the unit on the display.
- Diagnostic alarm: The device goes into the fault current state. The message "Diagnostic Warning" or "Diagnostic Alarm" appears on the display, along with the message ERROR. In addition, the diagnostic event is made available via HART communication.

In the default settings, all warnings and alarms are switched off. You can choose to set either the diagnostic warning only or the diagnostic alarm and warning. For HART communication, use the HART Communicator or PC software such as SIMATIC PDM. To see the steps required, refer to the attached table for operation of the HART Communicator or the help functions in the SIMATIC PDM software.

7.21.2 Operating hours counter

Description

You can read out one operating hours counter for the electronics and one for the sensor via HART communication. For HART communication, use the HART Communicator or PC software such as SIMATIC PDM. The counters are activated the first time the pressure transmitter is put into operation. If the power supply to the device is interrupted, the counter readings are automatically stored in the non-volatile memories. This means you have access to the latest counter readings with the next restart. The operating hours counters cannot be reset.

7.21.3 Calibration timer and service timer

Description

To ensure regular calibration of the electronics and for service work on the sensor, you activate a two-stage timer in each case. On expiry of the first time period, a calibration or service request is made. On expiry of a second time span set by parameter as a time difference, a diagnostic alarm is reported and a fault current is output.

The calibration intervals for the electronics are calculated using the following formula:

Calibration interval = required accuracy – probable total error Stability/month

7.21 Diagnostic functions

For performance of the calibration work, you must acknowledge the requests and alarms. Then you can reset the timer. In addition, there is a facility to deactivate the monitoring function.

The following procedure applies for acknowledgement of requests and alarms:

As long as the warning/alarm limit has not been reached, the following applies:

- "Reset the timer" this resets the timer, which then restarts from 0. The monitoring remains active.
- 2. "Alarm/Acknowledge the request" this has no effect; the timer continues to run and the monitoring remains active.


When the warning/alarm limit has been reached, the following applies:

- "Alarm/Acknowledge the request" resets the request / alarm message, but allows the timer to continue to run. In this state, a new alarm or warning is not possible since the time limits have already been exceeded.
- 2. "Reset timer" resets the request / alarm message, also resets the timer. It acknowledges the interrupt or warning at the same time. The timer immediately starts running again from zero and will report again when the warning/alarm limit is next reached. The next calibration interval is therefore immediately active.

7.21.4 Min/max indicator

Description

The pressure transmitter has three pairs of min/max pointers which you can use to monitor the three measured variables pressure, sensor temperature, and electronics temperature for negative and positive peak values. For each measured value, a resettable min/max pointer saves the maximum and minimum peak values in long-term storage in the two non-volatile memories. Consequently, the values are available even after the device is restarted. The min/max pointers are also updated during a simulation.



p Pressure

Figure 7-16 Basic representation of min/max pointers

7.21.5 Limit modules

Introduction

The diagnostic functions of this device give you an option to monitor the measured values in programmable limits. If the limits are not adhered to, the device sends a warning through HART communication or notifies a higher-level instance about an analog fault current.

Monitoring of current saturation

You can monitor the current output in the saturation range using a simple limit module. This limit module is configured and activated via HART communication. For HART communication, use a HART communicator or PC software such as SIMATIC PDM.

You need to set two time periods to configure the limit module:

The first time period specifies how long the current output is allowed to be in saturation before an interrupt is triggered and the device outputs its set fault current. This first time period is the response time.

The second time period specifies the duration of the interrupt. This second time period is the stop time.

Different outputs of the fault current corresponding to the set response and stop times are shown in the following example.

Configuring the direction of fault current

The current value is proportional to pressure within the saturation limits. When the saturation limits are exceeded, the direction of fault current can however vary from the direction of saturation. The upper or the lower fault current is displayed depending on the parameter settings of the direction of fault current.

You can configure the direction of fault current for a current saturation interrupt depending on your requirements. The following settings are possible under the current saturation menu:

Active interrupt value The applicable settings are those under the current interrupt type

menu command.

Inverse interrupt value
The applicable settings are the inverse settings under the current

interrupt type menu command.

Saturated interrupt value The fault current is output in the direction of current saturation.

Inverse saturated interrupt The fault current is output in the opposite direction to current satu-

value ration.

The difference between different settings is evident in examples 3 and 4 in the following figure. Example 3 shows the direction of fault current with the "Saturated current value" setting. Example 4 shows the direction of fault current with the "Active upper interrupt value" setting.

Example

The configured saturation limits in the following figures are 3.8 mA and 20.5 mA.

Example 1: the response time starts at t_1 . At t_1 , current reaches the configured saturation limit of 20.5 mA for the first time. At t_2 , the response time ends. The stop time begins and the interrupt is triggered. Time t_3 is the configured end of the stop time. At t_3 , the interrupt is immediately revoked even if the current then drops below the saturation limit again.

Example 2: the duration of the current saturation is shorter than the response time (t_1, t_2) . In that case, the device does not go into "fault current" state.

Example 3: the current drops below the lower saturation limit only for a short time. The fault current is not switched off until after the end of the stop time (t_3) . The direction of fault current corresponds to the "Saturated interrupt value" setting. The fault current is output in the direction of current saturation.

Example 4: the current drops below the lower saturation limit only for a short time. The fault current is not switched off until after the end of the stop time (t_3) . The direction of fault current corresponds to the "Active upper interrupt value" setting. The upper fault current is outputted although the direction of current saturation is downward.




Figure 7-17 Four examples of saturation monitoring

See also

Fault current (Page 126)

7.22 Simulation

7.22.1 Overview of simulation

Description

With the "Simulation" diagnostic function, you can receive and process simulated measured data on site or in the control room without having process pressure or a temperature value. This allows you to run individual process sequences in the "cold" state and thus simulate process states. In addition, if you inject simulation values you can test the line routing from the control room to the individual pressure transmitter.

The value to be simulated can be provided as a fixed value or in the form of a ramp function. Simulation of pressure and temperature values is handled in the same way in terms of parameter assignment and function, so the following will only deal with the general simulation procedures "Fixed value" and "Ramp function".

7.22 Simulation

For security reasons, all simulation data is held only in the non-volatile working memory. This means that when the device is restarted, any simulation which may be active will be shut down. You can simulate the pressure and both temperature values. It should be noted here that changing the temperatures by simulation will have no effect on the measured pressure value.




Figure 7-18 Block diagram of simulation

7.22.2 Simulation as fixed value

Description

Taking the physical unit into account, you can configure a fixed simulation value for all three possible simulation paths. You can simulate the pressure value and both temperature values simultaneously. While pressure simulation is activated, the pressure transmitter will not react to changes in the process pressure. The current output value adjusts itself in accordance with the preset pressure value. Simulation of the temperature values has no effect on the current output. It can only be observed via HART communication.

7.22.3 Simulation with a ramp function

Description

In addition to the adjustable fixed values for all three simulation paths, you can, as a second option, also configure one ramp function in each case. Adjustable lower and upper values together determine the limits between which the simulation values with a rising or falling tendency can move. The step width can be calculated with the step number, which is also adjustable. You can specify the rate of rise of the ramp via the duration of the individual ramp steps.

Increment = Upper range value – Lower range value
Number of steps

7.23 Limit monitor

Description

You can activate up to three limit monitors in order to monitor any of the device variables. The limit monitor monitors a value at an upper or lower limit value. If this limit is violated it sends a diagnostic warning or a diagnostic interrupt. Select the "Limit Monitor" menu command in SIMATIC PDM or in the HART communicator. You can program the following values for each of the three limit monitors:

Table 7-5 Parameter of the limit monitor

Monitoring variable	You will be shown a list of the active device variables. This list is independent of the measuring mode selected.
Limit monitoring: warning / interrupt	Select whether a warning or a warning plus an interrupt should be triggered when a limit is violated.
Limit monitoring: upper / lower	Specify here whether a device variable monitors the upper limit, the lower limit, or both limits.
Upper limit value	Upper limit value in the unit of the device variable.
Lower limit value	Lower limit value in the unit of the device variable.
Hysteresis	Operating point for chatter suppression in the case of small pressure changes.
Response time	The time which must pass after the limit is violated before this violation is registered.
Stop time	The time for which a limit interrupt or warning will always be sustained even when the event which triggered it is no longer present.

7.23 Limit monitor




Figure 7-19 Trip levels for the limit monitor

You can count the limit violations for each limit monitor by activating an event counter that provides separate, cumulative totals of upper and lower limit violations. A diagnostic warning and / or a diagnostic interrupt can be issued once a certain number of violations is reached, a number which you can also program. You can program the following values for the event counter:

Table 7- 6 Parameters of the event counter

Event counter: upper limit	Select here whether a warning or a warning plus an interrupt should be triggered when the comparison value is exceeded.		
Event counter: lower limit	Select here whether a warning or a warning plus an interrupt should be triggered when the comparison value is not met.		
Comparison value: upper limit	Specify here the number of overflows at which a warning or a warning plus an interrupt should be triggered.		
Comparison value: upper limit	Specify here the number of underflows at which a warning or a warning plus an interrupt should be triggered.		
Limit monitoring, warning/interrupt: upper limit	Select whether a warning or a warning plus an interrupt should be trig- gered when the event counter upper limit is violated.		
Limit monitoring, warning/interrupt: lower limit	Select whether a warning or a warning plus an interrupt should be triggered when the event counter lower limit is violated.		
Reset event counter upper limit	Here you can reset the upper limit counter to zero. A new event is not possible until the counter has been reset.		
Reset event counter lower limit	Here you can reset the lower limit counter to zero. A new event is not possible until the counter has been reset.		
Warning/interrupt acknowledgement	Here you can acknowledge each warning or interrupt separately.		




Figure 7-20 Limit monitor and event counter

Messages from the limit monitor and from the event counter can be acknowledged separately. Resetting the event counter starts a new monitoring interval.

7.23 Limit monitor

Functional safety

8.1 Safety function

The safety function of SITRANS P refers to the measurement of pressures. (Order option - Z C20 and -Z C23) Add an additional safety accuracy of 2% of the maximum measuring range to the application-specific measurement error.

Total tolerance (safety function) = \pm [application-specific measuring error + 2% safety accuracy].

Pressure transmitter safety accuracy: the maximum effect of a random non-critical individual error on the measured value.

The diagnostics function will respond within 4 seconds in the worst-case scenario.

The safety accuracy together with the application-specific measurement error allows the system operator to include a backup for process monitoring. Even if a random individual error occurs that is within the safety accuracy, the system can still be safely shut down.

As there is also always a possibility of dangerous faults occurring, these are categorized and listed in the manufacturer declaration for the device (SIL declaration of conformity, functional safety pursuant to IEC 61508 and IEC 61511).

Example:

A silo is to be securely monitored to check that the level does not exceed 10 meters.

Application-specific measurement error: 0.1%

Safety accuracy: 2.0% Total tolerance: 2.1%

2.1% of 10 meters is 21 centimeters. If process monitoring is set to 9.79 meters, safe shutdown is guaranteed even in the event of a random individual error within the safety accuracy.

Note

Use of remote seals

If remote seals are used, the application-specific measurement error is the product of the pressure transmitter and remote seal measurement errors.



Disregarding conditions for fulfilling the safety function

Disregarding conditions can result in a malfunction of the process system or application, for example, process pressure too high, maximum level exceeded.

The binding settings and conditions are listed in the chapters "Settings (Page 151)" and "Safety characteristics (Page 152)".

Please observe the applicable conditions to ensure the safety function.

Safety-instrumented system in single-channel operation (SIL 2)




Figure 8-1 Safety-instrumented system in single-channel operation

The combination of transmitter, automation system and final controlling element forms a safety-instrumented system that performs a safety function. The emphasis of this description is on the transmitter. For information on requirements for the automation system or final controlling element, please refer to the corresponding standards.

The transmitter generates a process-related measured value that is transferred to the automation system. The automation system monitors this measured value. If the measured value violates the high or low limit, the automation system generates a shutdown signal for the connected final controlling element, which switches the corresponding valve to the specified safety position.

Only one SITRANS P device is required for single-channel operation for SIL 2.

Safety-instrumented system in multi-channel operation (SIL 3)




Figure 8-2 Safety-instrumented system in multi-channel operation

The combination of transmitter, automation system and final controlling element forms a safety-instrumented system that performs a safety function. The emphasis of this description

is on the transmitter. For information on requirements for the automation system or final controlling element, please refer to the corresponding standards.

The transmitter generates process-related measured values that are transferred to the automation system. The automation system monitors these measured values. In the event of a fault, the automation system generates shutdown signals for connected final controlling elements that set the associated valve to the defined safety position. Faults are:

- Violations of the preset high or low limits
- Deviations between the two measured values

The automation system program must monitor the measured values of both SITRANS P devices. As soon as the measured values differ by e.g. 2% or more, the system must be brought into the safe state and the fault must be located.

Two SITRANS P devices are required for multi-channel operation for SIL 3. Operation with one device is not permitted.

Note

Switching-off of system at high monitoring accuracy

The two transmitters are connected to the process at different positions. Actual differences in pressure \geq the total tolerance (safety function) can occur when the process is started up or if there are other pressure variations. A difference in pressure \geq the total tolerance (safety function) will shut down the system.

- Match the monitoring accuracy of the automation system to the process.
- Mount the two transmitters exposed to equal conditions.

8.2 Safety Integrity Level (SIL)

The international standard IEC 61508 defines four discrete Safety Integrity Levels (SIL) from SIL 1 to SIL 4. Every level corresponds to a probability range for the failure of a safety function.

Description

The following table shows the dependency of the SIL on the "average probability of dangerous failures of a safety function of the entire safety-instrumented system" (PFD_{AVG}). The table deals with "Low demand mode", i.e. the safety function is required a maximum of once per year on average.

Table 8- 1 Safety Integrity Level

SIL	Interval
4	10 ⁻⁵ ≤ PFD _{AVG} < 10 ⁻⁴
3	10 ⁻⁴ ≤ PFD _{AVG} < 10 ⁻³
2	10 ⁻³ ≤ PFD _{AVG} < 10 ⁻²
1	10 ⁻² ≤ PFD _{AVG} < 10 ⁻¹

8.2 Safety Integrity Level (SIL)

The "average probability of dangerous failures of the entire safety-instrumented system" (PFD_{AVG}) is normally split between the following three components:




Figure 8-3 PFD distribution

The following table shows the achievable Safety Integrity Level (SIL) for the entire safety-instrumented system for type B devices depending on the safe failure fraction (SFF) and the hardware fault tolerance (HFT).

- Type B devices include analog transmitters and shut-off valves with complex components, e.g. microprocessors (also see IEC 61508, Section 2).
- For detailed information on values and hardware/firmware versions for your device, refer
 to the manufacturer declaration for the device (Declaration of Conformity, Functional
 Safety according to IEC 61508 and IEC 61511): Certificates
 (http://www.siemens.com/processinstrumentation/certificates).

SFF	HFT for type B devices	HFT for type B devices		
	0	1 (0) ¹⁾	2 (1) 1)	
< 60 %	Not permitted	SIL 1	SIL 2	
60 to 90 %	SIL 1	SIL 2	SIL 3	
90 to 99 %	SIL 2	SIL 3	SIL 4	
> 99 %	SIL 3	SIL 4	SIL 4	

Operational reliability in accordance with IEC 61511-1, Section 11.4.4

Operational reliability

According to IEC 61511-1, Section 11.4.4, the hardware fault tolerance (HFT) can be reduced by one (values in brackets) for transmitters and final controlling elements with complex components if the following conditions apply to the device:

- The device is proven in operation.
- The user can configure only the process-related parameters, e.g. control range, signal direction in case of a fault, limiting values, etc.
- The configuration level of the firmware is blocked against unauthorized operation.
- The function requires SIL of less than 4.

See also

General functional safety (http://www.siemens.com/safety)

Functional safety in process instrumentation (http://www.siemens.com/SIL)

8.3 Settings

Introduction

This section details the following areas:

- Settings for devices with functional safety
- Measures you must take when using the device for functional safety.

Procedure

- 1. Adjusting safety-relevant parameters
- 2. Checking the safety function
- 3. Activate button and function lock

Adjusting safety-relevant parameters

Parameter name	Adjust parameter value
Low saturation limit	3.8 mA
High saturation limit	20.5 mA
Lower fault current value	3.6 mA
Upper fault current value	22.8 mA

See section Setting the current limits (Page 127).

Checking the safety function

After adjusting the device, check the safety function. You can find a description for checking the safety function in the chapter Checking the safety function (Page 153).

See also

Releasing key lock or function lock (Page 98)

Locking buttons and functions (Page 96)

8.4 Safety characteristics

The safety characteristics necessary for using the system are listed in the "SIL declaration of conformity". These values apply under the following conditions:

- The SITRANS P pressure transmitter is only used in applications with a low demand for the safety function (low demand mode).
- Communication with the HART protocol is used only for the following:
 - Device configuration
 - Reading diagnostics values
 - However, it is not used for operations critical to safety. In particular, the simulation function must not be activated in safety-related operation.
- The safety-related parameters/settings have been entered by local operation or HART communication before commencing safety-related operation. Check the parameters/settings on the device display. See section Settings (Page 151).
- The safety function test has been concluded successfully.
- The transmitter is blocked against unwanted and unauthorized changes/operation.
- The current signal of 4 to 20 mA of the transmitter is evaluated by a safe system.
- Fault rates are calculated on the basis of a Mean Time To Repair (MTTR) of eight hours (order option C20) or 72 hours (order option C23).

Special points to note for multi-channel operation (SIL 3)

- Two devices are required for multi-channel operation in accordance with SIL 3.
- The automation system must monitor the measured values of both devices. The system must be put into safe mode as soon as the measured values differ too greatly.

8.5 Maintenance/check

8.5.1 Overview

Checking safety

Check the safety function of the entire safety circuit on a regular basis in accordance with IEC 61508/61511. The test intervals are determined in the course of calculations for each safety circuit of a system (PFD_{AVG}).

Checking safety function/proof test

Runs this test to detect hidden serious faults of the pressure transmitter.

Hidden faults result in incorrect measurements and dangerous failures in your safety-related system.

If necessary, replace the pressure transmitter.

Activate button and function lock

After parameter assignment/commissioning as well as after a proof test, perform the following steps:

- Set the lock mode in Mode 10 to write protection "L".
 Operation via keys and HART communication is blocked.
- 2. Protect the keys from unintended change in the parameters, e.g. by lead-sealing.

Electronics and measuring cell

The safety function of the pressure transmitter is ensured only if you use the electronics, measuring cell, display and connection board delivered by the factory. These components cannot be replaced.

See also

Settings (Page 151)

Checking safety function/proof test (Page 153)

8.5.2 Checking safety function/proof test

Requirement

- You should check the safety function while the device is installed, if possible. If this is not
 possible, you can also check the safety function when the device is not installed. Make
 sure that the pressure transmitter is mounted in the same position for testing as it is in the
 system.
- Observe the information in the section Key lock or function lock.
- If you are using add-on parts, also see the tests in chapter Add-on parts (Page 160).

Procedure

- 1. Make sure that the test does not inadvertently result in an emergency shutdown of the system.
- 2. Make sure that there are no active warnings or error messages.
- 3. Checking temperature sensors (Page 155)
- 4. Simulate the fault current. (Page 155)

8.5 Maintenance/check

5. Conduct a two-point measurement:

Two-point measurement ≥ 10% of the maximum measuring range. (Page 155)

- or -

Two-point measurement ≥ 50% of the maximum measuring range. (Page 155)

- 6. Make sure that the pressure transmitter is in measuring mode.
- 7. After the test, make sure that the emergency shutdown of the system is working again.
- 8. Activate the locking of buttons and functions (Page 152).

Result

If you are conducting the test as described, you will uncover dangerous faults to a certain degree that are not detected by runtime diagnostics:

- With two-point measurement ≥ 10% of the maximum measuring range: 83% of the faults are uncovered.
- With two-point measurement ≥ 50% of the maximum measuring range: 99% of the faults are uncovered.

Note

If you are operating or testing the pressure transmitter with a limited measuring range (10% of the maximum measuring range), you will also uncover 99% of the faults.

If a measuring cell of 63 bar is only used in the range from 0 bar to 6.3 bar, for example, and this range is tested completely, you will also uncover 99% of the faults.

If a larger measuring range than 10% is used but only 10% of the maximum measuring range is tested, the error discovery is less than 99%.

Interval

- Check the pressure transmitter regularly for proper function to uncover influences which could reduce the functionality of the pressure transmitter in time (proof test).
- Select the interval according to the process and ambient conditions of the installation location of the pressure transmitter.

Note

For a safety-instrumented system, we recommend checking the device at regular intervals of one year.

For safety-instrumented systems in multi-channel operation (SIL 3), the PFD value required by the IEC 61508 standard will not be exceeded within the service life (15 years). This means a proof test is not necessary as far as the standard is concerned.

8.5.2.1 Checking temperature sensors

Procedure

- Read the sensor temperature and the electronics temperature via HART communication.
- Check whether the measured temperature is within the range of -80 °C and 120 °C.
 If the measured temperature is not within this range, the temperature sensor is defective.

8.5.2.2 Simulating fault current

Introduction

You simulate the fault current with the operator function with the "Current simulator" keys (see Operation using buttons (Page 81)).

Alternatively, you can use the menu command Device>Measuring circuit test in SIMATIC PDM.

Procedure

- 1. Enter a low fault current value (3.6 mA).
- 2. Check the fault current value at the output.
- 3. Enter a high fault current value (22.8 mA).
- 4. Check the fault current value at the output.
- 5. Exit the simulation.

Checking the fault current is successful when the deviation between the set and the measured fault current is less than 0.2%.

8.5.2.3 Two-point measurement ≥ 10% of the maximum measuring range

General procedure

Requirement

The difference between the first input pressure and the second input pressure is \geq 10% of the maximum measuring range.

Checking the measuring range

- 1. Apply an initial input pressure.
- 2. Measure the output current.

8.5 Maintenance/check

- 3. Apply a second input pressure.
- 4. Measure the output current.




Figure 8-4 Example of two-point measurement 10%

See also

Procedure for monitoring a maximum pressure (Page 157)

Procedure for monitoring a minimum pressure

Checking monitoring of a minimum pressure

- 1. Check the monitoring of the minimum pressure with the threshold defined in the system.
- 2. Apply an input pressure value that is ≥ 1% below the threshold.
- 3. Apply an input pressure value that is \geq 9% above the threshold.




Figure 8-5 Monitoring of a minimum pressure

See also

Procedure for monitoring a maximum pressure (Page 157)

Procedure for monitoring a maximum pressure

Checking monitoring of the maximum pressure

- 1. Check the monitoring of the maximum pressure with the threshold defined in the system.
- 2. Apply an input pressure value that is 10% above the threshold.
- 3. Apply an input pressure value that is below the threshold.

Note

Step 3 can only be implemented if the maximum limit value is > 10% below the maximum full scale value. Otherwise, check only up to full scale value.

However, the test range must be 10% of the maximum measuring range.




Figure 8-6 Monitoring of a maximum pressure

See also

Procedure for monitoring a maximum pressure (Page 157)

Result

The two-point measurements are successful when the deviation between input pressure and measured output current is $\leq 0.2\%$.

Negative measurement result

If the two-point measurements of the pressure transmitter were not successful, the SIL level is no longer guaranteed.

Replace the pressure transmitter.

8.5.2.4 Two-point measurement ≥ 50% of the maximum measuring range

General procedure

Requirement

The difference between the first input pressure and the second input pressure is \geq 50% of the maximum measuring range.

Checking monitoring of the maximum measuring range

- 1. Apply an initial input pressure.
- 2. Measure the output current.
- 3. Apply a second input pressure.
- 4. Measure the output current.




Figure 8-7 Example of two-point measurement 50%

See also

Procedure for monitoring a maximum pressure (Page 159)

Procedure for monitoring a minimum pressure

Checking monitoring of a minimum pressure

- 1. Check the monitoring of the maximum pressure with the threshold defined in the system.
- 2. Apply an input pressure value that is 1% below the threshold.
- 3. Apply an input pressure value that is ≥ 49% above the threshold when the maximum limit value is > 10 % below the maximum full scale value.




Figure 8-8 Monitoring of a minimum pressure

See also

Procedure for monitoring a maximum pressure (Page 159)

Procedure for monitoring a maximum pressure

Checking monitoring of the maximum pressure

- 1. Check the monitoring of the maximum pressure with the threshold defined in the system.
- 2. Apply an input pressure value that is ≥ 10% above the threshold.
- 3. Apply an input pressure value that is \geq 40% below the threshold.

Note

Step 3 can only be implemented if the maximum limit value is > 10% below the maximum full scale value. Otherwise, check only up to full scale value.

However, the test range must be 50% of the maximum measuring range.




Figure 8-9 Monitoring of a maximum pressure

See also

Procedure for monitoring a maximum pressure (Page 159)

8.6 Add-on parts

Result

The two-point measurements are successful when the deviation between input pressure and measured output current is $\leq 0.2\%$.

Negative measurement result

If the two-point measurements of the pressure transmitter were not successful, the SIL level is no longer guaranteed.

• Replace the pressure transmitter.

8.5.2.5 Checking pressure transmitter for external damage

- Make sure that the terminal compartment is dry.
- Make sure that the enclosure and the process connections do not have any leaks through which the filling oil or the process medium could escape.
- Check the enclosure for critical damages.
- Make sure that the connecting cable is plugged in correctly and that it is not damaged.

8.6 Add-on parts

This chapter contains safety information for add-on parts.



Add-on parts unsuitable for process medium

Danger of injury or damage to device.

If the process medium is not suitable for the parts which come into contact with it, hot and/or toxic or corrosive substances could be released.

- Refer to the information in the chapter "Technical data (Page 185)".
- Make sure that the add-on parts are suitable for the corresponding application with regard to materials, temperature of process medium, and pressure.

8.6.1 Checking a device with add-on pneumatic block

Procedure

- 1. Check the connection between the pressure transmitter and pneumatic block and between the pneumatic block and pipelines in the plant for leaks.
- 2. Observe the safety information and specifications in chapter Installing/mounting (Page 37).

- 3. Check the following valves for correct positioning and absence of leaks:
 - Process valves
 - Stabilizing valve
 - Vent valves
 - Blowout valves or plugs
- 4. Observe the safety information and specifications in chapter Commissioning (Page 163).

8.6.2 Checking a device with add-on remote seal

Procedure

- 1. Check the connection between the pressure transmitter and remote seal and between the remote seal and the plant for leaks.
- 2. Observe the safety information and specifications in chapter Installing/mounting (Page 37).

8.6 Add-on parts

Commissioning

9.1 Basic safety instructions



Toxic gases and liquids

Danger of poisoning when venting the device: if toxic process media are measured, toxic gases and liquids can be released.

• Before venting ensure that there are no toxic gases or liquids in the device, or take the appropriate safety measures.

AWARNING

Improper commissioning in hazardous areas

Device failure or danger of explosion in hazardous areas.

- Do not commission the device until it has been mounted completely and connected in accordance with the information in Chapter "Technical data (Page 185)".
- Before commissioning take the effect on other devices in the system into account.

A WARNING

Opening device in energized state

Danger of explosion in areas subject to explosion hazard.

- Only open the device in a de-energized state.
- Check prior to commissioning that the cover, cover locks, and cable inlets are assembled in accordance with the directives.

Exception: Devices having the type of protection "Intrinsic safety Ex i" may also be opened in energized state in hazardous areas.

9.2 Introduction to commissioning

Following commissioning, the pressure transmitter is immediately ready for use.

To obtain stable measured values, the pressure transmitter needs to be allowed to warm up for around 5 minutes after the power supply is switched on. When it starts up, the pressure transmitter goes through an initialization routine (display at the end: "Init done"). If the pressure transmitter does not complete the initialization routine, check the auxiliary power.

9.3 gauge pressure, absolute pressure from the differential pressure series and absolute pressure from the gauge pressure series


The operating data must correspond to the values specified on the nameplate. If you switch on the auxiliary power, the pressure transmitter is in operation.

The following commissioning cases are typical examples. Configurations different from those listed here may be meaningful depending on the system configuration.


9.3 gauge pressure, absolute pressure from the differential pressure series and absolute pressure from the gauge pressure series

9.3.1 Commissioning for gases





Special arrangement



Measuring gases above the pressure tapping point Measuring gases below the pressure tapping point

9.3 gauge pressure, absolute pressure from the differential pressure series and absolute pressure from the gauge pressur

1 Pressure transmitter (5) Pressure line Shut-off valve Shut-off valve (2) Shut-off valve to process Shut-off valve (optional) (3) (7) Shut-off valve for test connection or for (8) Condensate vessel (optional) (4) bleed screw Drain valve

Requirement

All valves are closed.


Procedure

To commission the pressure transmitter for gases, proceed as follows:

- 1. Open the shut-off valve for the test connection 4.
- 2. Via the test connection of the shut-off valve ②, apply the pressure corresponding to the start of scale value to the pressure transmitter ①.
- 3. Check the start of scale value.
- 4. If the start of scale value differs from the value desired, correct it.
- 5. Close the shut-off valve for the test connection 4.
- 6. Open the shut-off valve 6 at the pressure tapping point.
- 7. Open the shut-off valve for the process 3.

9.3 gauge pressure, absolute pressure from the differential pressure series and absolute pressure from the gauge pressure series

9.3.2 Commissioning with steam or liquid



- Pressure transmitter
- Shut-off valve
- 3 Shut-off valve to process
- Shut-off valve for test connection or for bleed screw
- Pressure line
- 6 Shut-off valve
- O Blow-out valve
- 8 Compensation vessel (steam only)

Figure 9-1 Measuring steam

Requirement

All valves are closed.

Procedure

To commission the pressure transmitter for steam or liquid, proceed as follows:

- 1. Open the shut-off valve for the test connection 4.
- 2. Via the test connection of the shut-off valve ②, apply the pressure corresponding to the start of scale value to the pressure transmitter ①.
- 3. Check the start of scale value.
- 4. If the start of scale value differs from the value desired, correct it.
- 5. Close the shut-off valve for the test connection 4.

- 6. Open the shut-off valve 6 at the pressure tapping point.
- 7. Open the shut-off valve for the process 3.

9.4 Differential pressure and flow rate

9.4.1 Safety notes for commissioning with differential pressure and flow rate



Incorrect or improper operation

If the lock screws are missing or are not sufficiently tight, and/or if the valves are operated incorrectly or improperly, it could lead to serious physical injuries or considerable damage to property.


Measure

- Make sure the locking screw and/or the vent valve are screwed in and tightened.
- Ensure that the valves are operated correctly and properly.

9.4.2 Commissioning in gaseous environments

Usual arrangement

ent Special arrangement



- Pressure transmitter
- Stabilizing valve
- ③, ④ Differential pressure valves
- 5 Differential pressure lines

Pressure transmitter **above** the differential pressure transducer

- 6 Shut-off valves
- ⑦ Drain valves
- Condensate vessels (optional)
- Operation is a superation of the superation o

Pressure transmitter **below** the differential pressure transducer

Requirement

All shut-off valves are closed.


Procedure

To commission the pressure transmitter for gases, proceed as follows:


- 1. Open both the shut-off valves 6 at the pressure tapping point.
- 2. Open the stabilizing valve ②.
- 3. Open the differential pressure valve (③ or ④).
- 4. Check and, if necessary, correct the zero point when the start-of-scale value is 0 kPa (4 mA).
- 5. Close the stabilizing valve ②.
- 6. Open the other differential pressure valve (③ or ④).

9.4.3 Commissioning for liquids

Usual arrangement



Special arrangement



- Pressure transmitter
- Stabilizing valve
- (3), (4) Differential pressure valves
- (5) Differential pressure lines
- 6 Shut-off valves

Pressure transmitter **below** the differential pressure transducer

- ⑦ Drain valves
- (8) Gas collector vessels (optional)
- Differential pressure transducer
- Vent valves

Pressure transmitter **above** the differential pressure transducer

Requirement

All valves are closed.

Procedure

A DANGER

Toxic liquids

Danger of poisoning when the device is vented.

If toxic process media are measured with this device, toxic liquids can escape when the device is vented.


• Before venting, make sure there is no liquid in the device or take the necessary safety precautions.

To commission the pressure transmitter for liquids, proceed as follows:

- 1. Open both the shut-off valves 6 at the pressure tapping point.
- 2. Open the stabilizing valve 2.
- 3. With a pressure transmitter below the differential pressure transducer, open both blowout valves ⑦ one after the other until the air-free liquid escapes.

 In the case of a pressure transmitter above the differential pressure transducer, open both vent valves ⑩ one after the other until the air-free liquid escapes.
- 4. Close both drain valves (7) or vent valves (10).
- 5. Open the differential pressure valve ③ and the vent valve on the positive side of the pressure transmitter ① slightly, until fluid escapes without bubbles.
- 6. Close the vent valve.
- 7. Open the vent valve on the negative side of the pressure transmitter ① slightly, until fluid escapes without bubbles.
- 8. Close the differential pressure valve ③.
- 9. Open the differential pressure valve 4 until the liquid emerges and then close it.
- 10. Close the vent valve on the negative side of the pressure transmitter ①.
- 11. Open the differential pressure valve 3 by rotating it in ½ turn.
- 12. Check and, if necessary, correct the zero point (4 mA) when the start-of-scale value is 0 kPa.
- 13. Close the stabilizing valve ②.
- 14. Open the differential pressure valves (3 and 4) completely.

9.4.4 Commissioning with vapor



- Pressure transmitter
- Stabilizing valve
- ③, Differential pressure valves
- 4
- 5 Differential pressure lines
- 6 Shut-off valves
- Figure 9-2 Measuring steam

- ⑦ Drain valves
- 8 Condensate pots
- Differential pressure transducer/Orifice plate
- 1 Insulation

Requirement

All valves are closed.

Procedure



Hot vapor

Danger of injury or damage to device.

If the shut-off valves ⑥ and the differential pressure valve ③ are both open and the stabilizing valve ② is then opened, the pressure transmitter ① can be damaged by the flow of vapor.

Follow the specified procedure for commissioning.

AWARNING

Hot vapor

Danger of injury.

You can briefly open the drain valves ⑦ to clean the line. Hot vapor can escape in the process.

• Only open the drain valves ⑦ briefly, and close them again before vapor escapes.

To commission the pressure transmitter for vapor, proceed as follows:

- 1. Open both the shut-off valves 6 at the pressure tapping point.
- 2. Open the stabilizing valve ②.
- 3. Wait until the steam in the differential pressure lines ⑤ and in the equalizing vessels ⑧ has condensed.
- 4. Open the differential pressure valve ③ and the vent valve on the positive side of the pressure transmitter ① slightly, until air-free condensate escapes.
- 5. Close the vent valve.
- 6. Open the vent valve on the negative side of the pressure transmitter ① slightly, until condensate escapes without bubbles.
- 7. Close the differential pressure valve ③.
- 8. Open the differential pressure valve ④ slightly, until condensate escapes without bubbles, then close it.
- 9. Close the vent valve on the negative side ①.
- 10. Open the differential pressure valve 3 by rotating it in ½ turn.
- 11.Check and correct, if necessary, the zero point (4 mA) when the start of scale value is 0 kPa.

The result is only error-free if the differential pressure lines ⑤ have equally high condensate columns with the same temperature. The zero calibration must be repeated if required if these conditions are fulfilled.

- 12. Close the stabilizing valve 2.
- 13. Fully open the differential pressure valves 3 and 4.
- 14. You can briefly open the drain valves 7 to clean the line.
- 15. Close the drain valve ⑦ before vapor escapes.

9.4 Differential pressure and flow rate

Service and maintenance

10.1 Basic safety instructions



WARNING

Impermissible repair of explosion protected devices

Danger of explosion in areas subject to explosion hazard.

Repair must be carried out by Siemens authorized personnel only.



WARNING

Impermissible accessories and spare parts

Danger of explosion in areas subject to explosion hazard.

- Only use original accessories or original spare parts.
- Observe all relevant installation and safety instructions described in the instructions for the device or enclosed with the accessory or spare part.



⚠ WARNING

Use of incorrect device parts in potentially explosive environments

Devices and their associated device parts are either approved for different types of protection or they do not have explosion protection. There is a danger of explosion if device parts (such as covers) are used for devices with explosion protection that are not expressly suited for this type of protection. If you do not adhere to these guidelines, the test certificates and the manufacturer warranty will become null and void.

- Use only device parts that have been approved for the respective type of protection in the potentially explosive environment. Covers that are not suited for the "explosionproof" type of protection are identified as such by a notice label attached to the inside of the cover with "Not Ex d Not SIL".
- Do not swap device parts unless the manufacturer specifically ensures compatibility of these parts.

10.1 Basic safety instructions



Maintenance during continued operation in a hazardous area

There is a danger of explosion when carrying out repairs and maintenance on the device in a hazardous area.

- Isolate the device from power.
- or -
- Ensure that the atmosphere is explosion-free (hot work permit).



WARNING

Commissioning and operation with pending error

If an error message appears, correct operation in the process is no longer guaranteed.

- · Check the gravity of the error.
- · Correct the error.
- If the error still exists:
 - Take the device out of operation.
 - Prevent renewed commissioning.

See also

Display in case of a fault (Page 179)



WARNING

Hot, toxic or corrosive process media

Danger of injury during maintenance work.

When working on the process connection, hot, toxic or corrosive process media could be released.

- As long as the device is under pressure, do not loosen process connections and do not remove any parts that are pressurized.
- Before opening or removing the device ensure that process media cannot be released.



WARNING

Improper connection after maintenance

Danger of explosion in areas subject to explosion hazard.

- Connect the device correctly after maintenance.
- Close the device after maintenance work.

Refer to Chapter "Connecting (Page 61)".



Use of a computer in a hazardous area

If the interface to the computer is used in the hazardous area, there is a danger of explosion.

• Ensure that the atmosphere is explosion-free (hot work permit).



Releasing key lock

Improper modification of parameters could influence process safety.

 Make sure that only authorized personnel may cancel the key locking of devices for safety-related applications.



Hot surfaces

Danger of burns during maintenance work on parts having surface temperatures exceeding 70 °C (158 °F).

- Take corresponding protective measures, for example by wearing protective gloves.
- After carrying out maintenance, remount touch protection measures.

MARNING

Hazardous voltage with open device in versions with 4-conductor extension

Danger of electrocution when the enclosure is opened or enclosure parts are removed.

- Disconnect the device before you open the enclosure or remove enclosure parts.
- Observe the special precautionary measures if maintenance is required while the device is live. Have maintenance work carried out by qualified personnel.

NOTICE

Electrostatic-sensitive devices

The device contains electrostatic-sensitive devices (ESD). ESD can be destroyed by voltages far too low to be detected by humans. These voltages can occur if you simply touch a component part or the electrical connections of a module without being electrostatically discharged. The damage to a module caused by overvoltage cannot normally be detected immediately; it only becomes apparent after a longer period of operating time has elapsed.

Protective measures against the discharge of static electricity:

- Make sure that no power is applied.
- Before working with modules, make sure that you discharge static from your body, for example by touching a grounded object.
- Devices and tools used must be free of static charge.
- Hold modules only by their edges.
- Do not touch connector pins or conductor tracks on a module with the ESD notice.

10.2 Maintenance and repair work

10.2.1 Defining the maintenance interval



WARNING

No maintenance interval has been defined

Device failure, device damage, and risk of injury.

- Define a maintenance interval for recurring tests depending on the use of the device and your own experience.
- The maintenance interval will vary from site to site depending on corrosion resistance.

10.2.2 Checking the gaskets

Inspect the seals at regular intervals

Note

Incorrect seal changes

Incorrect measured values will be displayed. Changing the seals in a process flange of a differential pressure measuring cell can alter the start-of-scale value.

 Changing seals in devices with differential pressure measuring cells may only be carried out by personnel authorized by Siemens.

Note

Using the wrong seals

Using the wrong seals with flush-mounted process connections can cause measuring errors and/or damage the diaphragm.

- Always use seals which comply with the process connection standards or are recommended by Siemens.
- 1. Clean the enclosure and seals.
- 2. Check the enclosure and seals for cracks and damage.
- 3. Grease the seals if necessary.
 - or -
- 4. Replace the seals.

10.2.3 Display in case of a fault

Check the start of scale value of the device from time to time.

10.2 Maintenance and repair work

Differentiate between the following in case of a fault:

 The internal self test has detected a fault, e.g. sensor break, hardware fault/Firmware fault.

Displays:

- Display: "ERROR" display and ticker with an error text
- Analog output: Factory setting: Failure current 3.6 or 22.8 mA

Or depending on the parameterization

- HART: detailed error breakdown for display in the HART communicator or SIMATIC PDM
- Grave hardware faults, the processor is not functioning.

Displays:

- Display: no defined display
- Analog output: failure current < 3.6 mA

In the event of a defect, you can replace the application electronics by following the warning notes and the provided operating instructions.

See also

Error display (Page 75)

10.2.4 Changing the measuring cell and application electronics

Related

Each of the individual components "Measuring cell" and "Electronics" has a non-volatile memory (EEPROM).

Measuring cell data (e.g.: measuring range, measuring cell material, oil filling) and user data of the application electronics (e.g.: downscaling, additional electrical damping) are located in the measuring cell EEPROM. User data is lost when the measuring cell is replaced. Application-specific data are not lost when the application electronics are changed.

You can backup user data before changing the measuring cell and reload it afterwards. Use an input device which supports the HART protocol. (e.g. HART communicator, PC with HART modem and HART software or PC with HART modem and PDM software). Factory settings will be used if user data is not backed up before the measuring cell is changed.

Technical developments enable advanced functions to be implemented in the firmware of the measuring cell or application electronics. Further technical developments are indicated by modified firmware statuses (FW). The firmware status does not affect whether the modules can be replaced. However, the scope of functions is limited to the function of existing components.

If a combination of certain firmware versions of measuring cell and application electronics is not possible for technical reasons, the device will identify this problem and go into "Fault current" mode. This information is provided via the HART interface.

10.3 Cleaning



WARNING

Dust layers above 5 mm

Danger of explosion in hazardous areas. Device may overheat due to dust build up.

· Remove dust layers in excess of 5 mm.

NOTICE

Penetration of moisture into the device

Device damage.

 Make sure when carrying out cleaning and maintenance work that no moisture penetrates the inside of the device.

Cleaning the enclosure

- Clean the outside of the enclosure and the display window using a cloth moistened with water or a mild detergent.
- Do not use aggressive cleaning agents or solvents. Plastic components or painted surfaces could be damaged.



WARNING

Electrostatic charge

Danger of explosion in hazardous areas if electrostatic charges develop, for example, when cleaning plastic surfaces with a dry cloth.

Prevent electrostatic charging in hazardous areas.

10.3.1 Servicing the remote seal measuring system

The remote seal measuring system usually does not need servicing.

If the mediums are contaminated, viscous or crystallized, it could be necessary to clean the diaphragm from time to time. Use only a suitable solvent to remove the deposits from the

10.3 Cleaning

diaphragm. Do not use corrosive cleaning agents. Prevent the diaphragm from getting damaged due to sharp-edged tools.

NOTICE

Improper cleaning of diaphragm

Device damage. The diaphragm can be damaged.

Do not use sharp or hard objects to clean the diaphragm.

10.4 Return procedure

Enclose the bill of lading, return document and decontamination certificate in a clear plastic pouch and attach it firmly to the outside of the packaging.

Required forms

- Delivery note
- Return goods delivery note (http://www.siemens.com/processinstrumentation/returngoodsnote)

with the following information:

- Product (item description)
- Number of returned devices/replacement parts
- Reason for returning the item(s)
- Decontamination declaration (http://www.siemens.com/sc/declarationofdecontamination)

With this declaration you warrant "that the device/replacement part has been carefully cleaned and is free of residues. The device/replacement part does not pose a hazard for humans and the environment."

If the returned device/replacement part has come into contact with poisonous, corrosive, flammable or water-contaminating substances, you must thoroughly clean and decontaminate the device/replacement part before returning it in order to ensure that all hollow areas are free from hazardous substances. Check the item after it has been cleaned.

Any devices/replacement parts returned without a decontamination declaration will be cleaned at your expense before further processing.

The forms can be found on the Internet as well as in the documentation which comes with the device.

10.5 Disposal



Devices identified by this symbol may not be disposed of in the municipal waste disposal services under observance of the Directive 2002/96/EC on waste electronic and electrical equipment (WEEE).

They can be returned to the supplier within the EC or to a locally approved disposal service. Observe the specific regulations valid in your country.

Note

Special disposal required

The device includes components that require special disposal.

 Dispose of the device properly and environmentally through a local waste disposal contractor. Technical data

11.1 Overview of technical data

Introduction

The following overview of technical data provides you with a quick and easy access to relevant data and characteristic numbers.

Remember that tables in part contain the data of the three communication types HART, PROFIBUS and FOUNDATIONTM Fieldbus. This data deviates in many cases. Therefore, adhere to the communication type used by you when using the technical data.

Contents of the chapter

- SITRANS P DS III input (Page 186)
- SITRANS P410 input (Page 192)
- Output (Page 194)
- Measuring accuracy of SITRANS P DS III (Page 195)
- Measuring accuracy of SITRANS P410 (Page 203)
- Operating conditions (Page 205)
- Construction (Page 209)
- Display, keyboard and auxiliary power (Page 214)
- Certificates and approvals (Page 216)
- HART communication (Page 217)

11.2 SITRANS P DS III input

Gauge pressure input			
Measured variable	Gauge pressure		
Span continuously adjustable) or measuring range, max. operating pressure (in accord-	Span 1)	Maximum operating pressure MAWP (PS)	Maximum test pressure
ance with 97/23/EC Pressure Equipment	8.3 250 mbar	4 bar	6 bar
Directive) and max. test pressure (in accordance with DIN 16086) (for oxygen	0.83 25 kPa	400 kPa	0.6 MPa
measurement, max. 100 bar and 60 °C	0.12 3.6 psi	58 psi	87 psi
ambient temperature/process temperature	0.01 1 bar	4 bar	6 bar
)	1 100 kPa	400 kPa	0.6 MPa
	0.15 14.5 psi	58 psi	87 psi
	0.04 4 bar	7 bar	10 bar
	4 400 kPa	0.7 MPa	1 MPa
	0.58 58 psi	102 psi	145 psi
	0.16 16 bar	21 bar	32 bar
	16 1600 kPa	2.1 MPa	3.2 MPa
	2.3 232 psi	305 psi	464 psi
	0.63 63 bar	67 bar	100 bar
	63 6300 kPa	6.7 MPa	10 MPa
	9.1 914 psi	972 psi	1450 psi
	1.6 160 bar	167 bar	250 bar
	0.16 16 MPa	16.7 MPa	2.5 MPa
	23 2321 psi	2422 psi	3626 psi
	4 400 bar	400 bar	600 bar
	0.4 40 MPa	40 MPa	60 MPa
	58 5802 psi	5802 psi	8702 psi
	7 700 bar	800 bar	800 bar
	0.7 70 MPa	80 MPa	80 MPa
	102 10153 psi	11603 psi	11603 psi
Low measuring limit ²⁾			
Measuring cell with silicone oil filling	30 mbar a/3 kPa a/0.44 psi a		
Measuring cell with inert liquid	30 mbar a/3 kPa a/0.44 psi a		
Upper measuring limit	100 % of max. span (for oxygen measurement: max. 100 bar/10 MPa/1450 psi and 60 °C ambient temperature/process temperature)		
Start of scale value	Between the measuring limits (fully adjustable)		

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

With 250mbar/25 kPa/3.6 psi measuring cells, the lower measuring limit is 750 mbar a/75 kPa a/10.8 psi a. The measuring cell is vacuum-tight down to 30 mbar a/3 kPa a/0.44 psi a.

Measured variable	Gauge pressure		
Span (continuously adjustable) or measuring range, max. operating pressure and	Span 1)	Maximum operating pressure MAWP (PS)	Maximum test pressure
max. test pressure	0.01 1 bar	4 bar	6 bar
	1 100 kPa	400 kPa	0.6 MPa
	0.15 14.5 psi	58 psi	87 psi
	0.04 4 bar	7 bar	10 bar
	4 400 kPa	0.7 MPa	1 MPa
	0.58 58 psi	102 psi	145 psi
	0.16 16 bar	21 bar	32 bar
	0.06 1600 kPa	2.1 MPa	3.2 MPa
	2.3 232 psi	305 psi	464 psi
	0.6 63 bar	67 bar	100 bar
	0.06 6.3 MPa	6.7 MPa	10 MPa
	9.1 914 psi	972 psi	1450 psi
Lower measuring limit			
Measuring cell with silicone oil filling	100 mbar a/10 kPa a/1.45 psi a		
Measuring cell with inert liquid	100 mbar a/10 kPa a/1.45 psi a		
Measuring cell with neobee	100 mbar a/10 kPa a/1.45 psi a		
Upper measuring limit	100% of maximum span		

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

Absolute pressure input, with flush-mounted	diaphragm		
Measured variable	Absolute pressure		
Span (continuously adjustable) or measuring range, max. operating pressure and	Span 1)	Maximum operating pressure MAWP (PS)	Maximum test pressure
max. test pressure	43 1300 mbar a	2.6 bar a	10 bar a
	4.3 130 kPa a	260 kPa a	1 MPa a
	17 525 inH₂O a	37.7 psi a	145 psi a
	160 5000 mbar a	10 bar a	30 bar a
	16 500 kPa a	1 MPa a	3 MPa a
	2.32 72.5 psi a	145 psi a	435 psi a
	1 30 bar a	45 bar a	100 bar a
	0.1 3 MPa a	4.5 MPa	10 MPa a
	14.5 435 psi a	653 psi a	1450 psi a
	Depending on the proc	ess connection, the span m	ay differ from these values
Lower measuring limit	0 mbar a/kPa a/psi a		
Upper measuring limit	100% of maximum span		

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

Input pressure transmitter with PMC connection			
Measured variable	Gauge pressure		
Span (continuously adjustable) or measuring range, max. operating pressure and	Span ^{1) 2)}	Maximum operating pressure MAWP (PS)	Maximum test pressure
max. test pressure	0.01 1 bar	4 bar	6 bar
	1 100 kPa	400 kPa	600 kPa
	0.15 14.5 psi	58 psi	87 psi
	0.04 4 bar	7 bar	10 bar
	4 400 kPa	700 kPa	1 MPa
	0.58 58 psi	102 psi	145 psi
	0.16 16 bar	21 bar	32 bar
	0.016 1.6 MPa	2.1 MPa	3.2 MPa
	2.3 232 psi	305 psi	464 psi
Lower measuring limit			
Measuring cell with silicone oil filling ²⁾	100 mbar a/10 kPa a/1.45 psi a		
Measuring cell with inert liquid ²⁾	100 mbar a/10 kPa a/1.45 psi a		
Measuring cell with neobee ²⁾	100 mbar a/10 kPa a/1.45 psi a		
Upper measuring limit	100% of maximum span		

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

²⁾ For PMC-Style Minibolt, the span should not be less than 500 mbar

Absolute pressure input (from the gauge pressure series)			
Measured variable	Absolute pressure		
Span (continuously adjustable) or measuring range, maximum operating pressure (as per 97/23/EC pressure device guideline) and maximum test pressure (as per DIN 16086)	Span 1)	Maximum operating pressure MAWP (PS)	Maximum test pressure
	8.3 250 mbar a 0.83 25 kPa a 3 100 inH ₂ O a	1.5 bar a 150 kPa a 21.8 psi a	6 bar a 600 kPa a 87 psi a
	43 1300 mbar a 4.3 130 kPa a 17 525 inH ₂ O a	2.6 bar a 260 kPa a 37.7 psi a	10 bar a 1 MPa a 145 psi a
	160 5000 mbar a 16 500 kPa a 2.32 72.5 psi a	10 bar a 1 MPa a 145 psi a	30 bar a 3 MPa a 435 psi a
	1 30 bar a 0.1 3 MPa a 14.5 435 psi a	45 bar a 4.5 MPa a 653 psi a	100 bar a 10 MPa a 1450 psi a
Lower measuring limit	•	·	
Measuring cell with silicone oil filling	0 mbar a/kPa a/psi a		
Measuring cell with inert liquid			

Absolute pressure input (from the gauge pre	essure series)
for process temperature -20°C < ϑ \leq 60°C (-4°F < ϑ \leq +140°F)	30 mbar a/3 kPa a/0.44 psi a
for process temperature $60^{\circ}\text{C} < \vartheta \le 100^{\circ}\text{C}$ (max. 85°C for measuring cell 30 bar) ($140^{\circ}\text{F} < \vartheta \le 212^{\circ}\text{F}$ (max. 185°F for measuring cell 435 psi))	30 mbar a + 20 mbar a • (ϑ - 60 °C)/°C 3 kPa a + 2 kPa a • (ϑ - 60 °C)/°C 0.44 psi a + 0.29 psi a • (ϑ - 108 °F)/°F
Upper measuring limit	100 % of max. span (for oxygen measurement: max. 100 bar/10 MPa/1450 psi and 60 °C ambient temperature/process temperature)
Start of scale value	Between the measuring limits (fully adjustable)

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

Absolute pressure input (from the differentia	l pressure series)	
Measured variable	Absolute pressure	
Span (continuously adjustable) or measuring range and max. operating pressure (in accordance with 97/23/EC Pressure	Span 1)	Maximum operating pressure MAWP (PS)
	8.3 250 mbar a	32 bar a
Equipment Directive)	0.83 25 kPa a	3.2 MPa a
	3 100 inH ₂ O a	464 psi a
	43 1300 mbar a	32 bar a
	4.3 130 kPa a	3.2 MPa a
	17 525 inH₂O a	464 psi a
	160 5000 mbar a	32 bar a
	16 500 kPa a	3.2 MPa a
	2.32 72.5 psi a	464 psi a
	1 30 bar a	160 bar a
	0.1 3 MPa a	16 MPa a
	14.5 435 psi a	2320 psi a
	5.3 100 bar a	160 bar a
	0.5 10 MPa a	16 MPa a
	76.9 1450 psi a	2320 psi a
Lower measuring limit		
Measuring cell with silicone oil filling	0 mbar a /kPa a /psi a	
Measuring cell with inert liquid		
for process temperature $-20^{\circ}\text{C} < \vartheta$ $\leq 60^{\circ}\text{C} (-4^{\circ}\text{F} < \vartheta \leq +140^{\circ}\text{F})$	30 mbar a /3 kPa a /0.44 psi a	
for process temperature $60^{\circ}\text{C} < \vartheta \le 100^{\circ}\text{C}$ (max. 85°C for measuring cell 30 bar) (140°F < $\vartheta \le 212^{\circ}\text{F}$ (max. 185°F for measuring cell 435 psi))	30 mbar a + 20 mbar a • (ϑ - 60 °C)/°C 3 kPa a + 2 kPa a • (ϑ - 60 °C)/°C 0.44 psi a + 0.29 psi a • (ϑ - 108 °F)/°F	

11.2 SITRANS P DS III input

Absolute pressure input (from the differential pressure series)		
Upper measuring limit	100 % of max. span (for oxygen measurement: max. 100 bar/10 MPa/1450 psi and 60 °C ambient temperature/process temperature)	
Start of scale value	Between the measuring limits (fully adjustable)	

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

Differential pressure and flow rate input	D''' 11 10 10 10	
Measured variable	Differential pressure and flow rate	
Span (continuously adjustable) or measuring range and max. operating pressure (in	Span ¹⁾	Maximum operating pressure MAWP (PS)
accordance with 97/23/EC Pressure	1 20 mbar	32 bar
Equipment Directive)	0.1 2 kPa	3.2 MPa
	0.4015 8.031 inH ₂ O	464 psi
	1 60 mbar	160 bar
	0.1 6 kPa	16 MPa
	0.4015 24.09 inH ₂ O	2320 psi
	2.5 250 mbar	
	0.2 25 kPa	
	1.004 100.4 inH₂O	
	6 600 mbar	
	0.6 60 kPa	
	2.409 240.9 inH ₂ O	
	16 1600 mbar	
	1.6 160 kPa	
	6.424 642.4 inH ₂ O	
	50 5000 mbar	
	5 500 kPa	
	20.08 2008 inH ₂ O	
	0.3 30 bar	
	0.03 3 MPa	
	4.35 435 psi	
	2.5 250 mbar	420 bar
	0.25 25 kPa	42 MPa
	1.004 100.4 inH₂O	6091 psi
	6 600 mbar	
	0.6 60 kPa	
	2.409 240.9 inH ₂ O	
	16 1600 mbar	
	1.6 160 kPa	
	6.424 642.4 inH ₂ O	

Differential pressure and flow rate input	
	50 5000 mbar
	5 500 kPa
	20.08 2008 inH ₂ O
	0.3 30 bar
	0.03 3 MPa
	4.35 435 psi
Lower measuring limit	
Measuring cell with silicone oil filling	-100% of max. measuring range (-33 % for 30 bar /3 MPa /435 psi measuring cell) or 30 mbar a /3 kPa a /0.44 psi a
Measuring cell with inert liquid	
for process temperature -20°C < ϑ ≤ 60°C (-4°F < ϑ ≤ +140°F)	-100 % of max. measuring range (-33 % for 30 bar/3 MPa/435 psi measuring cell) or 30 mbar a/3 kPa a/0.44 psi a
for process temperature $60^{\circ}\text{C} < \vartheta \le 100^{\circ}\text{C}$ (max. 85°C for measuring cell 30 bar) ($140^{\circ}\text{F} < \vartheta \le 212^{\circ}\text{F}$	-100% of max. measuring range (-33% for 30 bar/3 kPa/435 psi measuring cell)
(max. 185°F for measuring cell	• 30 mbar a + 20 mbar a • (ϑ - 60 °C)/°C
435 psi))	3 kPa a + 2 kPa a • (ϑ - 60 °C)/°C
	0.44 psi a + 0.29 psi a • (ϑ - 108 °F)/°F
Upper measuring limit	100 % of max. span (for oxygen measurement: max. 100 bar/10 MPa/1450 psi and 60 °C ambient temperature/process temperature)
Start of scale value	Between the measuring limits (fully adjustable)

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

Level input		
Measured variable	Level	
Span (continuously adjustable) or measuring range and max. operating pressure (in	Span 1)	Maximum operating pressure MAWP (PS)
accordance with 97/23/EC Pressure	25 250 mbar	see the mounting flange
Equipment Directive)	2.5 25 kPa	
	10 100 inH ₂ O	<u></u>
	25 600 mbar	
	2.5 60 kPa	
	10 240 inH ₂ O	<u></u>
	53 1600 mbar	
	5.3 160 kPa	
	021 640 inH ₂ O	
	160 5000 mbar	
	16 500 kPa	
	2.32 72.5 psi	

11.3 SITRANS P410 input

Level input	
Lower measuring limit	
Measuring cell with silicone oil filling	-100% of max. measuring range or 30 mbar a/3 kPa a/0.44 psi a depending on the mounting flange
Measuring cell with inert liquid	-100% of max. measuring range or 30 mbar a/3 kPa a/0.44 psi a depending on the mounting flange
Upper measuring limit	100% of maximum span
Start of scale value	between the measuring limits continuously adjustable

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

11.3 SITRANS P410 input

Gauge pressure input Measured variable	Gauge pressure			
Span (continuously adjustable) or measuring range, max. operating pressure (in ac-	Span 1)	Maximum operating pressure MAWP (PS)	Maximum test pressure	
cordance with 97/23/EC Pressure	0.01 1 bar	4 bar	6 bar	
Equipment Directive) and max. test pressure (in accordance with DIN 16086).	1 100 kPa	400 kPa	0.6 MPa	
(iii doos danos iiiii 2 ii v 10000).	0.15 14.5 psi	58 psi	87 psi	
	0.04 4 bar	7 bar	10 bar	
	4 400 kPa	0.7 MPa	1 MPa	
	0.58 58 psi	102 psi	145 psi	
	0.16 16 bar	21 bar	32 bar	
	16 1600 kPa	2.1 MPa	3.2 MPa	
	2.3 232 psi	305 psi	464 psi	
	0.63 63 bar	67 bar	100 bar	
	63 6300 kPa	6.7 MPa	10 MPa	
	9.1 914 psi	972 psi	1450 psi	
	1.6 160 bar	167 bar	250 bar	
	0.16 16 MPa	16.7 MPa	2.5 MPa	
	23 2321 psi	2422 psi	3626 psi	
Lower measuring limit				
Measuring cell with silicone oil filling	30 mbar a/3 kPa a/0.	44 psi a		
Upper measuring limit	100% of maximum sp	oan		
Start of scale value	Between the measuring limits (fully adjustable)			

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

Measured variable	Differential pressure and flow rate		
Span (continuously adjustable) or measuring range and max. operating pressure (in accordance with 97/23/EC Pressure Equipment Directive)	Span 1)	Maximum operating pressure MAWF (PS)	
	2.5 250 mbar	160 bar	
	0.2 25 kPa	16 MPa	
	1.004 100.4 inH ₂ O	2320 psi	
	6 600 mbar		
	0.6 60 kPa		
	2.409 240.9 inH ₂ O	_	
	16 1600 mbar		
	1.6 160 kPa		
	6.424 642.4 inH ₂ O	_	
	50 5000 mbar		
	5 500 kPa		
	20.08 2008 inH ₂ O	_	
	0.3 30 bar		
	0.03 3 MPa		
	4.35 435 psi		
	6 600 mbar	420 bar	
	0.6 60 kPa	42 MPa	
	2.409 240.9 inH ₂ O	_ 6091 psi	
	16 1600 mbar		
	1.6 160 kPa		
	6.424 642.4 inH ₂ O	_	
	50 5000 mbar		
	5 500 kPa		
	20.08 2008 inH ₂ O	_	
	0.3 30 bar		
	0.03 3 MPa		
	4.35 435 psi		
_ower measuring limit			
Measuring cell with silicone oil filling	-100 % of max. measuring range (-33 % for 30 bar/3 MPa/435 psi me a/0.44 psi a	asuring cell) or 30 mbar a/3 kPa	
Upper measuring limit	100% of maximum span		
Start of scale value	Between the measuring limits (fully adjustable)		

¹⁾ Order the nominal measuring range with the order option Y01 for PROFIBUS PA or FOUNDATION Fieldbus.

11.4 Output

Output		
	HART	PROFIBUS PA and FOUNDATION Fieldbus
Output signal	4 20 mA	Digital PROFIBUS PA or FOUNDATION™ Fieldbus signal
Low saturation limit (fully adjusta- ble)	3.55 mA, set to 3.84 mA in the factory	-
High saturation limit (fully adjusta- ble)	23 mA, set to 20.5 mA or optionally 22.0 mA in the factory	-
Ripple (without HART communication)	$I_{SS} \le 0.5$ % of the max. output current	-
adjustable time constants damp- ing coefficient	0 100 s, continuously adjustable	0 100 s, continuously adjustable
Adjustable time constants (T63) with local operation	0 100 s, in steps of 0.1 s Factory-set to 2 s	0 100 s, in steps of 0.1 s Factory-set to 2 s
Current transmitter	3.55 23 mA	-
Failure signal	3.55 23 mA	-
Load	Resistor R [Ω]	-
Without HART communication	$R = \frac{U_{H} - 10,5 \text{ V}}{23 \text{ mA}}$	-
	U _H Power supply in V	
With HART communication		-
HART communicator (Handheld)	R =230 1100 Ω	
SIMATIC PDM	R =230 500 Ω	-
Characteristic curve	Linearly increasing or linearly decreasing	
	 Linear increase or decrease or root extraction increase (only for differential pressure and flow rate) 	
Bus physics		IEC 61158-2
Polarity-independent	_	Yes

Reference conditions	Rising characteristic curve			
	Start of scale value 0 bar/kPa/psi			
	Seal diaphragm stainless steel			
	 Measuring cell with si 	licone oil filling		
	Room temperature 25	5 °C (77 °F)		
Measuring span ratio r (spread, Turn- Down)	r = max. measuring span	/set measuring span and	nominal measuring range	
Conformity error at limit point setting, including hysteresis and repeatability				
Linear characteristic curve	r ≤ 1.25		1.25 < r ≤ 30	
250 mbar/25 kPa/3.6 psi	≤ 0.065%		≤ (0.008 • r + 0.055) %	
Linear characteristic curve	r≤5		5 < r ≤ 100	
1 bar/100 kPa/14.5 psi 4 bar/400 kPa/58 psi 16 bar/1.6 MPa/232 psi 63 bar/6.3 MPa/914 psi 160 bar/16 MPa/12321 psi	≤ 0.065%		≤ (0.004 • r + 0.045) %	
Linear characteristic curve	r ≤ 3	3 < r ≤ 10	10 < r ≤ 100	
400 bar/40 MPa/5802 psi 700 bar/70 MPa/10152 psi	≤ 0.075%	≤ (0.0029 • r + 0.071) %	≤ (0.005 • r + 0.05) %	
Effect of ambient temperature	In percent per 28 °C (50	°F)		
 250 mbar/25 kPa/3.6 psi 	≤ (0.16 • r + 0.1) %	• ,		
1 bar/100 kPa/14.5 psi	≤ (0.05 • r + 0.1) %			
 4 bar/400 kPa/58 psi 16 bar/1.6 MPa/232 psi 63 bar/6.3 MPa/914 psi 160 bar/16 MPa/2321 psi 400 bar/40 MPa/5802 psi 	≤ (0.025 • r + 0.125) %			
• 700 bar/70 MPa/10152 psi	≤ (0.08 • r + 0.16) %			
Long-term stability at ±30 °C (±54 °F)				
 250 mbar/25 kPa/3.6 psi 	Per year ≤ (0.25 • r) %			
• 1 bar/100 kPa/14.5 psi	In 5 years ≤ (0.25 • r) %			
4 bar/400 kPa/58 psi				
 16 bar/1.6 MPa/232 psi 63 bar/6.3 MPa/914 psi 160 bar/16 MPa/2321 psi 400 bar/40 MPa/5802 psi 	In 5 years ≤ (0.125 • r) %			

Measuring accuracy (as per EN 60770-1) gauge pressure		
• 700 bar/70 MPa/10152 psi	In 5 years ≤ (0.25 • r) %	
Step response time T ₆₃ (without electrical damping)	Approx. 0.15 s	
Effect of mounting position	≤ 0.05 mbar/0.005 kPa/0.000725 psi per 10° incline (zero-point correction is possible with position error compensation)	
Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V	
Measured value resolution for PROFIBUS PA or FOUNDATION Fieldbus	3 • 10 ⁻⁵ of the nominal measuring range	

Gauge pressure measuring accuracy, w	vith flush mounted diaphragm	
Reference conditions	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling Room temperature 25 °C (77 °F) 	
Measuring span ratio r (spread, Turn-Down)	r = max. measuring span/set measuring span and nominal measuring range	
Conformity error at limit point setting, including hysteresis and repeatability		
Linear characteristic curve		
r ≤ 5	≤ 0.075 %	
5 < r ≤ 100	≤ (0.005 • r + 0.05) %	
Effect of ambient temperature		
In percent per 28 °C (50 °F)	≤ (0.08 • r + 0.16)	
Effect of process temperature	In pressure per temperature change	
Temperature difference between medium temperature and ambient temperature	3 mbar per 10 K 0.3 kPa per 10 K 0.04 psi per 10 K	
Long-term stability at ±30 °C (±54 °F)	In 5 years ≤ (0.25 • r) %	
Step response time T ₆₃ without electrical damping	Approx. 0.2 s	
Effect of mounting position	In pressure per change of angle 0.4 mbar/0.04 kPa/0.006 psi per 10° incline (zero-point correction is possible with position error compensation)	
Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V	
Measured value resolution for PROFIBUS PA or FOUNDATION Fieldbus	3 • 10 ⁻⁵ of the nominal measuring range	

Absolute pressure measuring accuracy	with flush diaphragm		
Reference conditions	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling Room temperature 25 °C (77 °F) 		
Measuring span ratio r (spread, Turn-Down)	r = max. measuring span/set measuring span and nominal measuring range		
Conformity error at limit point setting, including hysteresis and repeatability			
Linear characteristic curve			
r ≤ 10	≤ 0.2%		
10 < r ≤ 30	≤ 0.4%		
Effect of ambient temperature			
In percent per 28 °C (50 °F)	≤ (0.16 • r + 0.24)		
Effect of process temperature	In pressure per temperature change		
 Temperature difference between medium temperature and ambient temperature 	3 mbar per 10 K 0.3 kPa per 10 K 0.04 psi per 10 K		
Long-term stability at ±30 °C (±54 °F)	In 5 years ≤ (0.25 • r) %		
Step response time T ₆₃ without electrical damping	Approx. 0.2 s		
Effect of mounting position	In pressure per change of angle 0.04 kPa/0.4 mbar/0.006 psi per 10° incline (zero-point correction is possible with position error compensation)		
Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V		
Measured-value resolution for PROFIBUS PA or	3 • 10 ⁻⁵ of the nominal measuring range		
FOUNDATION Fieldbus			

Measuring accuracy (according to EN experience conditions	Rising characteristic curve		
	Start of scale value 0 bar/kPa/psi		
	Seal diaphragm stainless steel		
	Measuring cell with silicone oil filling		
	 Room temperature 25 °C (77 °F) 		
Measuring span ratio r (spread, Turn- Down)	r = max. measuring span/set measuring span and nominal measuring range		
Conformity error at limit point setting, including hysteresis and repeatability			

Measuring accuracy (according to EN	60770-1) of pressure transmitter with PMC connection
Linear characteristic curve	
r ≤ 5	≤ 0.075 %
5 < r ≤ 100	≤ (0.005 • r + 0.05) %
Effect of ambient temperature	
In percent per 28 °C (50 °F)	≤ (0.08 • r + 0.16)
Effect of process temperature	In pressure per temperature change
Temperature difference between	3 mbar per 10 K
medium temperature and ambient	0.3 kPa per 10 K
temperature	0.04 psi per 10 K
Long-term stability at ±30 °C (±54 °F)	In 5 years ≤ (0.25 • r) %
Step response time T ₆₃ without electrical damping	Approx. 0.2 s
Effect of mounting position	In pressure per change of angle ≤ 0.1 mbar/0.01 kPa/0.00145 psi per 10° incline (zero point correction is possible with position error compensation)
Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V
Measured-value resolution for PROFIBUS PA or	3 • 10 ⁻⁵ of the nominal measuring range
FOUNDATION Fieldbus	

Absolute pressure measuring accuracy (f	rom gauge and differential pressure series)
Reference conditions	Rising characteristic curve
	Start of scale value 0 bar/kPa/psi
	Seal diaphragm stainless steel
	Measuring cell with silicone oil filling
	Room temperature 25 °C (77 °F)
Measuring span ratio r (spread, Turn-Down)	r = max. measuring span/set measuring span and nominal measuring range
Conformity error at limit point setting, including hysteresis and repeatability	
Linear characteristic curve	
r ≤ 10	≤ 0.1%
10 < r ≤ 30	≤ 0.2%
Effect of ambient temperature	In percent per 28 °C (50 °F)
• 250 mbar/25 kPa/3.6 psi	$\leq (0.15 \cdot r + 0.1)$

 1300 mbar a/130 kPa a/18.8 	$8 \leq (0.08 \cdot r + 0.16)$
psi a	
5 bar a/500 kPa a/72.5 psi a	a
30 bar a/3000 kPa a/435 ps	si a
100 bar a/10 MPa a/1450.3	B psi a
160 bar a/16 MPa a/2321 ps	osi a
400 bar a/40 MPa a/5802 ps	osi a
700 bar a/70 MPa a/10152.6 psi a	6
Long-term stability at ±30 °C (±54 °	°F) In 5 years ≤ (0.25 • r) %
Step response time T ₆₃ without elect damping	ectrical Approx. 0.2 s
Effect of mounting position	In pressure per change of angle
	 for absolute pressure (from the gauge pressure series): ≤ 0.05 mbar/0.005 kPa/0.000725 psi per 10° incline
	 for absolute pressure (from the differential pressure series): 0.7 mbar/0.07 kPa/0.001015 psi per 10° incline
_	(zero-point correction is possible with position error compensation)
Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V
Measured value resolution for PROFIBUS PA or FOUNDATION Fieldbus	3 • 10 ⁻⁵ of the nominal measuring range
Differential pressure and flow rate r	
Differential pressure and flow rate r	Rising characteristic curve
	Rising characteristic curveStart of scale value 0 bar/kPa/psi
	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel
	Rising characteristic curveStart of scale value 0 bar/kPa/psi
	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling
Reference conditions Measuring span ratio r (spread, Turn-Down) Conformity error at limit point setting, including hysteresis and re-	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling Room temperature 25 °C (77 °F)
Reference conditions Measuring span ratio r (spread, Furn-Down) Conformity error at limit point seting, including hysteresis and re-	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling Room temperature 25 °C (77 °F)
Measuring span ratio r (spread, Turn-Down) Conformity error at limit point setting, including hysteresis and repeatability	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling Room temperature 25 °C (77 °F) r = max. measuring span/set measuring span and nominal measuring ran
Reference conditions Measuring span ratio r (spread, Turn-Down) Conformity error at limit point setting, including hysteresis and repeatability Linear characteristic curve	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling Room temperature 25 °C (77 °F) r = max. measuring span/set measuring span and nominal measuring ran r ≤ 5 f < r ≤ 10 f < r ≤ 20
Measuring span ratio r (spread, Turn-Down) Conformity error at limit point setting, including hysteresis and repeatability Linear characteristic curve 20 mbar/2 kPa/0.29 psi	 Rising characteristic curve Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling Room temperature 25 °C (77 °F) r = max. measuring span/set measuring span and nominal measuring ran r ≤ 5 5 < r ≤ 10 10 < r ≤ 20 ≤ 0.075 % ≤ (0.0029 • r + 0.071) % ≤ (0.0045 • r + 0.071) %

250 mbar/25 kPa/3.63 psi	≤ 0.065%		≤ (0.004 • r + 0.045) %
600 mbar/60 kPa/8.70 psi			
1600 mbar/160 kPa/23.21 psi			
5 bar/500 kPa/72.52 psi			
30 bar/3 MPa/435.11 psi			
Root extraction characteristic			
Flow > 50 %	r≤5	5 < r ≤ 10	10 < r ≤ 20
 20 mbar/2 kPa/0.29 psi 	≤ 0.075 %	≤ (0.0029 • r + 0.071) %	≤ (0.0045 • r + 0.071) %
Root extraction characteristic			
Flow > 50 %	r ≤ 5		5 < r ≤ 60
• 60 mbar/6 kPa/0.87 psi	≤ 0.15 %		≤ (0.005 • r + 0.05) %
Root extraction characteristic			
Flow > 50 %	r ≤ 5		5 < r ≤ 100
 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 p si 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi 	≤ 0.065%		≤ (0.004 • r + 0.045) %
Root extraction characteristic			
Flow 25 50%	r ≤ 5	5 < r ≤10	10 < r ≤ 20
 20 mbar/2 kPa/0.29 psi 	≤ 0.15 %	≤ (0.0058 • r + 0.142) %	≤ (0.009 • r + 0.142) %
Root extraction characteristic			
Flow 25 50%	r ≤ 5		5 < r ≤ 60
• 60 mbar/6 kPa/0.87 psi	≤ 0.075 %		≤ (0.01 • r + 0.1) %
Root extraction characteristic	r ≤ 5		5 < r ≤ 100
250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi	≤ 0.13%		≤ (0.008 • r + 0.9) %
ffect of ambient temperature	In percent per 28	°C (50 °F)	
20 mbar/2 kPa/0.29 psi	≤ (0.15 • r + 0.1) %		
60 mbar/6 kPa/0.87 psi	≤ (0.075 • r + 0.1)	%	
250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi	≤ (0.025 • r + 0.12	25) %	

Differential pressure and flow rate Effect of static pressure	
At the start of scale value	
20 mbar/2 kPa/0.29 psi	≤ (0.15 • r) % per 32 bar (zero-point correction is possible with position error compensation)
60 mbar/6 kPa/0.87 psi 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi	≤ (0.1 • r) % per 70 bar (zero-point correction is possible with position error compensation)
5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi	≤ (0.2 • r) % per 70 bar (zero-point correction is possible with position error compensation)
On the measuring span	
20 mbar/2 kPa/0.29 psi	≤ 0.2% per 32 bar
60 mbar/6 kPa/0.87 psi 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi	≤ 0.14 % per 70 bar
_ong-term stability at ±30 °C ±54 °F)	Static pressure max. 70 bar/7 MPa/1015 psi
20 mbar/2 kPa/0.29 psi	Per year ≤ (0.2 • r) %
60 mbar/6 kPa/0.87 psi 30 bar/3 MPa/435.11 psi	In 5 years ≤ (0.25 • r) %
 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 	In 5 years ≤ (0.125 • r) %
Step response time T ₆₃ without electrical damping	
20 mbar/2 kPa/0.29 psi	Approx. 0.3 s
60 mbar/6 kPa/0.87 psi	
 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi 	Approx. 0.2 s
Effect of mounting position	In pressure per change of angle
	≤ 0.7 mbar/0.07 kPa/0.028 inH ₂ O per 10° incline
Effect of auxiliary power supply	(zero-point correction is possible with position error compensation) In percent per change in voltage 0.005 % per 1 V
Measured-value resolution for PROFIBUS PA or	3 • 10 ⁻⁵ of the nominal measuring range
FOUNDATION Fieldbus	

Level measuring accuracy				
Reference conditions	•	acteristic curve		
	Start of scale value 0 bar/kPa/psi			
	-	agm stainless steel		
	_	cell with silicone oil fi	_	
	·	erature 25 °C (77 °F	•	
Measuring span ratio r (spread, Turn-Down)	r = max. meası	uring span/set measu	ıring span and nomin	al measuring range
Conformity error at limit point setting, including hysteresis and repeatability				
Linear characteristic curve	r ≤ 5	5 < r ≤ 10	5 < r ≤ 25	5 < r ≤ 30
250 mbar/25 kPa/3.63 psi	≤ 0.125%	≤ (0.007 • r + 0.0 %	09)	
600 mbar/60 kPa/8.70 psi	≤ 0.125%		≤ (0.007 • r + 0.09) %	
1600 mbar/160 kPa/23.21 psi	≤ 0.125%			≤ (0.007 • r + 0.09) %
5 bar/500 kPa/72.52 psi	≤ 0.125%			≤ (0.007 • r + 0.09) %
Effect of ambient temperature	In percent per 2	28 °C (50 °F)		
 250 mbar/25 kPa/3.63 psi 	≤ (0.4 • r + 0.16	6) %		
• 600 mbar/60 kPa/8.70 psi	≤ (0.24 • r + 0.1	16) %		
• 1600 mbar/160 kPa/23.21 psi	≤ (0.2 • r + 0.16	6) %		
5 bar/500 kPa/72.52 psi				
Effect of static pressure				
At the start of scale value				
Measuring cell 250 mbar/25 kPa/3.63 psi	≤ (0.3 • r) % pe	r nominal pressure		
Measuring cell 600 mbar/60 kPa/8.70 psi	≤ (0.15 • r) % p	er nominal pressure		
Measuring cell 1600 mbar/160 kPa/23.21 psi	≤ (0.1 • r) % pe	r nominal pressure		
Measuring cell 5 bar/500 kPa/72.52 psi				
On the measuring span	≤ (0.1 • r) % pe	r nominal pressure		
Long-term stability at ±30 °C (±54 °F)	in 5 years ≤ (0. static pressure	25 • r) % max. 70 bar/7 MPa/	1015 psi	
Step response time T ₆₃ without electrical damping	Approx. 0.2 s			
Effect of mounting position	depending on t	he fill fluid in the mou	ınting flange	

Level measuring accuracy	
Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V
Measured value resolution for PROFIBUS PA or FOUNDATION Fieldbus	3 • 10 ⁻⁵ of the nominal measuring range

11.6 Measuring accuracy of SITRANS P410

Measuring accuracy (as per EN 60770 Reference conditions			
Reference conditions	Rising characteristic curve		
	 Start of scale value 0 bar/kPa/psi Seal diaphragm stainless steel Measuring cell with silicone oil filling 		
	Measuring span ratio r (spread, Turn- Down)	r = max. measuring span/set measuring span and nominal measuring range	
Conformity error at limit point setting, including hysteresis and repeatability			
Linear characteristic curve	r ≤ 5	5 < r ≤ 100	
1 bar/100 kPa/14.5 psi	≤ 0.04%	≤ (0.004 • r + 0.045) %	
4 bar400 kPa/58 psi			
16 bar/1.6 MPa/232 psi			
63 bar/6.3 MPa/914 psi			
160 bar/16 MPa/2321 psi			
Effect of ambient temperature	In percent per 28 °C (50 °F)		
 1 bar/100 kPa/14.5 psi 	≤ (0.05 • r + 0.1) %		
 4 bar/400 kPa/58 psi 	≤ (0.025 • r + 0.125) %		
16 bar/1.6 MPa/232 psi			
63 bar/6.3 MPa/914 psi			
160 bar/16 MPa/2321 psi			
Long-term stability at ±30 °C (±54 °F)			
• 1 bar/100 kPa/14.5 psi	In 5 years ≤ (0.25 • r) %		
4 bar/400 kPa/58 psi			
 16 bar/1.6 MPa/232 psi 63 bar/6.3 MPa/914 psi 160 bar/16 MPa/2321 psi 	In 5 years ≤ (0.125 • r) %		
Step response time T_{63} (without electrical damping)	Approx. 0.15 s		
Effect of mounting position	≤ 0.05 mbar/0.005 kPa/0.02 inH ₂ O per 10° i (zero point correction is possible with position		

11.6 Measuring accuracy of SITRANS P410

Measuring accuracy (as per EN 607 Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V	}
Measured value resolution for PROFIBUS PA or FOUNDATION Fieldbus	3 • 10 ⁻⁵ of the nominal measuring	g range
Differential pressure and flow rate n	neasuring accuracy	
Reference conditions	Rising characteristic curve	
	Start of scale value 0 bar/kPa/p	osi
	 Seal diaphragm stainless steel 	
	Measuring cell with silicone oil	filling
	 Room temperature 25 °C (77 ° 	F)
Measuring span ratio r (spread, Turn-Down)	r = max. measuring span/set meas	suring span and nominal measuring range
Conformity error at limit point set- ting, including hysteresis and re- peatability		
Linear characteristic curve	r≤5	5 < r ≤ 100
250 mbar/25 kPa/3.63 psi	≤ 0.04%	≤ (0.004 • r + 0.045) %
600 mbar/60 kPa/8.70 psi		
1600 mbar/160 kPa/23.21 psi		
5 bar/500 kPa/72.52 psi		
30 bar/3 MPa/435.11 psi		
Root extraction characteristic		
Flow > 50 %	r≤5	5 < r ≤ 30
250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi	≤ 0.04%	≤ (0.004 • r + 0.045) %

Flow 25 50%	r≤5	5 < r ≤ 30
250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi	≤ 0.08%	≤ (0.008 • r + 0.09) %
Effect of ambient temperature	In percent per 28 °C (50 °F)	
 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi 	≤ (0.025 • r + 0.125) %	

5 bar/500 kPa/72.52 psi

Differential pressure and flow rate n	neasuring accuracy
Effect of static pressure	
At the start of scale value	
250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi	\leq (0.1 • r) % per 70 bar (zero-point correction is possible with position error compensation)
5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi	$\leq (0.2 \ {\mbox{\circ}}\ r)$ % per 70 bar (zero-point correction is possible with position error compensation)
On the measuring span	
250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi	≤ 0.14 % per 70 bar
Long-term stability at ±30 °C (±54 °F)	Static pressure max. 70 bar/7 MPa/1015 psi
 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 	In 5 years ≤ (0.125 • r) %
• 30 bar/3 MPa/435.11 psi	In 5 years ≤ (0.25 • r) %
Step response time T ₆₃ without electrical damping	
 250 mbar/25 kPa/3.63 psi 600 mbar/60 kPa/8.70 psi 1600 mbar/160 kPa/23.21 psi 5 bar/500 kPa/72.52 psi 30 bar/3 MPa/435.11 psi 	Approx. 0.2 s
Effect of mounting position	In pressure per change of angle ≤ 0.7 mbar/0.07 kPa/0.001015 psi per 10° incline (zero-point correction is possible with position error compensation)
Effect of auxiliary power supply	In percent per change in voltage 0.005 % per 1 V
Measured value resolution for PROFIBUS PA or FOUNDATION Fieldbus	3 • 10 ⁻⁵ of the nominal measuring range

11.7 Operating conditions

Rated conditions for gauge pressure and absolute pressure (from the gauge pressure series)		
Installation conditions		
Ambient conditions		

11.7 Operating conditions

Ambient temperature	
Note	Observe the temperature class in hazardous areas.
Measuring cell with silicone oil filling	-40 +85 °C (-40 +185 °F)
Measuring cell with inert liquid	-20 +85 °C (-4 +185 °F)
Measuring cell with inert filling liquid for relative pressure measuring cells 1, 4, 16 and 63 bar	-40 +85°C (-40+185°F)
Display	-30 +85 °C (-22 +185 °F)
Storage temperature	-50 +85 °C (-58 +185 °F)
Climate class	
Condensation	Permitted
 Degree of protection in accordance with EN 60529 	IP66, IP68
Degree of protection in accord- ance with NEMA 250	NEMA 4X
Electromagnetic compatibility	
Interference emission and inter- ference immunity	In accordance with EN 61326 and NAMUR NE 21
Process medium conditions	
 Process temperature 	
Measuring cell with silicone oil filling	-40 +100 °C (-40 +212 °F)
Measuring cell with inert liquid	-20 +100 °C (-4 +212 °F)
With extension to Zone 0	-20 +60 °C (-4 +140 °F)
Conditions of use for gauge pressure	and absolute pressure with flush-mounted diaphragm
Installation conditions	and asserting in
Ambient temperature	
Note	Observe the temperature class in hazardous areas.
Measuring cell with silicone oil filling	-40 +85 °C (-40 +185 °F)
Measuring cell with inert liquid	-20 +85 °C (-4 +185 °F)
 Measuring cell with Neobee (FDA-compliant) 	-10 +85 °C (14 185 °F)
• Display	-30 +85 °C (-22 +185 °F)
	-50 +85 °C (-58 +185 °F)

Conditions of use for gauge pressure	and absolute pressure with flush-mounted diaphragm
Climate class	
Condensation	Permitted
Degree of protection in accord- ance with EN 60 529	IP66, IP68
Degree of protection in accord- ance with NEMA 250	NEMA 4X
Electromagnetic compatibility	
Interference emission and inter- ference immunity	In accordance with EN 61326 and NAMUR NE 21
Process medium conditions	
Process temperature ¹⁾	
Measuring cell with silicone oil filling	-40 +150°C (-40 +302 °F) -40 +200°C (-40 +392 °F) with cooling extension
Measuring cell with inert liquid	-20 +100 °C (-4 +212 °F) -20 +200°C (-4 +392 °F) with cooling extension
Measuring cell with Neobee (FDA-compliant)	-10 +150°C (14 302 °F) -10 +200°C (14 392 °F) with cooling extension
Measuring cell with high- temperature oil filling	-10 +250 °C (14 482 °F) with cooling extension

¹⁾ Observe the temperature limits in the process connection standards (e.g. DIN 32676 and DIN 11851) for the maximum process temperature for flush-mounted process connections.

Conditions of use for pressure transm	nitter with PMC connection
Installation conditions	
Ambient temperature	
Note	Observe the temperature class in hazardous areas.
Measuring cell with silicone oil filling	-40 +85 °C (-40 +185 °F)
• Display	-30 +85 °C (-22 +185 °F)
Storage temperature	-50 +85 °C (-58 +185 °F)
Climate class	
Condensation	Permitted
Degree of protection in accord- ance with EN 60529	IP66, IP68
Degree of protection in accord- ance with NEMA 250	NEMA 4X
Electromagnetic compatibility	
Interference emission and inter- ference immunity	In accordance with EN 61326 and NAMUR NE 21

11.7 Operating conditions

Conditions of use for pressure transr	nitter with PMC connection
Process medium conditions	
Process temperature	-40 +100 °C (-40 +212 °F)
	re (from the differential pressure series), differential pressure and flow rate
Installation conditions	
Installation instruction	any
Ambient conditions	
Ambient temperature	
Note	Observe the temperature class in hazardous areas.
Measuring cell with silicone oil filling	-40 +85 °C (-40 +185 °F)
Measuring cell	• -20 +85 °C (-4 +185 °F)
30 bar (435 psi)	• For flow: -20 +85 °C (-4 +185 °F)
Measuring cell with inert liquid	-20 +85 °C (-4 +185 °F)
Display	-30 +85 °C (-22 +185 °F)
Storage temperature	-50 +85 °C (-58 +185 °F)
Climate class	
Condensation	Permitted
Degree of protection in accord- ance with EN 60529	IP66, IP68
Degree of protection in accord- ance with NEMA 250	NEMA 4X
Electromagnetic compatibility	
Interference emission and inter- ference immunity	In accordance with EN 61326 and NAMUR NE 21
Process medium conditions	
Process temperature	
Measuring cell with silicone oil filling	-40 +100 °C (-40 +212 °F)
Measuring cell 30 bar (435 psi)	-20 +85 °C (-4 +185 °F)
Measuring cell with inert liquid	-20 +100 °C (-4 +212 °F)
Measuring cell 30 bar (435 psi)	-20 +85 °C (-4 +185 °F)
In conjunction with dust explosion protection	-20 +60°C (-4 +140°F)

Rated conditions for level	
Installation conditions	
Installation instruction	specified through the flange
Ambient conditions	
Ambient temperature	
Note	Observe the allocation of the max. permissible operating temperature to the max. permissible operating pressure of the relevant flange connection.
Measuring cell with silicone oil filling	-40 +85 °C (-40 +185 °F)
Display	-30 +85 °C (-22 +185 °F)
Storage temperature	-50 +85 °C (-58 +185 °F)
Climate class	
Condensation	Permitted
 Degree of protection in accordance with EN 60529 	IP66
Degree of protection in accord- ance with NEMA 250	NEMA 4X
Electromagnetic compatibility	
Interference emission and inter- ference immunity	In accordance with EN 61326 and NAMUR NE 21
Process medium conditions	
 Process temperature 	
Measuring cell with silicone oil	Plus side: See mounting flange
filling	• Low-pressure side: -40 +100 °C (-40 +212 °F)

11.8 Construction

Weight	Approx. 1.5 kg (3.3 lb) for aluminum enclosure		
Material			
Wetted parts materials			
Process connection	Stainless steel, mat. no. 1.4404/316L or Hastelloy C4, mat. no. 2.4610		
Oval flange	Stainless steel, mat. no. 1.4404/316L		
Seal diaphragm	Stainless steel, material no. 1.4404/316L or Hastelloy C276, material no. 2.4819		

Construction for gauge pressure and	absolute pressure (from	the gauge pressure series)	
Electronics housing	 Copper-free die cast aluminum GD-AlSi 12 or stainless steel precision casting, mat. no. 1.4408 		
		coating with polyurethane pat 1: epoxy-based; coat 2: p	polyurethane
	Stainless steel nan	neplate	
Mounting bracket	Steel or stainless stee	I	
Measuring cell filling	Silicone oil		
	 Neobee M20 		
	Inert liquid		
	(max. 120 bar g (2320 psi g) for oxygen measurement)		
Process connection	$G^{1}/_{2}B$ connection pin in accordance with DIN EN 837-1; female thread $^{1}/_{2}$ -14 NPT or oval flange (PN 160 (MAWP 2320 psi g)) with M10 fastening screw thread in accordance with DIN 19213 or $^{7}/_{16}$ -20 UNF in accordance with EN 61518. Male thread M20 x 1.5 and $^{1}/_{2}$ -14 NPT		
Electrical connection	Cable inlet using the fo	ollowing cable glands:	
	• Pg 13.5		
	 M20 x 1.5 and ½-14 NPT or Han 7D/Han 8D connector¹⁾ 		
		r: 6 to 12 mm; types of protectable cable gland for smaller	ction "nA" and "ic" (Zone 2): 8 to diameters
	M12 connector		
Torque for cable gland nut made of	Plastic	Metal	Stainless steel
	2.5 Nm (1.8 ft lb)	4.2 Nm (3.1 ft lb)	4.2 Nm (3.1 ft lb)
Degree of protection for Han and M12 connectors	IP65		

¹⁾ Han 8D is identical to Han 8U.

	Construction for gauge pressure, with flush mounted diaphragm				
W	/eight	Approx 1.5 13.5 kg (3.3 30 lb) with aluminum enclosure			
M	aterial				
•	Wetted parts materials				
	Process connection	Stainless steel, mat. no. 1.4404/316L			
	Seal diaphragm	Stainless steel, mat. no. 1.4404/316L			
•	Non-wetted parts materials				
	Electronics housing	 Non-copper aluminum die casting GD-AlSi 12 or stainless steel precision casting, mat. no. 1.4408 			
		 Standard: Powder coating with polyurethane Option: 2 coats: Coat 1: epoxy-based; coat 2: polyurethane 			
		Stainless steel nameplate			
	Mounting bracket	Steel or stainless steel			

Construction for gauge pressure, with flush mounted diaphragm			
Measuring cell filling	Silicone oil		
	 Neobee M20 		
	 Inert liquid 		
Process connection	Flanges as per EN a	and ASME	
	F&B and Pharma fla	ange, clamp and threaded c	onnectors
	NEUMO BioConnect	ct/BioControl	
	PMC connections for	or the paper industry	
Electrical connection	Cable inlet using the following cable glands:		
	• Pg 13.5		
	 M20x1.5 		
	• ½-14 NPT		
	Han 7D/Han 8D plu	g ¹⁾	
	 M12 connector 		
Torque for cable gland nut made of	Plastic	Metal	Stainless steel
	2.5 Nm (1.8 ft lb)	4.2 Nm (3.1 ft lb)	4.2 Nm (3.1 ft lb)
Degree of protection for Han and M12 connectors	IP65		

¹⁾ Han 8D is identical to Han 8U.

Construction of pressure transmitter with PMC connection			
Weight	Approx. 1.5 kg (3.3 lb) for aluminum enclosure		
Material			
Wetted parts materials			
Gasket (standard)	PTFE flat gasket		
O-ring (minibolt)	FPM (Viton)		
	FFPM or NBR (optional)		
Seal diaphragm	Hastelloy C276, mat. No. 2.4819		
Non-wetted parts materials			
Electronics housing	 Non-copper aluminum die casting GD-AlSi 12 or stainless steel precision casting, mat. no. 1.4408 		
	Standard: Powder coating with polyurethane		
	Option: 2 coats: Coat 1: epoxy-based; coat 2: polyurethane		
	Stainless steel nameplate		
Mounting bracket	Steel or stainless steel		
Measuring cell filling	Silicone oil		
	Inert liquid		
Process connection			

11.8 Construction

Construction of pressure transmitter	with PMC connection			
Standard	Flush mounted			
	• 1 ¹ / ₂ "			
	PMC Standard des	sign		
Minibolt	Flush mounted			
	• 1"			
	PMC Minibolt designation	gn		
Electrical connection	Cable inlet using the following cable glands:			
	• Pg 13.5			
	• M20 x 1.5			
	• ½-14 NPT			
	Han 7D/Han 8D plug¹)			
	M12 connector			
Torque for cable gland nut made of	Plastic	Metal	Stainless steel	
	2.5 Nm (1.8 ft lb)	4.2 Nm (3.1 ft lb)	4.2 Nm (3.1 ft lb)	
Degree of protection for Han and M12 connectors	IP65			

¹⁾ Han 8D is identical to Han 8U.

Weight Material		Approx. 4.5 kg (9.9 lb) for aluminum enclosure		
•	Wetted parts materials			
	Seal diaphragm	Stainless steel, mat. no. 1.4404/316L, Hastelloy C276, mat. no. 2.4819, Monel, mat. no. 2.4360, tantalum or gold		
	Pressure caps and locking screw	Stainless steel, mat. no. 1.4408 to PN 160, mat. no. 1.4571/316Ti for PN 420, Hastelloy C4, 2.4610 or Monel, mat. no. 2.4360		
	O-ring	FPM (Viton) or optionally: PTFE, FEP, FEPM and NBR		
•	Non-wetted parts materials			
	Electronics housing	Non-copper aluminum die casting GD-AlSi 12 or stainless steel precision cast ing, mat. no. 1.4408		
		 Standard: Powder coating with polyurethane Option: 2 coats: Coat 1: epoxy-based; coat 2: polyurethane 		
		Stainless steel nameplate		
	Pressure cap screws	Stainless steel		
	Mounting bracket	Steel or stainless steel		
Measuring cell filling		Silicone oil		
		Neobee M20		
		Inert liquid		
		(max. 120 bar g (2320 psi g) for oxygen measurement)		

Design for absolute pressure (from the	ne differential pressure se	eries), differential pressure ar	nd flow rate
Process connection	¹ / ₄ -18 NPT female thread and flat connection with ⁷ / ₁₆ -20 UNF fastening screw thread in accordance with EN 61518 or M10 fastening screw thread in accordance with DIN 19213 (M12 for PN 420 (MAWP 6092 psi))		
Electrical connection	Screw terminals		
	Cable inlet using the following cable glands:		
	• Pg 13.5		
	• M20 x 1.5		
	• ½-14 NPT or Han 7D/Han 8D connector ¹⁾		
	 M12 connector 		
Torque for cable gland nut made of	Plastic	Metal	Stainless steel
	2.5 Nm (1.8 ft lb)	4.2 Nm (3.1 ft lb)	4.2 Nm (3.1 ft lb)
Degree of protection for Han and M12 connectors	IP65		

¹⁾ Han 8D is identical to Han 8U.

Co	onstruction for level			
W	eight			
•	as per EN (pressure transmitter with mounting flange, without tube)	approx 11 13 kg (24.2 28.7 lb)		
•	as per ASME (pressure transmitter with mounting flange, without tube)	approx 11 18 kg (24.2 39.7 lb)		
Ма	aterial			
•	Wetted parts materials			
	Plus side			
	Seal diaphragm on the mounting flange	Stainless steel, mat. no. 1.4404/316L, Monel 400, mat. no. 2.4360, Hastelloy B2, mat. no. 2.4617, Hastelloy C276, mat. no. 2.4819, Hastelloy C4, mat. no. 2.4610, tantalum, PTFE, ECTFE		
	Sealing surface	smooth as per EN 1092-1, form B1 or ASME B16.5 RF 125 250 AA for stainless steel 316L, EN 2092-1 form B2 or ASME B16.5 RFSF for the remaining materials		
	Sealing material in the pressure caps			
	for standard applications	Viton		
	for underpressure applica- tions on the mounting flange	Copper		
	Minus side			
	Seal diaphragm	Stainless steel, mat. no. 1.4404/316L		
	Pressure caps and locking screws	Stainless steel, mat. no. 1.4408		

11.9 Display, keyboard and auxiliary power

Construction for level			
O-ring	FPM (Viton)		
Non-wetted parts materials			
Electronics housing	 Non-copper aluminum die casting GD-AlSi 12 or stainless steel precision casting, mat. no. 1.4408 		
		coating with polyurethane pat 1: epoxy-based; coat 2: p	polyurethane
	Stainless steel nar	neplate	
Pressure cap screws	Stainless steel		
Measuring cell filling	Silicone oil		
Mounting flange fill fluid	Silicon oil or a differen	t design	
Process connection			
Plus side	Flange as per EN and	ASME	
Minus side	¹ / ₄ -18 NPT female thread and flat connection with M10 fastening screw thread in accordance with DIN 19213 (M12 for PN 420 (MAWP 6092 psi)) or ⁷ / ₁₆ -20 UNF in accordance with EN 61518		
Electrical connection	Screw terminals		
	Cable inlet using the following cable glands:		
	• Pg 13.5		
	• M20 x 1.5		
	• ½-14 NPT or Han	7D/Han 8D connector ¹⁾	
	 M12 connector 		
Torque for cable gland nut made of	Plastic	Metal	Stainless steel
	2.5 Nm (1.8 ft lb)	4.2 Nm (3.1 ft lb)	4.2 Nm (3.1 ft lb)
Degree of protection for Han and M12 connectors	IP65		

¹⁾ Han 8D is identical to Han 8U.

11.9 Display, keyboard and auxiliary power

Display and user interface		
Keys	3 for on-site programming directly at the device	
Display	With or without integrated display (optional)	
	 Cover with inspection window (optional) 	

Auxiliary power U _H		
	HART	PROFIBUS PA or Foundation Fieldbus
Terminal voltage on pressure transmitter	• DC 10.5 V 45 V	-
	In the case of intrinsically safe operation 10.5 V 30 V DC	
Ripple	U _{SS} ≤ 0.2 V (47 125 Hz)	_
Noise	U _{eff} ≤ 1.2 mV (0.5 10 kHz)	-
Auxiliary power	- -	Bus-powered
Separate supply voltage	- -	Not necessary
Bus voltage		
• Not (£x)	-	9 32 V
For intrinsically safe operation	-	9 24 V
Current consumption		
Max. basic current	-	12.5 mA
Starting current ≤ basic current	-	Yes
Max. current in event of fault	-	15.5 mA
Error shut-down electronics (FDE) present	-	Yes

11.10 Certificates and approvals

•	HART	PROFIBUS PA and FOUNDATION
	MAKI	Fieldbus
Classification according to Pressure Equipment Directive (PED 97/23/EC)	 for gases of Fluid Group 1 and liquids of Fluid Group 1; meets requirements of Article 3 Para. 3 (good engineering practice) only for flow rate: for gases of Fluid Group 1 and liquids of Fluid Group 1; fulfills the basic safety requirements as per article 3, Para 1 (appendix 1); classified as category III, module H conformity evaluation by TÜV Nord 	
Drinking water	Available soon (for SITRANS P DSIII)	
Explosion protection		
Intrinsic safety "i"		
Designation	(II 1/2 G Ex ia/ib IIC T4/T5/T6 Ga/Gb	
Permissible ambient temperature	-40 +85 °C (-40 +185 °F) temperature class T4 -40 +70 °C (-40 +158 °F) temperature class T5 -40 +60 °C (-40 +140 °F) temperature class T6	
Connection	To a certified intrinsically safe circuit with the max. values: $U_i = 30 \text{ V}, I_i = 100 \text{ mA},$	FISCO supply unit U_0 = 17.5 V, I_0 = 380 mA, P_0 = 5.32 W Linear barrier
	P_i = 750 mW, R_i = 300 Ω	U ₀ = 24 V, I ₀ = 174 mA, P ₀ = 1 W
Effective inner capacitance	C _i = 6 nF	C _i = 1.1 nF
Effective inner inductance	L _i = 0.4 mH	L _i = 7 μH
 Flameproof enclosure encapsulation "d" 		
Designation	(II 1/2 G Ex d IIC T4, T6 Ga/Gb	
Permissible ambient temperature	-40 +85 °C (-40 +185 °F) temperature class T4 -40 +60 °C (-40 +140 °F) temperature class T6	
Connection	To a circuit with the operating values: $U_H = 10.5 \dots 45 \text{ V DC}$	To a circuit with the operating values: $U_H = 9 \dots 32 \text{ V DC}$
 Dust explosion protection for Zone 20 and 20/21 		
Designation		
	(II 1/2 D Ex ta/tb IIIC T120°C Da/Db	
Permissible ambient temperature	-40 +85 °C (-40 +185 °F)	
max. surface temperature	120°C (248°F)	
Connection	To a certified intrinsically safe circuit with the max. values: U _i = 30 V, I _i = 100 mA,	FISCO supply unit $U_0 = 17.5 \text{ V}, I_0 = 380 \text{ mA}, P_0 = 5.32 \text{ W}$ Linear barrier
	$P_i = 750 \text{ mW}, R_i = 300 \Omega$	$U_0 = 24 \text{ V}, I_0 = 250 \text{ mA}, P_0 = 1.2 \text{ W}$
Effective inner capacitance	C _i = 6 nF	C _i = 1.1 nF
Effective inner inductance	L _i = 0.4 mH	L _i = 7 μH

C	ertificates and approvals				
		HART	PROFIBUS PA and FOUNDATION Fieldbus		
•	Dust explosion protection for Zone 22				
	Designation	(II 2 D Ex tb IIIC T120°C Db			
	Connection	To a circuit with the operating values: $U_H = 10.5 \dots 45 \text{ V DC}$; $P_{max} = 1.2 \text{ W}$	To a circuit with the operating values: $U_H = DC 9 \dots 32 V$; $P_{max} = 1.2 W$		
•	Type of protection "n" (Zone 2)				
	Designation	(II 2/3 G Ex nA IIC T4/T5/T6 Gc			
	Connection "nA"	U _n = 45 V	U _m = 32 V		
	Connection "ic"	To a circuit with the operating values: $U_i = 45 \text{ V}$	FISCO supply unit U _O =17.5 V, I _O = 570 mA Linear barrier		
	Effective inner capacitance	C _i = 6 nF	$U_0 = 32 \text{ V}, I_0 = 132 \text{ mA}, P_0 = 1 \text{ W}$ $C_i = 1.1 \text{ nF}$		
	Effective inner capacitance	L _i = 0.4 mH	L _i = 7 μH		
•	Explosion protection in accordance with FM	Certificate of Compliance 3008490	Σ, - 7 μπ		
Designation (XP/DIP) or IS; NI; S CL I, DIV 1, GP ABCD T4 T6; CL II, DIV 1, GP EFG IIC T4 T6; CL I, DIV 2, GP ABCD T4 T6; CL II, DIV					
	Permissible ambient temperature	T _{amb} = T4: -40 +85 °C (-40 +185 °F) T _{amb} = T5: -40 +70 °C (-40 +158 °F) T _{amb} = T6: -40 +60 °C (-40 +140 °F)			
•	Explosion protection as per CSA	Certificate of Compliance 1153651			
	Designation (XP/DIP) or (IS)	CL I, DIV 1, GP ABCD T4 T6; CL II, CL I, DIV 2, GP ABCD T4 T6; CL II,	DIV 1, GP EFG; CL III; Ex ia IIC T4 T6: DIV 2, GP FG; CL III		
	Permissible ambient temperature	T _{amb} = T4: -40 +85 °C (-40 +185 ° T _{amb} = T5: -40 +70 °C (-40 +158 ° T _{amb} = T6: -40 +60 °C (-40 +140 °	F)		

11.11 HART communication


HART communication					
Load for a					
HART communicator connection	230 1100 Ω				
HART modem	230 500 Ω				
Cable	2-wire, shielded: ≤ 3.0 km (1.86 miles), multi- wired, shielded: ≤ 1.5 km (0.93 miles)				
Protocol	HART Version 5.x				

11.11 HART communication

HART communication					
PC/laptop requirements	IBM-compatible, user memory > 32 MB, hard disk > 70 MB, depending on the type of modem: RS 232 interface or USB connection, VGA graphic				
Software for computer	SIMATIC PDM				

Dimension drawings 12

12.1 SITRANS P, DS III/P410 for gauge pressure and absolute pressure from the gauge pressure series



- ① Electronics side, display (longer for cover with inspection window)¹⁾
- 2 Connection side¹⁾
- 3 Electrical connection:
 - Pg 13.5 gland (adapter)²⁾³⁾
 - M20 x 1.5 gland³⁾
 - 1/2-14 NPT gland
 - Han 7D/Han 8D plug^{2) 3)}
- 4 Harting adapter
- 5 Protective cap of the operating buttons
- 6 Blanking plug
- Safety catch

(only for flameproof encapsulation, not shown in the drawing)


- 8 Process connection: G½B connection pin or oval flange
- Mounting bracket (optional)
- Take an additional 20 mm (0.79 inches) thread length into account
- Not with "flameproof enclosure" type of protection


12.1 SITRANS P, DS III/P410 for gauge pressure and absolute pressure from the gauge pressure series

- Not for "FM + CSA [is + XP]" type of protection
- For Pg 13.5 with adapter, approx 45 mm (1.77 inches)
- 5) Minimum distance for rotating
- 6) SITRANS P410 is only available as gauge pressure and differential pressure version.

Figure 12-1 Pressure transmitter SITRANS P DS III/P410 for absolute pressure, from the gauge pressure series, dimensions in mm (inches)

12.2 SITRANS P DS III/P410 for differential pressure, flow rate and absolute pressure from the differential pressure series





- ① Electronics side, display (longer for cover with inspection window)¹⁾
- ② Connection side¹⁾
- 3 Electrical connection:
 - Pg 13.5 gland (adapter)²⁾³⁾
 - M20 x 1.5 gland
 - 1/2-14 NPT gland
 - Han 7D/Han 8D plug²⁾³
- 4 Harting adapter
- ⑤ Protective cap of the operating buttons
- 6 Blanking plug
- Safety catch

(only for "flameproof enclosure" type of protection, not shown in the drawing)


- 8 Lateral ventilation for liquid measurement (standard)
- 9 Lateral ventilation for gas measurement (addition H02)
- Mounting bracket (optional)
- 1 Sealing plug, with valve (optional)
- Process connection: 1/4-18 NPT (EN 61518)

12.2 SITRANS P DS III/P410 for differential pressure, flow rate and absolute pressure from the differential pressure series

- Take an additional 20 mm (0.79 inches) thread length into account
- Not with "flameproof enclosure" type of protection
- Not for "FM + CSA [IS + XP]" type of protection
- For Pg 13.5 with adapter, approx 45 mm (1.77 inches)
- ⁵⁾ 92 mm (3.62 inch) minimum distance for rotating the pointer
- 6) SITRANS P410 is only available as gauge pressure and differential pressure version.

Figure 12-2 Pressure transmitter SITRANS P DS III/P410 for differential pressure and flow rate, dimensions in mm (inches)

12.2 SITRANS P DS III/P410 for differential pressure, flow rate and absolute pressure from the differential pressure series




- ① Electronics side, display (longer for cover with inspection window)¹⁾
- 2 Connection end
- ③ Electrical connection:
 - Pg 13.5 gland (adapter)²⁾³⁾
 - M20 x 1.5 gland
 - 1/2-14 NPT gland
 - Han 7D/Han 8D plug²⁾³
- 4 Harting adapter
- 5 Protective cap of the operating buttons
- 6 Blanking plug
- Safety catch

(only for "flameproof enclosure" type of protection, not shown in the drawing)

- Sealing plug, with valve (optional)
- Process connection: ¼-18 NPT (IEC 61518)
- (1) Clearance for rotating the enclosure
- Take an additional 20 mm (0.79 inches) thread length into account
- 2) Not with "flameproof enclosure" type of protection
- Not for "FM + CSA [is + XP]" type of protection
- ⁴⁾ 92 mm (3.6 inch) minimum distance for rotating the pointer
- ⁵⁾ 74 mm (2.9 inch) for PN \geq 420 (MAWP \geq 6092 psi)
- 91 mm (3.6 inch) for PN \geq 420 (MAWP \geq 6092 psi)
- 7) 219 mm (8.62 inch) for PN \geq 420 (MAWP \geq 6092 psi)
- 8) For Pg 13.5 with adapter approx. 45 mm (1.77 inches)
- 6) SITRANS P410 is only available as gauge pressure and differential pressure version.

Figure 12-3 Pressure transmitter SITRANS P DS III/P410 for differential pressure and flow rate with caps for vertical differential pressure lines, dimensions in mm (inches)

12.3 SITRANS P DS III/P410 for level



- ① Electrical connection:
 - Pg 13.5 gland (adapter)²⁾³⁾
 - M20 x 1.5 gland
 - 1/2-14 NPT gland
 - Han 7D/Han 8D plug^{2) 3)}
- 2 Protective cap of the operating buttons
- 3 Blanking plug
- Safety catch

(only for "flameproof enclosure" type of protection, not shown in the drawing)


- (5) Connection side¹⁾
- 6 Electronics side, display


(longer for cover with inspection window)1)

- 7 Locking screw with valve (option)
- 8 Harting adapter
- Process connection: Minus side ¼-18 NPT (IEC 61518)
- Take an additional 20 mm (0.79 inches) thread length into account
- 2) Not with "flameproof enclosure" type of protection
- Not for "FM + CSA [is + XP]" type of protection
- ⁴⁾ 92 mm (3.62 inches) minimum distance for rotating the enclosure with pointer
- ⁵⁾ For Pg 13.5 with adapter, approx 45 mm (1.77 inches)
- 6) SITRANS P410 is only available as gauge pressure and differential pressure version.

Figure 12-4 Pressure transmitter SITRANS P DS III/P410 for level, including mounting flange, dimensions in mm (inches)

12.4 SITRANS P DS III/P410 (flush mounted)





- ① Electronics side, display
 - (longer for cover with inspection window)1)
- 2 Connection side¹⁾
- ③ Electrical connection:
 - M20 x 1.5 gland
 - 1/2-14 NPT gland
 - M12 connector
- 4 Protective cap of the operating buttons
- S Blanking plug
- Safety catch

(only for "flameproof enclosure" type of protection, not shown in the drawing)

- Process connection: see Flange table
- 1) In addition, allow approx. 20 mm (0.79 inch) for the thread length
- ²⁾ 92 mm (3.6 inches) minimum distance for rotating the enclosure with display
- 6) SITRANS P410 is only available as gauge pressure and differential pressure version.

Figure 12-5 SITRANS P DS III/P410 (flush mounted)

12.4 SITRANS P DS III/P410 (flush mounted)

12.4.1 Note 3A and EHDG

Note

Approvals

The references to the approvals for "EHEDG" and "3A" refer to the respective process connections and are not device-specific. Please refer to the technical specifications of the respective pressure transmitter to see whether the desired certificate is available for your device/flange combination.

12.4.2 Connections as per EN and ASME

Flange as per EN

EN 1092-1				
	DN	PN	⊘D	H ₂
	25	40	115 mm (4.5")	Approx. 52 mm (2")
· ==	25	100	140 mm (5.5")	
ı — — — — — — — — — — — — — — — — — — —	40	40	150 mm (5.9")	
†	40	100	170 mm (6.7")	
D	50	16	165 mm (6.5")	
	50	40	165 mm (6.5")	
	80	16	200 mm (7.9")	
	80	40	200 mm (7.9")	

Threaded connections

G3/4", G1" and G2" l	n accordanc	e with DIN 38	52	
	DN	PN	⊘D	H ₂
	3/4"	63	37 mm (1.5")	Approx. 45 mm (1.8")
	1"	63	48 mm (1.9")	Approx. 47 mm (1.9")
T ^N	2"	63	78 mm (3.1")	Approx. 52 mm (2")

Flanges as per ASME

ASME B 16.5				
	DN	CLASS	⊘D	H ₂
	1"	150	110 mm (4.3")	Approx. 52 mm (2")
. =	1"	300	125 mm (4.9")	
I T	1½"	150	130 mm (5.1")	
D	1½"	300	155 mm (6.1")	
J	2"	150	150 mm (5.9")	
	2"	300	165 mm (6.5")	
	3"	150	190 mm (7.5")	
	3"	300	210 mm (8.1")	
	4"	150	230 mm (9.1")	
	4"	300	255 mm (10.0")	

12.4.3 F&B and pharma flange

Connections as per DIN

DIN 11851				
	DN	PN	⊘D	H ₂
	50	25	92 mm (3.6")	Approx. 52 mm (2")
	80	25	127 mm (5.0")	

	DN	PN	⊘D	H ₂
	25	40	52 mm (2")	Approx. 52 mm (2")
. ====	40	40	65 mm (2.6")	
	50	40	78 mm (3.1")	
	100	40	130 mm (5.1")	
pprovals	EHEDG			

	DN	PN	⊘D	H ₂
	50	16	94 mm (3.7")	Approx. 52 mm (2")
. =====================================	65	16	113 mm (4.4")	
\	80	16	133 mm (5.2")	
T D	100	16	159 mm (6.3")	
Approvals	EHEDG			


	DN	PN	⊘D	H ₂
	50	16	94 mm (3.7")	Approx. 52 mm (2")
(((((((((((((((((((65	16	113 mm (4.4")	
I	80	16	133 mm (5.2")	
D	100	16	159 mm (6.3")	
Approvals	EHEDG			

50 25 77.5 mm (3.1") Approx. 52 mm 65 25 91 mm (3.6") 80 16 106 mm (4.2") 100 16 130 mm (5.1")		DN	PN	⊘D	H ₂
80 16 106 mm (4.2")		50	25	77.5 mm (3.1")	Approx. 52 mm (2")
	. ====	65	25	91 mm (3.6")	
100 16 130 mm (5.1")		80	16	106 mm (4.2")	<u> </u>
D		100	16	130 mm (5.1")	

Tri-Clamp as per DIN 32676						
	DN	PN	⊘D	H ₂		
	50	16	64 mm (2.5")	Approx. 52 mm (2")		
H D	65	16	91 mm (3.6")			


Other connections

Varivent® connector				
	DN	PN	⊘D	H ₂
	40-125	40	84 mm (3.3")	Approx. 52 mm (2")



Approvals	EHEDG	
, .pp. 0 . 00		

Connection in acc	ordance with D	RD		
	DN	PN	⊘D	H ₂
	65	40	105 mm (4 1")	Approx 52 mm (2")



BioConnect™ connectors

BioConnect™ scre	wed joint			
	DN	PN	⊘D	H ₂
	50	16	82 mm (3.2")	Approx. 52 mm (2")
. ===	65	16	105 mm (4.1")	
	80	16	115 mm (4.5")	
	100	16	145 mm (5.7")	
	2"	16	82 mm (3.2")	
 	2½"	16	105 mm (4.1")	
l - □	3"	16	105 mm (4.1")	
	4"	16	145 mm (5.7")	
Approvals	EHEDG			

	DN	PN	⊘D	H ₂
	50	16	110 mm (4.3")	Approx. 52 mm (2")
. =	65	16	140 mm (5.5")	
	80	16	150 mm (5.9")	
•	100	16	175 mm (6.9")	
l - □ □	2"	16	100 mm (3.9")	
	21/2"	16	110 mm (4.3")	
	3"	16	140 mm (5.5")	
	4"	16	175 mm (6.9")	
Approvals	EHEDG			

BioConnect™ c	DN	PN	⊘D	H ₂
	50	16	77.4 mm (3.0")	Approx. 52 mm (2")
	65	10	90.9 mm (3.6")	
	80	10	106 mm (4.2")	
_T	100	10	119 mm (4.7")	
	<u>2"</u>	16	64 mm (2.5")	
, 🚑	2½"	16	77.4 mm (3.0")	
l → D	3"	10	90.9 mm (3.6")	
	4"	10	119 mm (4.7")	
Approvals	EHEDG			

Connect S™ flange	d joint			
	DN	PN	⊘D	H ₂
	50	16	125 mm (4.9")	Approx. 52 mm (2")
. ==	65	10	145 mm (5.7")	
₽	80	10	155 mm (6.1")	
1	100	10	180 mm (7.1")	
D	2"	16	125 mm (4.9")	
	2½"	10	135 mm (5.3")	
	3"	10	145 mm (5.7")	
	4"	10	180 mm (7.1")	
Approvals	EHEDG			

Other connections

DN	PN	⊘D	H ₂
50	16	90 mm (3.5")	Approx. 52 mm (2")
65	16	120 mm (4.7")	

12.4.4 PMC Style

Connections for the paper industry

	DN	PN	⊘D	H₂
		-	40.9 mm (1.6")	Approx. 36.8 mm (1.4")
π ^N D	W44X1.2	25 cap nut		

PMC-Style Minibolt	DN	PN	⊘D	H ₂
	_	-	26.3 mm (1.0")	Approx. 33.1 mm (1.3"
I ²				

12.4.5 Special connections

Tank connection

	DN	PN	⊘D	H ₂
	TG52/50			
	43.5 mm	10	63 mm (2.5")	Approx. 63 mm (2.5")
	TG52/150			
T D	43.5 mm	10	63 mm (2.5")	Approx. 170 mm (6.7")

SMS connectors


	DN	PN	⊘D	H ₂
	2"	25	84 mm (3.3")	Approx. 52 mm (2.1")
· •	2½"	25	100 mm (3.9")	
	3"	25	114 mm (4.5")	

12.4 SITRANS P DS III/P410 (flush mounted)

SMS threaded socke	DN	PN		H ₂
	2"	25	70 x 1/6 mm (2.8")	Approx. 52 mm (2.1")
	2½"	25	85 x 1/6 mm (3.3")	
T D	3"	25	98 x 1/6 mm (3.9")	_

IDF connectors

	DN	PN	⊘D	H ₂
	2"	25	77 mm (3.0")	Approx. 52 mm (2.1")
A ()	2½"	25	91 mm (3.6")	
	3"	25	106 mm (4.2")	



Spare parts/accessories 13

13.1 Order data

In order to ensure that the ordering data you are using is not outdated, the latest ordering data is always available on the Internet:

Process instrumentation catalog (http://www.siemens.com/processinstrumentation/catalogs)

Selection and order data	Order no.
CD "sitrans p - pressure transmitters" with documentation in German/English/French/Spanish/Italian, etc.	A5E00090345
HART modem	
With USB interface	7MF4997-1DB ^{1) D)}
Weld-in support for PMC connection	
For Series SITRANS P DS III and SITRANS P300	
PMC Style Standard: Thread 1½"	7MF4997-2HA
PMC-Style Minibolt: flush mounted 1"	7MF4997-2HB
Gaskets for PMC connection, (1 set = 5 pieces)	
PTFE gasket for PMC Style Standard: Thread 1½"	7MF4997-2HC
Viton gasket for PMC Style Minibolt: flush mounted 1"	7MF4997-2HD
Weld-in adapter for PMC connection	
For connection of weld-in support delay during welding for:	
PMC Style Standard: Thread 1½"	7MF4997-2HE
PMC-Style Minibolt: flush mounted 1"	7MF4997-2HF

- 1) Available from stock
- D) Subject to export regulations AL: N, ECCN, EAR99H

Selection and order data	Order no.
Mounting bracket and fastening parts	
For SITRANS P DS III, DS III PA and DS III FF	
For gauge pressure transmitter (7MF403C.)	
For absolute pressure transmitter (7MF423C.)	
Made of steel	7MF4997-1AB
Made of stainless steel	7MF4997-1AH
Mounting bracket and fastening parts	
For SITRANS P DS III, DS III PA and DS III FF	
For gauge pressure transmitter (7MF403A.,B. andD.)	

13.1 Order data

Selection and order data	Order no.
For absolute pressure transmitter (7MF423A.,B. andD.)	
Made of steel	7MF4997-1AC
Made of stainless steel	7MF4997-1AJ
Mounting bracket and fastening parts	
For SITRANS P DS III, DS III PA and DS III FF	
Differential pressure transmitter with flange thread	
Made of steel	
For thread M10 (7MF433 and 7MF443)	7MF4997-1AD
For thread M12 (7MF453)	7MF4997-1AE
Made of stainless steel	
For thread M10 (7MF433 and 7MF443)	7MF4997-1AK
For thread M12 (7MF453)	7MF4997-1AL
Mounting bracket and fastening parts	
For SITRANS P DS III, DS III PA and DS III FF	
Differential and absolute pressure transmitter with flange thread 7/16-20 UNF (7MF433, 7MF443 and 7MF453)	
Made of steel	7MF4997-1AF
Made of stainless steel	7MF4997-1AM
Cover	
For SITRANS P DS III, DS III PA and DS III FF	
Made of aluminum die casting, including gasket	
Without inspection window	7MF4997-1BB
With inspection window	7MF4997-1BE
Made of stainless steel, including gasket	
Without inspection window	7MF4997-1BC
With inspection window	7MF4997-1BF
Digital display	
For SITRANS P DS III, DS III PA and DS III FF	
Including the fastening material	7MF4997-1BR
Measuring point label	
• not labeled (five pieces)	7MF4997-1CA
 labeled (1 unit) Specifications as per Y01 or Y02, Y15 and Y16 (refer to SITRANS P pressure transmitter) 	7MF4997-1CB-Z Y:
Fastening screws, 50 pieces for:	7MF4997-1CD
Measuring point label	
Earthing and connecting terminals	
Digital display	
Locking screws, (1 set = 2 pieces) for pressure cap	

Selection and order data	Order no.
Made of stainless steel	7MF4997-1CG
Made of Hastelloy	7MF4997-1CH
Vent valves, complete (1 set = 2 pieces)	
Made of stainless steel	7MF4997-1CP
Made of Hastelloy	7MF4997-1CQ
Electronics	
For SITRANS P DS III	7MF4997-1DK
For SITRANS P DS III PA	7MF4997-1DL
For SITRANS P DS III FF	7MF4997-1DM
Network card	
For SITRANS P DS III	7MF4997-1DN
For SITRANS P DS III PA and DS III FF	7MF4997-1DP
Sealing rings for pressure caps made of	
FPM (Viton)	7MF4997-2DA
PTFE (Teflon)	7MF4997-2DB
FEP (with silicon core, suitable for food)	7MF4997-2DC
FFPM (Kalrez, Compound 4079)	7MF4997-2DD
NBR (Buna N)	7MF4997-2DE

13.2 Order data for SIMATIC PDM

You can find ordering data in the Catalog FI 01 "Field devices for process automation in the Chapter "Communication and software > Software > SIMATIC PDM - Process Device Manager".

13.2 Order data for SIMATIC PDM

Appendix

A

A.1 Certificate

The certificates can be found on the enclosed CD and on the Internet under:

Certificates (http://www.siemens.com/processinstrumentation/certificates)

A.2 Literature and standards

No.	Standard	Description
/1/	IEC 61508	Functional safety of following systems:
	Section 1-7	Safety-instrumented
		Electrical
		Electronic
		Programmable
		Target group:
		Manufacturers and suppliers of equipment
/2/	IEC 61511	Functional safety - Safety systems for the process industry
	Section 1-3	Target group:
		Planners, constructors and users

A.3 Literature and catalogs

Table A- 1

No.	Title	Publisher	Order no.
/1/	Catalog ST 70 Components for Totally Integrated Automation	Siemens AG	E86060-K4670-A111
/2/	Catalog ST 80 SIMATIC Human Machine Interface Systems	Siemens AG	E86060-K4680-A101
/3/	FIELDBUS ONLINE Information about FOUNDATION™ Fieldbus	Fieldbus Foundation	www.fieldbus.org

See also

IK PI Catalog (http://www.automation.siemens.com/net/html_76/support/printkatalog.htm)

A.4 Overview of HART operating structure

The following overview applies to the HART communicator operating structure.

1 (PV meas) *) 2 (PV) status					
3 Module type			-		
4 Identification	1 Operation Unit	1 Tag	4		
		2 Long Tag> M **)	4		
	1	3 Descriptor	1		
		4 Message			
		5 Date			
	2 Device	1 Manufacturer]		
	1	2 Model	1		
	1	3 Device identification	1		
	1	4 Distributor	1		
		5 MLFB Order Number	1 MLFB Order No> M	1	
	1	6 Measurement type	1 MEI B OIGH 140> W	J	
	1	7 Fabrication-No	1		
	1	/ Fabrication-No	4		
	1	8 Final asembly number	4		
	1	9 Sensor serial number			
	1	10 Revisions	1 Universal rev.	1	
	1		2 Field device rev.]	
	1		3 Software rev.]	
			4 Hardware rev.	J	
	3 Basic Parameters	1 Pressure unit			
	1	2 LSL (Lower Sensor Limit)	1		
	1	3 USL (Upper Sensor Limit)	1		
	1	4 Minimum Span	1		
	1	5 LRV (Lower Range Value)	1		
	1		1		
	1	6 URV (Upper Range Value))	4		
	1	7 Pressure damping			
F. O F - 1 . 'O .	1.0-1-1-0-1-0-1	8 Pressure xfer function	xfer = transfer	1	
5 Config Inp/Outp	1 Quick-Setup & Meas.	1 PV, Current, Status	1 (PV meas) *)	1	
	1	I	2 AO (analogue output)	1	
	1	I	3 (PV) % range		_
	1	I	4 Statue con >	6 Diagnosis/Service	
	1		5 Measurement type		
	1	2 Meas.Val. & Status	1 Pressure Values	1 Pressure	
	1			2 Pres status	7
	1			3 Untrimmed pressure	7
	1			4 Untrimmed pres status	-
	1		2 Temperature Values		-
	1		2 Temperature values	1 Sens-Temp	-
	1			2 Sens-Temp status	4
	1			3 Electr-Temp	4
	1			4 Electr-Temp status	_
	1		3 Level, Vol, Mass Values	1 Level	
	1		(shown if valid items)	2 Level status	
	1			3 Volume	
	1			4 Volume status	
	1			5 Mass	7
	1			6 Mass status	┥
	1		4 Vol-, Mass- & Flow	1 Vol-Flow	\dashv
	1				-
	1		(shown if valid items)	2 Vol-Flow status	_
	1			3 Mass-Flow	_
	1			4 Mass-Flow status	
	1		5 Appl & Stat	1 Customer	
	1		(shown if valid items)	2 Customer Status	
	1	3 Quick-Setup	1 Tag		_
	1		2 Ext TAG> M	1	
	1		3 PV is	1	
	1	I	4 (PV) unit	1	
	1	I		1 Position corr> M	¬
	1	I	5 Position correction	i Position coff> M	_
	1	I	6 LRV	1	
	1	I	7 URV	1	
	1	I	8 Pressure damping	1	
			9 Pressure xfer function		_
	2 Input	1 Config Pres/Temp	1 Pressure sensor	1 Pressure	
			I	2 Untrimmed pres	
	1	I	I	3 Pressure units	1 Pres abs/rel
	1	I	I		2 Pressure unit
	1	I	I	I	3 Untrimmed pres
	1	I	2 Temperature sensor	1 Sens-Temp	- Committee press
	1	I	_ / 0po. 0.0.0 0011001	2 Electr-Temp	⊣
	1	I	I		1 Sane Tomo colt
	1	I	I	3 Temp units	1 Sens-Temp unit
	1	I	2 Pit-	4 P	2 Electr-Temp unit
	1	I	3 Pres units see>	1 Pressure sensor	4
	1		4 Temp units see>	2 Temperature sensor	4
	1	2 Display Process Variables	1 Prozess variables	1 (PV measurement)	_
	1		I	2 (PV) %rnge	
	1	I	I	3 AO	7
	I	I	I	4 (SV measurement)	7
		I	I	5 (TV measurement)	┪
		I	I	6 (QV measurement)	\dashv
			4 magayrama=t	o (QV measurement)	_
		2 Mars - Control 24	1 measurement	1	
		3 Meas Switch/Mapper		1	
		3 Meas Switch/Mapper	2 PV is		
		3 Meas Switch/Mapper	3 SV is		
		3 Meas Switch/Mapper	3 SV is 4 TV is		
		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is		
		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is	1 Input scaling	1 Pres abs/rel
		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is 6 (measurement) config	1 Input scaling	1 Pres abs/rel
		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is	1 Input scaling	2 Pressure unit
		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is 6 (measurement) config	1 Input scaling	2 Pressure unit 3 Input LRV
		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is 6 (measurement) config		2 Pressure unit 3 Input LRV 4 Input URV
		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is 6 (measurement) config	2 Level scaling	2 Pressure unit 3 Input LRV 4 Input URV 1 Level unit
to be continued		3 Meas Switch/Mapper	3 SV is 4 TV is 5 QV is 6 (measurement) config		2 Pressure unit 3 Input LRV 4 Input URV

continuance	continuance	continuance	continuance	3 Volume scaling	1 Volume unit
5 Config Inp/Outp	2 Input	3 Meas Switch/Mapper	6 (measurement) config		2 Vol LRV
1		o made o management	e.g. Level		3 Vol URV
					2 Density unit
					3 Density
					3 Mass unit
			6 (measurement) config	1 Input scaling	1 Pres abs/rel
				1 input scaling	
			e.g. Flow		2 Pressure unit
					3 Input LRV
					4 Input URV
				2 Flow scaling	1 Vol flow unit
					2 Vol flow LRV
					3 Vol flow URV
					2 Density unit
					3 Density
					3 Mass flow unit
			6 (measurement) config	1 Input scaling	1 Pres abs/rel
			e.g. Customer	1 input souning	2 Pressure unit
			e.g. Customer		3 Input LRV
					4 Input URV
					4 input URV
				3 Customer scaling	1 Cust unit (5 Ch)
					2 Cust LRV
					3 Cust URV
			7 Unser linearization	1 Special Curve status>	only if meas not pres
			if Level, Flow or Customer	2 No curve points	1
			this is valid - otherwise not	3 Setup special char> M	1
				4 Display special char> M	1
I		4 Meas.Limits & Span	1 Module range		1
			2 Active Device Variables	1 Pressure	1 Pressure unit
I		l	Donne variables		2 Pres USL
		l	1		3 Pres LSL
I		l	1		
I		l	1	I	4 Trimpoint sum
		l	1		5 Pres min.span
		l	1	2 Sens-Temp	1 Sens-Temp unit
		l	1		2 Sens-Temp USL
					3 Sens-Temp LSL
					4 Sens-Temp min.span
				3 Electr-Temp	1 Electr-Temp unit
					2 Electr-Temp USL
					3 Electr-Temp LSL
					4 Electr-Temp min.span
				4 Untrimmed Pres	1 Untrimmed Pres unit
				4 Ontrimined Fres	2 Untrimmed Pres USL
					3 Untrimmed Pres LSL
					4 Untr Pres min.span
			additional if measurement is mapped to level	5 Level	1 Level unit
					2 Level USL
					3 Level LSL
					4 Level min.span
			additional if measurement	6 Volume	1 Volume unit
			is mapped to level		2 Volume USL
					3 Volume LSL
					4 Volume min.span
			additional if measurement is mapped to level	7 Mass	1 Mass unit
					2 Mass USL
					3 Mass LSL
					4 Mass min.span
			additional if measurement	5 Vol-Flow	1 Vol-Flow unit
I		l	is mapped to flow		2 Vol-Flow USL
		l	is mapped to not		3 Vol-Flow LSL
		l			4 Vol-Flow min.span
I		l	additional if measurement is mapped to flow	6 Mass-Flow	1 Mass-Flow unit
		l		5 Mass-110W	2 Mass-Flow USL
I		l		I	
		l			3 Mass-Flow LSL
		l	additional if measurement	5.0	4 Mass-Flow min.span
I		l		5 Customer	1 (PV) unit
		l	is mapped to customer	I	2 Customer USL
		l	1	I	3 Customer LSL
I					4 Customer min. span
I	3 Output	1 Analog output	1 Analog output		
	'	1	2 Percent range	1	
I		l	3 Zero and Span	1 Zero/Span set	1 Apply values >1
		l	4 Pres xfer function		2 Out Scaling PV >2
		l	5 Startpoint square root	1	_ our commit + ~E
			5 Startpoliti square 100t	>1 Out Scaling DV	1 Unit
		l	1	>1 Out Scaling PV	1 Unit
		l	1	I	2 LRV
				1	3 URV
I		l	1	I	4 LSL
		l	1		5 USL
		l		>2 Apply values	1 Apply values> M
		l	6 Current Limits	1 Lower AO Limit	
		l	1	2 Upper AO Limit	1
I		l	7 Alarms	1 AO Alarm Type	1
I		l		2 Alarm LRV	1
I		l	1	3 Alarm URV	1
I		2. C	41	3 Alaini UKV	1
I		2 Sensor trim points	1 Lower sensor trim point	4	
I			2 Upper sensor trim point	1	
I		3 HART output	1 Polling address]	
I		· ·	2 Num request preambles	1	
I		l	3 Num response preambles	1	
I	4 Local meter	1 Meter type		-	
1	. 200011110101	2 Unit tracking	1		
to be continued		3 Local Display unit	1		

A.4 Overview of HART operating structure

5 Config Inp/Outp	Mech. Construction Mech = mechanical	5 Bargraph 6 Access Control 1 No of electronic changes 2 Design	Lokal keys control mode Write protect Set write protect> M Sensor Remote Seal	3 LCD LRV 4 LCD URV 1 Fill fluid 2 Isolation material 3 O ring material 4 Module range	1
		1 No of electronic changes	2 Write protect 3 Set write protect> M 1 Sensor	2 Isolation material 3 O ring material	
			3 Set write protect> M 1 Sensor	2 Isolation material 3 O ring material	
			1 Sensor	2 Isolation material 3 O ring material	
				2 Isolation material 3 O ring material	
	Moore Trade and Control of the Contr	2 Story.		2 Isolation material 3 O ring material	į
			2 Remote Seal	3 O ring material	1
			2 Remote Seal		1
			2 Remote Seal		
				1 Number remote seal (RS)	
			1	2 RS type	
				3 RS isolator material 4 RS fill fluid	
				5 Extension length	
	1			6 Extension type	
	(7 Capillar length	
		3 Process Connection	1 Process Connection		
1			2 DrainVent / plug mat	4	
,			3 DrainVent / plug pos 4 Process flange bolt	-	
			5 Flange type	1	
			6 Flange material	1	
		4 Electronic Connection	1 Electr housing material		
			2 Electr connection		
6 Certif & Approv	1 Explos. Protection		_		Explos = Explosion
7 Diagnosis/Service	1 Status	1 Status summary			Certif = Certification
		2 Extended device status	4		Approv = Approval
		3 Simulation status	1 Status arous 2	7	
		4 Hardw/Firmw status	1 Status group 2 2 Status group 3	1	
			3 Status group 4	1	
			4 Status group 5	1	
		5 Diag Alarm Status	1 Status group 15	1	
			2 Status group 16		
		6 Diag Warn Status	1 Status group 19	4	
	2 Device	1 Selftest/Reset	2 Status group 20 1 Selftest> M	-	
	2 Device	1 Selites/Reset	2 Display Test> M	-	
			3 Master reset> M	1	
			4 Changes Config	1 Config changed counter	1
		2 Sensor trim	1 Restore mfgr trims> M		mfgr = manufacture
			2 Sensor trim	1 Sensor trim points	1 Lower sensor trim p
				2 Sensor trim	2 Upper sensor trim po
				2 Sensor trim	1 Pres zero trim> M 2 Lower sensor trim
					3 Upper sensor trim
				3 Trimpoint summary	
			3 Trim analog output	1 D/A trim> M	ĺ
				2 Scaled D/A trim> M	
		2.631-5	4 Position correction	1 Position corr> M	i
		3 Simulation/Test	1 Loop test> M 2 Inputs> M	Simulation AO Simulation Fixed / Ramp	
		4 Access Control	1 Local keys control mode	Silidatori Fixed / Ramp	
			2 Write protect	1	
			3 Set write protect> M		
ļ	3 Diagnostic settings	1 W/A time unit	W/A = warning/alarm	-	
		2 Calib interval	1 Calib status	4	
			2 W/A acknowledge> M	1 Calib time	ı
		I	3 Calib timer	1 Calib time 2 Reset timer> M	
		I	4 Calib warning	E . YOUGH WITHOUT THE INI	1
			5 Calib alarm	1	
			6 W/A activation]	
		3 Service interval	1 Service status		
		I	2 W/A acknowledge> M	1.0 1 1	1
		I	3 Service timer	1 Service time 2 Reset timer> M	
		I	4 Service warning	∠ reset timer> M	ı
	i		5 Service alarm	1	
			6 W/A activation	1	
Ì		4 AO saturation	1 AO alarm type		
		I	2 Saturation alarm	1	
		1	3 Alarm duration	-	
			4 Alarm activation	1	
		5 Limiter setup		1	
		5 Limiter setup	1 Display limiter> M	1	
		5 Limiter setup	1 Display limiter> M 2 Setup limiter> M	-	
		5 Limiter setup	1 Display limiter> M 2 Setup limiter> M 3 Limiter status> M 4 Limiter: Ack W/A> M		
		5 Limiter setup	1 Display limiter> M 2 Setup limiter> M 3 Limiter status> M 4 Limiter: Ack W/A> M 5 CmpCnt: Ack W/A> M		CmpCnt =
		·	1 Display limiter> M 2 Setup limiter> M 3 Limiter status> M 4 Limiter: Ack W/A> M 5 CmpCnt: Ack W/A> M 6 Reset counter,> M		CmpCnt =
	4 View	5 Limiter setup 1 Operating hours	1 Display limiter> M 2 Setup limiter> M 3 Limiter status> M 4 Limiter: Ack W/A> M 5 CmpCnt: Ack W/A> M 6 Reset counter> M 1 Operating hours Electr		CmpCnt =
	4 View	1 Operating hours	Display limiter> M Setup limiter> M Setup limiter> M Limiter status> M Limiter status> M Limiter: Ack WiA> M CompCnt: Ack WiA> M Reset counter> M Departing hours Electr Operating hours Sensor	1 Pres may	CmpCnt =
	4 View	·	1 Display limiter> M 2 Setup limiter> M 3 Limiter status> M 4 Limiter: Ack W/A> M 5 CmpCnt: Ack W/A> M 6 Reset counter> M 1 Operating hours Electr	1 Pres max	CmpCnt =
	4 View	1 Operating hours	Display limiter> M Setup limiter> M Setup limiter> M Limiter status> M Limiter status> M Limiter: Ack WiA> M CompCnt: Ack WiA> M Reset counter> M Departing hours Electr Operating hours Sensor	2 Pres min	CmpCnt =
	4 View	1 Operating hours	1 Display limiter> M 2 Setup limiter> M 3 Limiter status> M 4 Limiter status> M 5 CmpCnt: Ack W/A> M 6 Reset counter> M 1 Operating hours Electr 2 Operating hours Sensor 1 Pressure pointer	2 Pres min 3 Reset pointer> M	CmpCnt =
	4 View	1 Operating hours	Display limiter> M Setup limiter> M Setup limiter> M Limiter status> M Limiter status> M Limiter: Ack WiA> M CompCnt: Ack WiA> M Reset counter> M Departing hours Electr Operating hours Sensor	2 Pres min 3 Reset pointer> M 1 Electr-Temp max 2 Electr- Temp min	CmpCnt =
	4 View	1 Operating hours	1 Display limiter -> M 2 Setup limiter -> M 3 Limiter status -> M 4 Limiter. Ack W/A -> M 5 CmpCnt. Ack W/A -> M 6 Reset counter> M 1 Operating hours Electr 2 Operating hours Sensor 1 Pressure pointer 2 Electr-Temp pointer	2 Pres min 3 Reset pointer> M 1 Electr-Temp max 2 Electr-Temp min 3 Reset pointer> M	CmpCnt =
	4 View	1 Operating hours	1 Display limiter> M 2 Setup limiter> M 3 Limiter status> M 4 Limiter status> M 5 CmpCnt: Ack W/A> M 6 Reset counter> M 1 Operating hours Electr 2 Operating hours Sensor 1 Pressure pointer	2 Pres min 3 Reset pointer> M 1 Electr-Temp max 2 Electr- Temp min	Ack = acknowledge CmpCnt = Comparation Count

A.5 Technical support

Technical Support

If this documentation does not provide complete answers to any technical questions you may have, contact Technical Support at:

- Support reguest (http://www.siemens.com/automation/support-reguest)
- More information about our Technical Support is available at Technical support (http://www.siemens.com/automation/csi/service)

Internet Service & Support

In addition to our documentation, Siemens provides a comprehensive support solution at:

Service&Support (http://www.siemens.com/automation/service&support) where you will find support news, support documents including EDDs and software, and also support from experts.

Additional Support

If you have additional questions about the device, please contact your local Siemens representative.

Find your local contact partner at:

Partner (http://www.automation.siemens.com/partner)

Documentation for various products and systems is available at:

 Instructions and manuals (http://www.siemens.com/processinstrumentation/documentation)

See also

Product information on SITRANS P in the Internet (http://www.siemens.com/sitransp)

Process instrumentation catalog (http://www.siemens.com/processinstrumentation/catalogs)

E-mail (mailto:support.automation@siemens.com)

A.5 Technical support

List of abbreviations

List of abbreviations

Table B- 1 Units

Abbreviation	In full	Meaning	
bar a	bar absolute	Pressure unit for absolute pressure	
bar g	bar gauge	Pressure unit for gauge pressure	
inH20 a	inches of water absolute	Pressure unit for absolute pressure	
inH₂0 g	inches of water gauge	Pressure unit for gauge pressure	
lb	Pound	Unit of weight	
psi a	psi absolute	Pressure unit for absolute pressure	
psi g	psi gauge	Pressure unit for gauge pressure	
Раа	Pascal absolute	Pressure unit for absolute pressure	
Pa g	Pascal gauge	Pressure unit for gauge pressure	

Table B- 2 Other abbreviations

Abbreviation	In full	Meaning
PED	Pressure Equipment Directive	
HART	Highway Addressable Remote Transducer	Standardized protocol for transmission of information between field device and automation system.
LRL	Engl.: Lower Range Limit	Lower end of the measuring range
LRV	Engl.: Lower Range Value	Lower end of the set measuring span
MA	Start of scale value	Lower end of the set measuring span
ME	Full scale value	Upper end of the set measuring span
MAWP	Engl.: Maximum Allowable Working Pressure (PS)	Maximum permissible operating pressure
NFPA	National Fire Protection Association	US - American Fire Protection Organization
F&B	Food and beverage industry	
PDM	Engl.: Process Device Manager	Tool for communication with HART devices (manufacturer: Siemens)
URL	Engl.: Upper Range Limit	Upper end of the measuring range
URV	Engl.: Upper Range Value	Upper end of the set measuring span

Abbreviation	Full term in English	Meaning
FIT	Failure in Time	Frequency of failure
		Number of faults within 10 ⁹ hours
HFT	Hardware Fault Tolerance	Hardware fault tolerance:
		Capability of a function unit to continue executing a required function in the presence of faults or deviations.
MooN	"M out of N" voting	Classification and description of the safety-instrumented system in terms of redundancy and the selection procedures used.
		A safety-instrumented system or part that consists of "N" independent channels. The channels are connected to each other in such a way that "M" channels are in each case sufficient for the device to perform the safety instrumented function.
		Example: Pressure measurement: 1002 architecture. A safety- instrumented system decides that a specified pressure limit has been exceeded if one out of two pressure sensors reaches this limit. In a 1001 architecture, there is only one pressure sensor.
MTBF	Mean Time Between Failures	Average period between two failures
MTTR	Mean Time To Restoration	Average period between the occurrence of a fault in a device or system and restoration of functionality
PFD	Probability of Dangerous Failure on Demand	Probability of dangerous failures of a safety function on demand
PFDavg	Average Probability of Dangerous Failure on Demand	Average probability of dangerous failures of a safety function on demand
SFF	Safe Failure Fraction	Proportion of safe failures:
		Proportion of failures without the potential to bring the safety- instrumented system into a dangerous or non-permissible func- tional status.
SIL	Safety Integrity Level	The international standard IEC 61508 defines four discrete Safety Integrity Levels (SIL 1 to SIL 4). Each level corresponds to a range of probability for failure of a safety function. The higher the Safety Integrity Level of the safety-instrumented system, the lower the probability that it will not execute the required safety functions.
SIS	Safety Instrumented System	A safety-instrumented system (SIS) executes the safety functions that are required to achieve or maintain a safe status in a system. It consists of sensors, logic unit/control system and final controlling elements.

Glossary

ATEX

ATEX is an abbreviation of the French term "Atmosphère explosible" (potentially explosive atmosphere). ATEX stands for both EC directives in the area of explosion protection: ATEX product directive 94/9/EC and ATEX operating directive 1999/92/EC.

Auxiliary power supply

Auxiliary power supply refers to an electrical supply or reference voltage which some electrical circuits require apart from the standard supply. The auxiliary power supply can, for example, be specially stabilized, have a particular level or polarity and/or other properties which are important for the correct functioning of switch components.

Auxiliary voltage

→ Auxiliary power supply

Dangerous failure

Failure with the potential to switch a safety-instrumented system to a hazardous or non-functioning safety state.

EEPROM

EEPROM (Electrically Erasable Programmable Read-Only Memory): a non-volatile, electronic memory module.

EEPROMs are often used where individual bytes of data (e.g. configuration data or runtime meters) change over time and must be stored safely in the event of a mains power failure.

Failure/Fault/Error

Failure:

A resource is no longer capable of executing a required function.

Fault/Error:

Undesired state of a resource indicated by its incapability of executing a required function.

Fault/Error

→ Failure/Fault/Frror

Final controlling element

Converter that converts electrical signals into mechanical or other non-electric variables.

Firmware

Firmware (FW) is software that is embedded on a chip in electronic devices – in contrast to software which is saved on hard disks, CD-ROMs or other media. These days, firmware is mostly stored in a flash memory or EEPROM.

Firmware usually contains the elementary functions for controlling the device, as well as input and output routines.

Frequency shift keying

Frequency shift keying is a simple form of modulation, where the digital values 0 and 1 modulate the actual current signal by means of two different frequencies.

Frequency Shift Keying (FSK)

→ Frequency shift keying

HART

HART (Highway Addressable Remote Transducer) is a standardized, widely used communications system used to structure industrial fieldbusses. The communications system provides digital communications for multiple participants (field devices) via a common databus. HART is based especially on the equally widely used 4/20 mA standard for the transfer of analog sensor signals. The cabling from existing older systems can be used directly and both systems operated in parallel.

HART specifies several protocol levels in the OSI model. It facilitates the transfer of process and diagnostics data and control signals between field devices and high-level control systems. Standardized parameter sets can be used for the manufacture-independent operation of all HART devices.

Typical applications include transmitters for measuring mechanical and electrical dimensions.

MAWP (PS)

Maximum Allowable Working Preassure (PS)

Non-volatile memory

→ EEPROM

Risk

Combination of the probability of damage occurring and the extent of the damage.

Safety function

Defined function executed by a safety-instrumented system with the objective of attaining or maintaining a safe system state by taking a defined hazardous incident into account.

Example:

Limit pressure monitoring

Safety Integrity Level

→ S/L

Safety-instrumented system

A safety-instrumented system (SIS) executes the safety functions that are required to achieve or maintain a safe state in a system. It consists of a sensor, logic unit/control system and final controlling element.

Example:

A safety-instrumented system is made up of a pressure transmitter, a limit signal sensor and a control valve.

Sensor

Converter that converts mechanical or other non-electric variables into electrical signals.

SIL

The international standard IEC 61508 defines four discrete safety integrity levels (SIL) from SIL 1 to SIL 4. Each level corresponds to a probability range for the failure of a safety function. The higher the SIL of the safety-instrumented system, the higher the probability that the required safety function will work.

The SIL which can be achieved is determined by the following safety-instrumented characteristics:

- Average probability of failure on demand (PFD_{AVG})
- Hardware fault tolerance (HFT)
- Safe failure fraction (SFF)

srli2

→ srlin2

srlin2

"srli2" or "srlin2" is a type of square root extracting characteristic curve for the output current. This characteristic curve type is proportional to the flow rate, linear in two levels up to the application point and has a pre-defined application point of 10%.

"srli2" or "srlin2" are synonymous and technically there is no difference between them. The abbreviation "srli2" is used in sections that refer to the on-site operation of the pressure transmitter. The reason for the abbreviation is that the pressure transmitter display is restricted to five characters. The abbreviation "srlin2" is used for HART operation.

Index

	Configuration data, 134, 134 Connector
3	M12, 67
3A, 226	Constant current operation, 94, 126
JA, 220	Correct usage, (See improper device modifications)
	Current limit, 127
A	Current simulator, 94
Asknowledgement 120	Current transmitter, 126
Acknowledgement, 138 Additional Support, 243	Customer Support Hotline, 243
Ambient temperature, 206, 206, 207, 208, 209	
Effect, 195, 196, 197, 198, 198, 200, 202, 203, 204	D
Analog output, 122	Device
Analog output block, 122	Device
Analog output stage, 109	Electrostatic-sensitive, 18, 178 Device variable, 77, 118
Appendix, 239	DV, 110
Approval	Diagnostic interrupt, 126, 137
3A, 226	Diagnostic warning, 137
EHEDG, 226 Approval plate, (Layout of nameplate with approval	Differential pressure, 20, 21, 98, 136
information)	Direct sunlight, 41
Arrow display, 76	Display of unit, 74
	Downscaling, 82, 82
_	DV Device variable, 110
В	Dynamic variable (DV), 109
Bar graph, 131	Byriainile variable (BV), 100
Blind adjustment, 125	
Bridge output voltage, 29, 30, 31	E
button and function lock	EHEDG, 226
Activate, 153	Electrical damping, 126
	Electromagnetic compatibility, 206, 207, 207, 208, 209
С	Electronics, 153
	Electrostatic-sensitive device (ESD), 18, 178
Calibration	EMC, 206, 207, 207, 208, 209
Current simulator, 132	Error display, 75
Calibration interval, 138	
Calibration timer, 137 Certificate, 239	F
Certificates, 15	
Certification, 239	Factory calibration, 134
Characteristic curve	Failure current, 126
lin, 98	Fast recording of measured values, 126 Fast Response Mode, 126
srlin, 98	Filling liquid, 29, 31, 32
srlin2, 98	Firmware, 12
sroff, 98	Flange, 31, 47
Characteristics Safety, 152	Full scale value
Jaioty, 102	Set, 81, 81

Function chart, 33	Differential pressure and flow rate, 30 Gauge pressure, 29 Level, 31	
H	Measuring mode, 81, 81, 108, 110, 114	
Han plug, 66 HART Modem, 19 HART communicator, 107 Hazardous area Laws and directives, 15 History, 11 Hotline, 243	Measuring mode selector, 109, 110 Message OVER, 77 UNDER, 77 Mounting bracket, 44 Mounting flange, 31 MTTR, 152 multi-channel operation, 148	
11041110, 210	MWP, (See MAWP)	
	N	
Improper device modifications, 16 Input scaling, 112, 114, 117 Install	Nameplate, 23	
Remote seal, 51	0	
Installation, 43, 43, 44 Internet, 243	Operating structure, 240 Operation Local, 81	
K	Output scaling, 112, 115, 118	
Keyboard lock, 96	Output scaling, 112, 115, 118	
	Р	
L		
L (level), 113 Layout of nameplate with general information, 23 LCD scaling, 123 Level, 21 Limit monitor, 143 lin, 98, 136 Load, 194	Pairs of min/max pointer, 138 Pairs of values, 115, 117 Plug Han, 66 Position correction, 93, 93 Pressure simulation, 142 Pressure unit, 130 Primary variable, 77, 101 Process connection, 22	
M	Proof test, 152 PV	
M12 connector, 67 MA Start of scale value, 110 Mapper, 109, (See also:Variable mapper)	Primary variable, 101, 110 PV Primary variable, 101, 110	
Mass, 111, 113 MAWP, 245	Q	
ME Full scale value, 110 Measured value display, 81, 102	Qualified personnel, 17 QV	
Measured value status, 119	Quarternary variable, 110	
Measuring cell Absolute pressure, 33		

R Ramp function, 141, 143 Remote seal Description, 35 Install, 51 Maintenance, 181 W Response time, 139 Root application point, 99, 114 S Ζ Safety Checking, 152 Safety function, 147 safety-relevant Parameter, 151 Saturation limit, 127 Scope of delivery, 13 Sensor trim, 131 Service, 243 Service timer, 137 Shut-off valve, 166, 168, 171, 172, 173 Signal range, 77 SIL 3, 148 Simulation, 138, 141 Span, 82, 82 srlin, 98, 136 srlin2, 98, 136 sroff, 98, 136 Stabilizing valve, 169, 169, 171, 173 Start of scale value Set, 81, 81 Stop time, 139 Structure, 21 Support, 243 SV Secondary variable, 110 Т Tank connection, 233 Test certificates, 15 Trim Sensor, 131 Trimming lower trim point, 132 upper trim point, 132 Turning range, 58 TV Tertiary variable, 110

V

Variable mapper, 109, 109 Vent valve, 135, 171, 173 Volume, 113

Write protection, 96, 153

Zero point calibration, 93, 93 Zero-point calibration, 125

Get more information

www.siemens.com/processautomation www.siemens.com/sitransp

Siemens AG Process Industries and Drives Process Automation 76181 Karlsruhe GERMANY Subject to change without prior notice A5E00047092-10 © Siemens AG 2015

